
SPE Runtime Management Library

Version 2.0

October 17, 2008

©Copyright International Business Machines Corporation, Sony Computer Entertainment Incorporated, Toshiba Corporation 2003, 2004, 2005, 2006

All Rights Reserved
Printed in the United States of America June 2006

The following are trademarks of International Business Machines Corporation in the United States, or other countries, or both.

IBM PowerPC
IBM Logo PowerPC Architecture

Other company, product, and service names may be trademarks or service marks of others. All information contained in this document is subject to change without notice. The products described in this document are NOT intended for use in applications such as implantation, life support, or other hazardous uses where malfunction could result in death, bodily injury, or catastrophic property damage. The information contained in this document does not affect or change IBM product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of IBM or third parties. All information contained in this document was obtained in specific environments, and is presented as an illustration. The results obtained in other operating environments may vary.

THE INFORMATION CONTAINED IN THIS DOCUMENT IS PROVIDED ON AN “AS IS” BASIS. In no event will IBM be liable for damages arising directly or indirectly from any use of the information contained in this document.

IBM Systems and Technology Group
2070 Route 52, Bldg. 330
Hopewell Junction, NY 12533-6351

The IBM home page can be found at ibm.com

The IBM semiconductor solutions home page can be found at ibm.com/chips

June 15, 2006

Contents

1	Overview	1
1.1	Terminology	1
1.2	Usage Scenarios	1
2	Data Structure Documentation	5
2.1	addr64 Union Reference	5
2.2	fd_attr Struct Reference	6
2.3	image_handle Struct Reference	7
2.4	mfc_command_parameter_area Struct Reference	8
2.5	spe_context Struct Reference	10
2.6	spe_context_base_priv Struct Reference	12
2.7	spe_context_event_priv Struct Reference	16
2.8	spe_context_info Struct Reference	18
2.9	spe_event_data Union Reference	19
2.10	spe_event_unit Struct Reference	20
2.11	spe_gang_context Struct Reference	23
2.12	spe_gang_context_base_priv Struct Reference	24
2.13	spe_ld_info Struct Reference	25
2.14	spe_mfc_command_area Struct Reference	26
2.15	spe_mssync_area Struct Reference	29
2.16	spe_program_handle Struct Reference	30
2.17	spe_reg128 Struct Reference	31
2.18	spe_sig_notify_1_area Struct Reference	32
2.19	spe_sig_notify_2_area Struct Reference	33
2.20	spe_spu_control_area Struct Reference	34
2.21	spe_stop_info Struct Reference	36
3	File Documentation	39
3.1	accessors.c File Reference	39

3.2	cbea_map.h File Reference	43
3.3	create.c File Reference	44
3.4	create.h File Reference	52
3.5	design.txt File Reference	54
3.6	dma.c File Reference	55
3.7	dma.h File Reference	62
3.8	elf_loader.c File Reference	64
3.9	elf_loader.h File Reference	70
3.10	handler_utils.h File Reference	76
3.11	image.c File Reference	79
3.12	info.c File Reference	83
3.13	info.h File Reference	86
3.14	lib_builtin.c File Reference	89
3.15	lib_builtin.h File Reference	93
3.16	libspe2-types.h File Reference	95
3.17	libspe2.h File Reference	104
3.18	load.c File Reference	108
3.19	mbox.c File Reference	111
3.20	mbox.h File Reference	120
3.21	run.c File Reference	121
3.22	spe_event.c File Reference	128
3.23	spebase.h File Reference	140
3.24	speevent.h File Reference	178

Chapter 1

Overview

The libspe2 functionality is split into 4 libraries:

- **libspe-base** This library provides the basic infrastructure to manage and use SPEs. The central data structure is a SPE context `spe_context`. It contains all information necessary to manage an SPE, run code on it, communicate with it, and so on. To use the libspe-base library, the header file `spebase.h` has to be included and an application needs to link against `libspebase.a` or `libspebase.so`.
- **libspe-event** This is a convenience library for the handling of events generated by an SPE. It is based on libspe-base and epoll. Since the `spe_context` introduced by libspe-base contains the file descriptors to mailboxes etc, any other event handling mechanism could also be implemented based on libspe-base.

1.1 Terminology

- **main thread** usually the application main thread running on a PPE
- **SPE thread** a thread that uses SPEs. Execution starts on the PPE. Execution shifts between PPE and an SPE back and fro, e.g., PPE services system calls for SPE transparently

1.2 Usage Scenarios

1.2.1 Single-threaded sample

Note: In the new model, it is not necessary to have a main thread - the SPE thread can be the only application thread. It may run parts of its code on PPE and then start an SPE, e.g., for an accelerated function. The main thread is needed only if you want to use multiple SPEs concurrently. The following minimalistic sample illustrates the basic steps:




Figure 1.1: Simple program

Here is the same sample with some error checking:

1.2.2 Multi-threaded sample

This illustrates a threaded sample using the pthread library:




Figure 1.2: Simple pthread program

Here is the same sample with some error checking:

1.2.3 Problem state mapping samples

This illustrates accessing the MFC Local Store Address Register.

1.2.4 Event samples

This illustrates a sample using the event library. The event, which we receive is of course that the spu program has stopped, because otherwise we would not get there.




Figure 1.3: Simple event program

Events are more useful in multithreaded environments:

Chapter 2

Data Structure Documentation

2.1 addr64 Union Reference

```
#include <elf_loader.h>
```

Data Fields

- unsigned long long [ull](#)
- unsigned int [ui](#) [2]

2.1.1 Detailed Description

Definition at line 28 of file elf_loader.h.

2.1.2 Field Documentation

2.1.2.1 unsigned long long ull

Definition at line 30 of file elf_loader.h.

Referenced by [_base_spe_context_run\(\)](#).

2.1.2.2 unsigned int ui[2]

Definition at line 31 of file elf_loader.h.

Referenced by [_base_spe_context_run\(\)](#).

The documentation for this union was generated from the following file:

- [elf_loader.h](#)

2.2 fd_attr Struct Reference

Data Fields

- const char * [name](#)
- int [mode](#)

2.2.1 Detailed Description

Definition at line 37 of file `create.c`.

2.2.2 Field Documentation

2.2.2.1 const char* name

Definition at line 38 of file `create.c`.

Referenced by `_base_spe_open_if_closed()`.

2.2.2.2 int mode

Definition at line 39 of file `create.c`.


Referenced by `_base_spe_open_if_closed()`.

The documentation for this struct was generated from the following file:

- [create.c](#)

2.3 image_handle Struct Reference

Collaboration diagram for image_handle:



Data Fields

- [spe_program_handle_t speh](#)
- [unsigned int map_size](#)

2.3.1 Detailed Description

Definition at line 32 of file image.c.

2.3.2 Field Documentation

2.3.2.1 spe_program_handle_t speh

Definition at line 33 of file image.c.

Referenced by `_base_spe_image_close()`, and `_base_spe_image_open()`.

2.3.2.2 unsigned int map_size

Definition at line 34 of file image.c.

Referenced by `_base_spe_image_close()`, and `_base_spe_image_open()`.

The documentation for this struct was generated from the following file:

- [image.c](#)

2.4 mfc_command_parameter_area Struct Reference

```
#include <dma.h>
```

Data Fields

- `uint32_t pad`
- `uint32_t lsa`
- `uint64_t ea`
- `uint16_t size`
- `uint16_t tag`
- `uint16_t class`
- `uint16_t cmd`

2.4.1 Detailed Description

Definition at line 27 of file dma.h.

2.4.2 Field Documentation

2.4.2.1 `uint32_t pad`

Definition at line 28 of file dma.h.

2.4.2.2 `uint32_t lsa`

Definition at line 29 of file dma.h.

2.4.2.3 `uint64_t ea`

Definition at line 30 of file dma.h.

2.4.2.4 `uint16_t size`

Definition at line 31 of file dma.h.

2.4.2.5 `uint16_t tag`

Definition at line 32 of file dma.h.

2.4.2.6 `uint16_t class`

Definition at line 33 of file dma.h.

2.4.2.7 uint16_t cmd

Definition at line 34 of file dma.h.


The documentation for this struct was generated from the following file:

- [dma.h](#)

2.5 spe_context Struct Reference

```
#include <libspe2-types.h>
```

Collaboration diagram for spe_context:



Data Fields

- `spe_program_handle_t handle`
- `struct spe_context_base_priv * base_private`
- `struct spe_context_event_priv * event_private`

2.5.1 Detailed Description

SPE context The SPE context is one of the base data structures for the libspe2 implementation. It holds all persistent information about a "logical SPE" used by the application. This data structure should not be

accessed directly, but the application uses a pointer to an SPE context as an identifier for the "logical SPE" it is dealing with through libspe2 API calls.

Definition at line 64 of file libspe2-types.h.

2.5.2 Field Documentation

2.5.2.1 spe_program_handle_t handle

Definition at line 72 of file libspe2-types.h.

2.5.2.2 struct spe_context_base_priv* base_private [read]

Definition at line 76 of file libspe2-types.h.

Referenced by __base_spe_spe_dir_get(), __base_spe_stop_event_source_get(), __base_spe_stop_event_target_get(), __base_spe_close_if_open(), __base_spe_context_create(), __base_spe_context_lock(), __base_spe_context_run(), __base_spe_context_unlock(), __base_spe_handle_library_callback(), __base_spe_in_mbox_status(), __base_spe_in_mbox_write(), __base_spe_ls_area_get(), __base_spe_mfcio_tag_status_read(), __base_spe_mssync_start(), __base_spe_mssync_status(), __base_spe_open_if_closed(), __base_spe_out_intr_mbox_status(), __base_spe_out_mbox_read(), __base_spe_out_mbox_status(), __base_spe_program_load(), __base_spe_program_load_complete(), __base_spe_ps_area_get(), __base_spe_signal_write(), and __event_spe_event_handler_register().

2.5.2.3 struct spe_context_event_priv* event_private [read]

Definition at line 77 of file libspe2-types.h.


The documentation for this struct was generated from the following file:

- [libspe2-types.h](#)

2.6 spe_context_base_priv Struct Reference

```
#include <spebase.h>
```

Collaboration diagram for spe_context_base_priv:



Data Fields

- `pthread_mutex_t fd_lock` [NUM_MBOX_FDS]
- `int fd_grp_dir`
- `int fd_spe_dir`
- `unsigned int flags`
- `int spe_fds_array` [NUM_MBOX_FDS]
- `int spe_fds_refcount` [NUM_MBOX_FDS]
- `int ev_pipe` [2]
- `void * psmmap_mmap_base`
- `void * mem_mmap_base`

- void * [mfc_mmap_base](#)
- void * [mssync_mmap_base](#)
- void * [cntl_mmap_base](#)
- void * [signal1_mmap_base](#)
- void * [signal2_mmap_base](#)
- int entry
- [spe_program_handle_t * loaded_program](#)
- int emulated_entry
- int active_tagmask

2.6.1 Detailed Description

Definition at line 61 of file spebase.h.

2.6.2 Field Documentation

2.6.2.1 pthread_mutex_t fd_lock[NUM_MBOX_FDS]

Definition at line 65 of file spebase.h.

Referenced by [_base_spe_context_create\(\)](#), [_base_spe_context_lock\(\)](#), and [_base_spe_context_unlock\(\)](#).

2.6.2.2 int fd_grp_dir

Definition at line 68 of file spebase.h.

2.6.2.3 int fd_spe_dir

Definition at line 71 of file spebase.h.

Referenced by [__base_spe_spe_dir_get\(\)](#), [_base_spe_context_create\(\)](#), [_base_spe_context_run\(\)](#), [_base_spe_open_if_closed\(\)](#), and [_base_spe_program_load_complete\(\)](#).

2.6.2.4 unsigned int flags

Definition at line 74 of file spebase.h.

Referenced by [_base_spe_context_create\(\)](#), [_base_spe_context_run\(\)](#), [_base_spe_handle_library_callback\(\)](#), [_base_spe_in_mbox_status\(\)](#), [_base_spe_in_mbox_write\(\)](#), [_base_spe_mfcio_tag_status_read\(\)](#), [_base_spe_mssync_start\(\)](#), [_base_spe_mssync_status\(\)](#), [_base_spe_out_intr_mbox_status\(\)](#), [_base_spe_out_mbox_read\(\)](#), [_base_spe_out_mbox_status\(\)](#), [_base_spe_program_load\(\)](#), [_base_spe_signal_write\(\)](#), and [_event_spe_event_handler_register\(\)](#).

2.6.2.5 int spe_fds_array[NUM_MBOX_FDS]

Definition at line 77 of file spebase.h.

Referenced by [_base_spe_close_if_open\(\)](#), [_base_spe_context_create\(\)](#), and [_base_spe_open_if_closed\(\)](#).

2.6.2.6 int spe_fds_refcount[NUM_MBOX_FDS]

Definition at line 78 of file spebase.h.

Referenced by _base_spe_close_if_open(), and _base_spe_open_if_closed().

2.6.2.7 int ev_pipe[2]

Definition at line 81 of file spebase.h.

Referenced by __base_spe_stop_event_source_get(), and __base_spe_stop_event_target_get().

2.6.2.8 void* psmmap_mmap_base

Definition at line 84 of file spebase.h.

Referenced by _base_spe_context_create().

2.6.2.9 void* mem_mmap_base

Definition at line 85 of file spebase.h.

Referenced by _base_spe_context_create(), _base_spe_context_run(), _base_spe_handle_library_callback(), _base_spe_ls_area_get(), and _base_spe_program_load().

2.6.2.10 void* mfc_mmap_base

Definition at line 86 of file spebase.h.

Referenced by _base_spe_context_create(), and _base_spe_ps_area_get().

2.6.2.11 void* mssync_mmap_base

Definition at line 87 of file spebase.h.

Referenced by _base_spe_context_create(), _base_spe_mssync_start(), _base_spe_mssync_status(), and _base_spe_ps_area_get().

2.6.2.12 void* cntl_mmap_base

Definition at line 88 of file spebase.h.

Referenced by _base_spe_context_create(), _base_spe_in_mbox_status(), _base_spe_out_intr_mbox_status(), _base_spe_out_mbox_status(), and _base_spe_ps_area_get().

2.6.2.13 void* signal1_mmap_base

Definition at line 89 of file spebase.h.

Referenced by _base_spe_context_create(), _base_spe_ps_area_get(), and _base_spe_signal_write().

2.6.2.14 void* signal2_mmap_base

Definition at line 90 of file spebase.h.

Referenced by _base_spe_context_create(), _base_spe_ps_area_get(), and _base_spe_signal_write().

2.6.2.15 int entry

Definition at line 93 of file spebase.h.

Referenced by _base_spe_context_run(), and _base_spe_program_load().

2.6.2.16 spe_program_handle_t* loaded_program

Definition at line 99 of file spebase.h.

Referenced by _base_spe_context_create(), _base_spe_program_load(), and _base_spe_program_load_complete().

2.6.2.17 int emulated_entry

Definition at line 103 of file spebase.h.

Referenced by _base_spe_context_run(), and _base_spe_program_load().

2.6.2.18 int active_tagmask

Definition at line 108 of file spebase.h.

Referenced by _base_spe_mfcio_tag_status_read().


The documentation for this struct was generated from the following file:

- [spebase.h](#)

2.7 spe_context_event_priv Struct Reference

```
#include <speevent.h>
```

Collaboration diagram for spe_context_event_priv:



Data Fields

- `pthread_mutex_t lock`
- `pthread_mutex_t stop_event_read_lock`
- `int stop_event_pipe [2]`
- `spe_event_unit_t events [__NUM_SPE_EVENT_TYPES]`

2.7.1 Detailed Description

Definition at line 35 of file speevent.h.

2.7.2 Field Documentation

2.7.2.1 pthread_mutex_t lock

Definition at line 37 of file speevent.h.

Referenced by _event_spe_context_finalize(), and _event_spe_context_initialize().

2.7.2.2 pthread_mutex_t stop_event_read_lock

Definition at line 38 of file speevent.h.

Referenced by _event_spe_context_finalize(), _event_spe_context_initialize(), and _event_spe_stop_info_read().

2.7.2.3 int stop_event_pipe[2]

Definition at line 39 of file speevent.h.

Referenced by _event_spe_context_finalize(), _event_spe_context_initialize(), _event_spe_context_run(), _event_spe_event_handler_deregister(), _event_spe_event_handler_register(), and _event_spe_stop_info_read().

2.7.2.4 spe_event_unit_t events[__NUM_SPE_EVENT_TYPES]

Definition at line 40 of file speevent.h.


Referenced by _event_spe_context_initialize(), _event_spe_event_handler_deregister(), and _event_spe_event_handler_register().

The documentation for this struct was generated from the following file:

- [speevent.h](#)

2.8 spe_context_info Struct Reference

Collaboration diagram for spe_context_info:



Data Fields

- int [spe_id](#)
- unsigned int [npc](#)
- unsigned int [status](#)
- struct [spe_context_info](#) * [prev](#)

2.8.1 Detailed Description

Definition at line 39 of file run.c.

2.8.2 Field Documentation

2.8.2.1 int spe_id

Definition at line 40 of file run.c.

Referenced by [_base_spe_context_run\(\)](#).

2.8.2.2 unsigned int npc

Definition at line 41 of file run.c.

Referenced by [_base_spe_context_run\(\)](#).

2.8.2.3 unsigned int status

Definition at line 42 of file run.c.

Referenced by [_base_spe_context_run\(\)](#).

2.8.2.4 struct spe_context_info* prev [read]

Definition at line 43 of file run.c.

Referenced by [_base_spe_context_run\(\)](#).

The documentation for this struct was generated from the following file:

- [run.c](#)

2.9 spe_event_data Union Reference

```
#include <libspe2-types.h>
```

Data Fields

- void * [ptr](#)
- unsigned int [u32](#)
- unsigned long long [u64](#)

2.9.1 Detailed Description

spe_event_data_t User data to be associated with an event

Definition at line 143 of file libspe2-types.h.

2.9.2 Field Documentation

2.9.2.1 void* ptr

Definition at line 145 of file libspe2-types.h.

Referenced by [_event_spe_event_handler_register\(\)](#).

2.9.2.2 unsigned int u32

Definition at line 146 of file libspe2-types.h.

2.9.2.3 unsigned long long u64

Definition at line 147 of file libspe2-types.h.


The documentation for this union was generated from the following file:

- [libspe2-types.h](#)

2.10 spe_event_unit Struct Reference

```
#include <libspe2-types.h>
```

Collaboration diagram for spe_event_unit:



Data Fields

- unsigned int events
- [spe_context_ptr_t spe](#)
- [spe_event_data_t data](#)

2.10.1 Detailed Description

`spe_event_t`

Definition at line 152 of file `libspe2-types.h`.

2.10.2 Field Documentation

2.10.2.1 unsigned int events

Definition at line 154 of file `libspe2-types.h`.

Referenced by `_event_spe_event_handler_deregister()`, and `_event_spe_event_handler_register()`.

2.10.2.2 `spe_context_ptr_t spe`

Definition at line 155 of file `libspe2-types.h`.

Referenced by `_event_spe_context_initialize()`, `_event_spe_event_handler_deregister()`, `_event_spe_event_handler_register()`, and `_event_spe_event_wait()`.

2.10.2.3 `spe_event_data_t data`

Definition at line 156 of file `libspe2-types.h`.

Referenced by `_event_spe_event_handler_register()`.


The documentation for this struct was generated from the following file:

- [libspe2-types.h](#)

2.11 spe_gang_context Struct Reference

```
#include <libspe2-types.h>
```

Collaboration diagram for spe_gang_context:



Data Fields

- struct [spe_gang_context_base_priv](#) * [base_private](#)
- struct [spe_gang_context_event_priv](#) * [event_private](#)

2.11.1 Detailed Description

SPE gang context The SPE gang context is one of the base data structures for the libspe2 implementation. It holds all persistent information about a group of SPE contexts that should be treated as a gang, i.e., be execute together with certain properties. This data structure should not be accessed directly, but the application uses a pointer to an SPE gang context as an identifier for the SPE gang it is dealing with through libspe2 API calls.

Definition at line 94 of file libspe2-types.h.

2.11.2 Field Documentation

2.11.2.1 struct spe_gang_context_base_priv* base_private [read]

Definition at line 99 of file libspe2-types.h.

Referenced by [_base_spe_context_create\(\)](#), and [_base_spe_gang_context_create\(\)](#).

2.11.2.2 struct spe_gang_context_event_priv* event_private [read]

Definition at line 100 of file libspe2-types.h.

The documentation for this struct was generated from the following file:

- [libspe2-types.h](#)

2.12 spe_gang_context_base_priv Struct Reference

```
#include <spebase.h>
```

Data Fields

- unsigned int flags
- int fd_gang_dir
- char gangname [256]

2.12.1 Detailed Description

[spe_context](#): This holds the persistant information of a SPU instance it is created by `spe_create_context()`
Definition at line 150 of file spebase.h.

2.12.2 Field Documentation

2.12.2.1 unsigned int flags

Definition at line 153 of file spebase.h.

2.12.2.2 int fd_gang_dir

Definition at line 156 of file spebase.h.

2.12.2.3 char gangname[256]

Definition at line 158 of file spebase.h.

Referenced by `_base_spe_context_create()`, and `_base_spe_gang_context_create()`.

The documentation for this struct was generated from the following file:

- [spebase.h](#)

2.13 spe_ld_info Struct Reference

```
#include <elf_loader.h>
```

Data Fields

- unsigned int entry

2.13.1 Detailed Description

Definition at line 34 of file elf_loader.h.

2.13.2 Field Documentation

2.13.2.1 unsigned int entry

Definition at line 36 of file elf_loader.h.

Referenced by _base_spe_load_spe_elf(), and _base_spe_program_load().

The documentation for this struct was generated from the following file:

- [elf_loader.h](#)

2.14 spe_mfc_command_area Struct Reference

```
#include <cbea_map.h>
```

Data Fields

- unsigned char [reserved_0_3](#) [4]
- unsigned int [MFC_LSA](#)
- unsigned int [MFC_EAH](#)
- unsigned int [MFC_EAL](#)
- unsigned int [MFC_Size_Tag](#)
- union {
 - unsigned int [MFC_ClassID_CMD](#)
 - unsigned int [MFC_CMDStatus](#)};
- unsigned char [reserved_18_103](#) [236]
- unsigned int [MFC_QStatus](#)
- unsigned char [reserved_108_203](#) [252]
- unsigned int [Prxy_QueryType](#)
- unsigned char [reserved_208_21B](#) [20]
- unsigned int [Prxy_QueryMask](#)
- unsigned char [reserved_220_22B](#) [12]
- unsigned int [Prxy_TagStatus](#)

2.14.1 Detailed Description

Definition at line 34 of file cbea_map.h.

2.14.2 Field Documentation

2.14.2.1 unsigned char reserved_0_3[4]

Definition at line 35 of file cbea_map.h.

2.14.2.2 unsigned int MFC_LSA

Definition at line 36 of file cbea_map.h.

2.14.2.3 unsigned int MFC_EAH

Definition at line 37 of file cbea_map.h.

2.14.2.4 unsigned int MFC_EAL

Definition at line 38 of file cbea_map.h.

2.14.2.5 unsigned int MFC_Size_Tag

Definition at line 39 of file cbea_map.h.

2.14.2.6 unsigned int MFC_ClassID_CMD

Definition at line 41 of file cbea_map.h.

2.14.2.7 unsigned int MFC_CMDStatus

Definition at line 42 of file cbea_map.h.

2.14.2.8 union { ... }**2.14.2.9 unsigned char reserved_18_103[236]**

Definition at line 44 of file cbea_map.h.

2.14.2.10 unsigned int MFC_QStatus

Definition at line 45 of file cbea_map.h.

2.14.2.11 unsigned char reserved_108_203[252]

Definition at line 46 of file cbea_map.h.

2.14.2.12 unsigned int Prxy_QueryType

Definition at line 47 of file cbea_map.h.

2.14.2.13 unsigned char reserved_208_21B[20]

Definition at line 48 of file cbea_map.h.

2.14.2.14 unsigned int Prxy_QueryMask

Definition at line 49 of file cbea_map.h.

2.14.2.15 unsigned char reserved_220_22B[12]

Definition at line 50 of file cbea_map.h.

2.14.2.16 unsigned int Prxy_TagStatus

Definition at line 51 of file cbea_map.h.

The documentation for this struct was generated from the following file:

- [cbea_map.h](#)

2.15 spe_mssync_area Struct Reference

```
#include <cbea_map.h>
```

Data Fields

- unsigned int MFC_MSSync

2.15.1 Detailed Description

Definition at line 30 of file cbea_map.h.

2.15.2 Field Documentation

2.15.2.1 unsigned int MFC_MSSync

Definition at line 31 of file cbea_map.h.

Referenced by _base_spe_mssync_start(), and _base_spe_mssync_status().

The documentation for this struct was generated from the following file:

- [cbea_map.h](#)

2.16 spe_program_handle Struct Reference

```
#include <libspe2-types.h>
```

Data Fields

- `unsigned int handle_size`
- `void * elf_image`
- `void * toe_shadow`

2.16.1 Detailed Description

SPE program handle Structure `spe_program_handle` per CESOF specification libspe2 applications usually only keep a pointer to the program handle and do not use the structure directly.

Definition at line 43 of file libspe2-types.h.

2.16.2 Field Documentation

2.16.2.1 `unsigned int handle_size`

Definition at line 49 of file libspe2-types.h.

Referenced by `_base_spe_image_open()`.

2.16.2.2 `void* elf_image`

Definition at line 50 of file libspe2-types.h.

Referenced by `_base_spe_image_close()`, `_base_spe_image_open()`, `_base_spe_load_spe_elf()`, `_base_spe_parse_isolated_elf()`, `_base_spe_program_load_complete()`, `_base_spe_toe_ear()`, and `_base_spe_verify_spe_elf_image()`.

2.16.2.3 `void* toe_shadow`

Definition at line 51 of file libspe2-types.h.

Referenced by `_base_spe_image_close()`, `_base_spe_image_open()`, and `_base_spe_toe_ear()`.

The documentation for this struct was generated from the following file:

- `libspe2-types.h`

2.17 spe_reg128 Struct Reference

```
#include <handler_utils.h>
```

Data Fields

- unsigned int **slot** [4]

2.17.1 Detailed Description

Definition at line 23 of file handler_utils.h.

2.17.2 Field Documentation

2.17.2.1 unsigned int slot[4]

Definition at line 24 of file handler_utils.h.

The documentation for this struct was generated from the following file:

- [handler_utils.h](#)

2.18 spe_sig_notify_1_area Struct Reference

```
#include <cbea_map.h>
```

Data Fields

- unsigned char [reserved_0_B](#) [12]
- unsigned int [SPU_Sig_Notify_1](#)

2.18.1 Detailed Description

Definition at line 69 of file cbea_map.h.

2.18.2 Field Documentation

2.18.2.1 unsigned char reserved_0_B[12]

Definition at line 70 of file cbea_map.h.

2.18.2.2 unsigned int SPU_Sig_Notify_1

Definition at line 71 of file cbea_map.h.

Referenced by [_base_spe_signal_write\(\)](#).

The documentation for this struct was generated from the following file:

- [cbea_map.h](#)

2.19 spe_sig_notify_2_area Struct Reference

```
#include <cbea_map.h>
```

Data Fields

- unsigned char [reserved_0_B](#) [12]
- unsigned int [SPU_Sig_Notify_2](#)

2.19.1 Detailed Description

Definition at line 74 of file cbea_map.h.

2.19.2 Field Documentation

2.19.2.1 unsigned char reserved_0_B[12]

Definition at line 75 of file cbea_map.h.

2.19.2.2 unsigned int SPU_Sig_Notify_2

Definition at line 76 of file cbea_map.h.

Referenced by [_base_spe_signal_write\(\)](#).

The documentation for this struct was generated from the following file:

- [cbea_map.h](#)

2.20 spe_spu_control_area Struct Reference

```
#include <cbea_map.h>
```

Data Fields

- unsigned char [reserved_0_3](#) [4]
- unsigned int [SPU_Out_Mbox](#)
- unsigned char [reserved_8_B](#) [4]
- unsigned int [SPU_In_Mbox](#)
- unsigned char [reserved_10_13](#) [4]
- unsigned int [SPU_Mbox_Stat](#)
- unsigned char [reserved_18_1B](#) [4]
- unsigned int [SPU_RunCntl](#)
- unsigned char [reserved_20_23](#) [4]
- unsigned int [SPU_Status](#)
- unsigned char [reserved_28_33](#) [12]
- unsigned int [SPU_NPC](#)

2.20.1 Detailed Description

Definition at line 54 of file cbea_map.h.

2.20.2 Field Documentation

2.20.2.1 unsigned char reserved_0_3[4]

Definition at line 55 of file cbea_map.h.

2.20.2.2 unsigned int SPU_Out_Mbox

Definition at line 56 of file cbea_map.h.

2.20.2.3 unsigned char reserved_8_B[4]

Definition at line 57 of file cbea_map.h.

2.20.2.4 unsigned int SPU_In_Mbox

Definition at line 58 of file cbea_map.h.

2.20.2.5 unsigned char reserved_10_13[4]

Definition at line 59 of file cbea_map.h.

2.20.2.6 unsigned int SPU_Mbox_Stat

Definition at line 60 of file cbea_map.h.

Referenced by _base_spe_in_mbox_status(), _base_spe_out_intr_mbox_status(), and _base_spe_out_mbox_status().

2.20.2.7 unsigned char reserved_18_1B[4]

Definition at line 61 of file cbea_map.h.

2.20.2.8 unsigned int SPU_RunCntl

Definition at line 62 of file cbea_map.h.

2.20.2.9 unsigned char reserved_20_23[4]

Definition at line 63 of file cbea_map.h.

2.20.2.10 unsigned int SPU_Status

Definition at line 64 of file cbea_map.h.

2.20.2.11 unsigned char reserved_28_33[12]

Definition at line 65 of file cbea_map.h.

2.20.2.12 unsigned int SPU_NPC

Definition at line 66 of file cbea_map.h.

The documentation for this struct was generated from the following file:

- [cbea_map.h](#)

2.21 spe_stop_info Struct Reference

```
#include <libspe2-types.h>
```

Data Fields

- unsigned int stop_reason
- union {
 - int spe_exit_code
 - int spe_signal_code
 - int spe_runtime_error
 - int spe_runtime_exception
 - int spe_runtime_fatal
 - int spe_callback_error
 - int spe_isolation_error
 - void * __reserved_ptr
 - unsigned long long __reserved_u64}
- int spu_status

2.21.1 Detailed Description

spe_stop_info_t

Definition at line 118 of file libspe2-types.h.

2.21.2 Field Documentation

2.21.2.1 unsigned int stop_reason

Definition at line 119 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.2 int spe_exit_code

Definition at line 121 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.3 int spe_signal_code

Definition at line 122 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.4 int spe_runtime_error

Definition at line 123 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.5 int spe_runtime_exception

Definition at line 124 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.6 int spe_runtime_fatal

Definition at line 125 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.7 int spe_callback_error

Definition at line 126 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.8 int spe_isolation_error

Definition at line 127 of file libspe2-types.h.

Referenced by _base_spe_context_run().

2.21.2.9 void* __reserved_ptr

Definition at line 129 of file libspe2-types.h.

2.21.2.10 unsigned long long __reserved_u64

Definition at line 130 of file libspe2-types.h.

2.21.2.11 union { ... } result

Referenced by _base_spe_context_run().

2.21.2.12 int spu_status

Definition at line 132 of file libspe2-types.h.

Referenced by _base_spe_context_run().

The documentation for this struct was generated from the following file:

- [libspe2-types.h](#)


Chapter 3

File Documentation

3.1 accessors.c File Reference

```
#include "spebase.h"
#include "create.h"
#include <fcntl.h>
#include <errno.h>
#include <sys/mman.h>
```

Include dependency graph for accessors.c:



Functions

- void * `_base_spe_ps_area_get (spe_context_ptr_t spe, enum ps_area area)`
- void * `_base_spe_ls_area_get (spe_context_ptr_t spe)`
- `__attribute__ ((noinline))`
- int `_base_spe_event_source_acquire (spe_context_ptr_t spe, enum fd_name fdesc)`
- void `_base_spe_event_source_release (struct spe_context *spe, enum fd_name fdesc)`
- int `_base_spe_spe_dir_get (spe_context_ptr_t spe)`
- int `_base_spe_stop_event_source_get (spe_context_ptr_t spe)`
- int `_base_spe_stop_event_target_get (spe_context_ptr_t spe)`

- int `_base_spe_ls_size_get (spe_context_ptr_t spe)`

3.1.1 Function Documentation

3.1.1.1 `__attribute__ ((noinline))`

Definition at line 69 of file accessors.c.

```
70 {
71     return;
72 }
```

3.1.1.2 int `__base_spe_event_source_acquire (spe_context_ptr_t spe, enum fd_name fdesc)`


Definition at line 74 of file accessors.c.

References `_base_spe_open_if_closed()`.

Referenced by `_event_spe_event_handler_deregister()`, and `_event_spe_event_handler_register()`.

```
75 {
76     return _base_spe_open_if_closed(spe, fdesc, 0);
77 }
```

Here is the call graph for this function:



3.1.1.3 void `__base_spe_event_source_release (struct spe_context *spectx, enum fd_name fdesc)`

`__base_spe_event_source_release` releases the file descriptor to the specified event source

Parameters:

`spectx` Specifies the SPE context


`fdesc` Specifies the event source

Definition at line 79 of file accessors.c.

References `_base_spe_close_if_open()`.

```
80 {
81     _base_spe_close_if_open(spe, fdesc);
82 }
```

Here is the call graph for this function:



3.1.1.4 int __base_spe_spe_dir_get (spe_context_ptr_t spe)

Definition at line 84 of file accessors.c.

References spe_context::base_private, and spe_context_base_priv::fd_spe_dir.

```
85 {
86     return spe->base_private->fd_spe_dir;
87 }
```

3.1.1.5 int __base_spe_stop_event_source_get (spe_context_ptr_t spe)

speevent users read from this end

Definition at line 92 of file accessors.c.

References spe_context::base_private, and spe_context_base_priv::ev_pipe.

```
93 {
94     return spe->base_private->ev_pipe[1];
95 }
```

3.1.1.6 int __base_spe_stop_event_target_get (spe_context_ptr_t spe)

speevent writes to this end

Definition at line 100 of file accessors.c.

References spe_context::base_private, and spe_context_base_priv::ev_pipe.

```
101 {
102     return spe->base_private->ev_pipe[0];
103 }
```

3.1.1.7 void* __base_spe_ls_area_get (spe_context_ptr_t spe)

Definition at line 64 of file accessors.c.

References spe_context::base_private, and spe_context_base_priv::mem_mmap_base.

```
65 {
66     return spe->base_private->mem_mmap_base;
67 }
```

3.1.1.8 int __base_spe_ls_size_get (spe_context_ptr_t spe)

`_base_spe_ls_size_get` returns the size of the local store area

Parameters:

spectx Specifies the SPE context

Definition at line 105 of file accessors.c.

References LS_SIZE.

```
106 {
107     return LS_SIZE;
108 }
```

3.1.1.9 void* _base_spe_ps_area_get (spe_context_ptr_t spe, enum ps_area area)


Definition at line 30 of file accessors.c.

References spe_context::base_private, spe_context_base_priv::cntl_mmap_base, spe_context_base_priv::mfc_mmap_base, spe_context_base_priv::mssync_mmap_base, spe_context_base_priv::signal1_mmap_base, spe_context_base_priv::signal2_mmap_base, SPE_CONTROL_AREA, SPE_MFC_COMMAND_AREA, SPE_MSSYNC_AREA, SPE_SIG_NOTIFY_1_AREA, and SPE_SIG_NOTIFY_2_AREA.

```
31 {
32     void *ptr;
33
34     switch (area) {
35         case SPE_MSSYNC_AREA:
36             ptr = spe->base_private->mssync_mmap_base;
37             break;
38         case SPE_MFC_COMMAND_AREA:
39             ptr = spe->base_private->mfc_mmap_base;
40             break;
41         case SPE_CONTROL_AREA:
42             ptr = spe->base_private->cntl_mmap_base;
43             break;
44         case SPE_SIG_NOTIFY_1_AREA:
45             ptr = spe->base_private->signal1_mmap_base;
46             break;
47         case SPE_SIG_NOTIFY_2_AREA:
48             ptr = spe->base_private->signal2_mmap_base;
49             break;
50         default:
51             errno = EINVAL;
52             return NULL;
53             break;
54     }
55
56     if (ptr == MAP_FAILED) {
57         errno = EACCES;
58         return NULL;
59     }
60
61     return ptr;
62 }
```

3.2 cbea_map.h File Reference

This graph shows which files directly or indirectly include this file:



Data Structures

- struct `spe_mssync_area`
- struct `spe_mfc_command_area`
- struct `spe_spu_control_area`
- struct `spe_sig_notify_1_area`
- struct `spe_sig_notify_2_area`

Typedefs

- typedef struct `spe_mssync_area` `spe_mssync_area_t`
- typedef struct `spe_mfc_command_area` `spe_mfc_command_area_t`
- typedef struct `spe_spu_control_area` `spe_spu_control_area_t`
- typedef struct `spe_sig_notify_1_area` `spe_sig_notify_1_area_t`
- typedef struct `spe_sig_notify_2_area` `spe_sig_notify_2_area_t`

3.2.1 Typedef Documentation

3.2.1.1 `typedef struct spe_mfc_command_area spe_mfc_command_area_t`

3.2.1.2 `typedef struct spe_mssync_area spe_mssync_area_t`

3.2.1.3 `typedef struct spe_sig_notify_1_area spe_sig_notify_1_area_t`


3.2.1.4 `typedef struct spe_sig_notify_2_area spe_sig_notify_2_area_t`

3.2.1.5 `typedef struct spe_spu_control_area spe_spu_control_area_t`

3.3 create.c File Reference

```
#include <errno.h>
#include <fcntl.h>
#include <pthread.h>
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include <sys/mman.h>
#include <sys/types.h>
#include <sys/spu.h>
#include <sys/stat.h>
#include <unistd.h>
#include "create.h"
#include "spebase.h"
```

Include dependency graph for create.c:



Data Structures

- struct [fd_attr](#)

Functions

- void [_base_spe_context_lock](#) (spe_context_ptr_t spe, enum [fd_name](#) fdesc)
- void [_base_spe_context_unlock](#) (spe_context_ptr_t spe, enum [fd_name](#) fdesc)
- int [_base_spe_open_if_closed](#) (struct [spe_context](#) *spe, enum [fd_name](#) fdesc, int locked)
- void [_base_spe_close_if_open](#) (struct [spe_context](#) *spe, enum [fd_name](#) fdesc)
- [spe_context_ptr_t _base_spe_context_create](#) (unsigned int flags, [spe_gang_context_ptr_t](#) gctx, [spe_context_ptr_t](#) aff_spe)
- [spe_gang_context_ptr_t _base_spe_gang_context_create](#) (unsigned int flags)
- int [_base_spe_context_destroy](#) ([spe_context_ptr_t](#) spe)
- int [_base_spe_gang_context_destroy](#) ([spe_gang_context_ptr_t](#) gctx)

3.3.1 Function Documentation

3.3.1.1 void _base_spe_close_if_open (struct spe_context *spe, enum fd_name fdesc)

Definition at line 125 of file create.c.


References `_base_spe_context_lock()`, `_base_spe_context_unlock()`, `spe_context::base_private`, `spe_context_base_priv::spe_fds_array`, and `spe_context_base_priv::spe_fds_refcount`.

Referenced by `__base_spe_event_source_release()`, and `_base_spe_signal_write()`.

```

126 {
127     _base_spe_context_lock(spe, fdesc);
128
129     if (spe->base_private->spe_fds_array[(int)fdesc] != -1 &&
130         spe->base_private->spe_fds_refcount[(int)fdesc] == 1) {
131
132         spe->base_private->spe_fds_refcount[(int)fdesc]--;
133         close(spe->base_private->spe_fds_array[(int)fdesc]);
134
135         spe->base_private->spe_fds_array[(int)fdesc] = -1;
136     } else if (spe->base_private->spe_fds_refcount[(int)fdesc] > 0) {
137         spe->base_private->spe_fds_refcount[(int)fdesc]--;
138     }
139
140     _base_spe_context_unlock(spe, fdesc);
141 }
```

Here is the call graph for this function:



3.3.1.2 spe_context_ptr_t _base_spe_context_create (unsigned int flags, spe_gang_context_ptr_t gctx, spe_context_ptr_t aff_spe)

`_base_spe_context_create` creates a single SPE context, i.e., the corresponding directory is created in SPUFS either as a subdirectory of a gang or individually (maybe this is best considered a gang of one)

Parameters:

`flags`

`gctx` specify NULL if not belonging to a gang

`aff_spe` specify NULL to skip affinity information

Definition at line 183 of file create.c.

References `_base_spe_emulated_loader_present()`, `spe_gang_context::base_private`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `CNTL_OFFSET`, `CNTL_SIZE`, `DEBUG_PRINTF`, `spe_context_base_priv::fd_lock`, `spe_context_base_priv::fd_spe_dir`, `spe_context_base_priv::flags`, `spe_gang_context_base_priv::gangname`, `spe_context_base_priv::loaded_program`, `LS_SIZE`, `spe_context_base_priv::mem_mmap_base`, `spe_context_base_priv::mfc_mmap_base`, `MFC_OFFSET`, `MFC_SIZE`, `MSS_SIZE`, `spe_context_base_priv::mssync_mmap_base`, `MSSYNC_OFFSET`, `spe_context_base_priv::psmap_mmap_base`, `PSMAP_SIZE`, `spe_context_base_priv::signal1_mmap_base`,

SIGNAL1_OFFSET, spe_context_base_priv::signal2_mmap_base, SIGNAL2_OFFSET, SIGNAL_SIZE, SPE_AFFINITY_MEMORY, SPE_CFG_SIGNIFY1_OR, SPE_CFG_SIGNIFY2_OR, SPE_EVENTS_ENABLE, spe_context_base_priv::spe_fds_array, SPE_ISOLATE, SPE_ISOLATE_EMULATE, and SPE_MAP_PS.

```

185 {
186     char pathname[256];
187     int i, aff_spe_fd = 0;
188     unsigned int spu_createflags = 0;
189     struct spe_context *spe = NULL;
190     struct spe_context_base_priv *priv;
191
192     /* We need a loader present to run in emulated isolated mode */
193     if (flags & SPE_ISOLATE_EMULATE
194         && !_base_spe_emulated_loader_present()) {
195         errno = EINVAL;
196         return NULL;
197     }
198
199     /* Put some sane defaults into the SPE context */
200     spe = malloc(sizeof(*spe));
201     if (!spe) {
202         DEBUG_PRINTF("ERROR: Could not allocate spe context.\n");
203         return NULL;
204     }
205     memset(spe, 0, sizeof(*spe));
206
207     spe->base_private = malloc(sizeof(*spe->base_private));
208     if (!spe->base_private) {
209         DEBUG_PRINTF("ERROR: Could not allocate "
210                     "spe->base_private context.\n");
211         free(spe);
212         return NULL;
213     }
214
215     /* just a convenience variable */
216     priv = spe->base_private;
217
218     priv->fd_spe_dir = -1;
219     priv->mem_mmap_base = MAP_FAILED;
220     priv->psmap_mmap_base = MAP_FAILED;
221     priv->mssync_mmap_base = MAP_FAILED;
222     priv->mfc_mmap_base = MAP_FAILED;
223     priv->cntl_mmap_base = MAP_FAILED;
224     priv->signal1_mmap_base = MAP_FAILED;
225     priv->signal2_mmap_base = MAP_FAILED;
226     priv->loaded_program = NULL;
227
228     for (i = 0; i < NUM_MBOX_FDS; i++) {
229         priv->spe_fds_array[i] = -1;
230         pthread_mutex_init(&priv->fd_lock[i], NULL);
231     }
232
233     /* initialise spu_createflags */
234     if (flags & SPE_ISOLATE) {
235         flags |= SPE_MAP_PS;
236         spu_createflags |= SPU_CREATE_ISOLATE | SPU_CREATE_NOSCHED;
237     }
238
239     if (flags & SPE_EVENTS_ENABLE)
240         spu_createflags |= SPU_CREATE_EVENTS_ENABLED;
241
242     if (aff_spe)
243         spu_createflags |= SPU_CREATE_AFFINITY_SPU;
244
245     if (flags & SPE_AFFINITY_MEMORY)
246         spu_createflags |= SPU_CREATE_AFFINITY_MEM;

```

```

247
248     /* Make the SPUFS directory for the SPE */
249     if (gctx == NULL)
250         sprintf(pathname, "/spu/sputhread-%i-%lu",
251                 getpid(), (unsigned long)spe);
252     else
253         sprintf(pathname, "/spu/%s/sputhread-%i-%lu",
254                 gctx->base_private->gangname, getpid(),
255                 (unsigned long)spe);
256
257     if (aff_spe)
258         aff_spe_fd = aff_spe->base_private->fd_spe_dir;
259
260     priv->fd_spe_dir = spu_create(pathname, spu_createflags,
261                                   S_IRUSR | S_IWUSR | S_IXUSR, aff_spe_fd);
262
263     if (priv->fd_spe_dir < 0) {
264         DEBUG_PRINTF("ERROR: Could not create SPE %s\n", pathname);
265         perror("spu_create()");
266         free_spe_context(spe);
267         /* we mask most errors, but leave ENODEV */
268         if (errno != ENODEV)
269             errno = EFAULT;
270         return NULL;
271     }
272
273     priv->flags = flags;
274
275     /* Map the required areas into process memory */
276     priv->mem_mmap_base = mapfileat(priv->fd_spe_dir, "mem", LS_SIZE);
277     if (priv->mem_mmap_base == MAP_FAILED) {
278         DEBUG_PRINTF("ERROR: Could not map SPE memory.\n");
279         free_spe_context(spe);
280         errno = ENOMEM;
281         return NULL;
282     }
283
284     if (flags & SPE_MAP_PS) {
285         /* It's possible to map the entire problem state area with
286          * one mmap - try this first */
287         priv->psmap_mmap_base = mapfileat(priv->fd_spe_dir,
288                                           "psmap", PSMAP_SIZE);
289
290         if (priv->psmap_mmap_base != MAP_FAILED) {
291             priv->mssync_mmap_base =
292                 priv->psmap_mmap_base + MSSYNC_OFFSET;
293             priv->mfc_mmap_base =
294                 priv->psmap_mmap_base + MFC_OFFSET;
295             priv->cntl_mmap_base =
296                 priv->psmap_mmap_base + CNTL_OFFSET;
297             priv->signall_mmap_base =
298                 priv->psmap_mmap_base + SIGNAL1_OFFSET;
299             priv->signal2_mmap_base =
300                 priv->psmap_mmap_base + SIGNAL2_OFFSET;
301
302         } else {
303             /* map each region separately */
304             priv->mfc_mmap_base =
305                 mapfileat(priv->fd_spe_dir, "mfc", MFC_SIZE);
306             priv->mssync_mmap_base =
307                 mapfileat(priv->fd_spe_dir, "mss", MSS_SIZE);
308             priv->cntl_mmap_base =
309                 mapfileat(priv->fd_spe_dir, "cntl", CNTL_SIZE);
310             priv->signall_mmap_base =
311                 mapfileat(priv->fd_spe_dir, "signall",
312                           SIGNAL_SIZE);
313             priv->signal2_mmap_base =


```

```

314             mapfileat(priv->fd_spe_dir, "signal2",
315                         SIGNAL_SIZE);
316
317             if (priv->mfc_mmap_base == MAP_FAILED ||
318                 priv->cntl_mmap_base == MAP_FAILED ||
319                 priv->signal1_mmap_base == MAP_FAILED ||
320                 priv->signal2_mmap_base == MAP_FAILED) {
321                 DEBUG_PRINTF("ERROR: Could not map SPE "
322                             "PS memory.\n");
323                 free_spe_context(spe);
324                 errno = ENOMEM;
325                 return NULL;
326             }
327         }
328     }
329
330     if (flags & SPE_CFG_SIGNIFY1_OR) {
331         if (setsignify(priv->fd_spe_dir, "signal1_type")) {
332             DEBUG_PRINTF("ERROR: Could not open SPE "
333                             "signal1_type file.\n");
334             free_spe_context(spe);
335             errno = EFAULT;
336             return NULL;
337         }
338     }
339
340     if (flags & SPE_CFG_SIGNIFY2_OR) {
341         if (setsignify(priv->fd_spe_dir, "signal2_type")) {
342             DEBUG_PRINTF("ERROR: Could not open SPE "
343                             "signal2_type file.\n");
344             free_spe_context(spe);
345             errno = EFAULT;
346             return NULL;
347         }
348     }
349
350     return spe;
351 }

```

Here is the call graph for this function:



3.3.1.3 int _base_spe_context_destroy (spe_context_ptr_t *specxt*)

`_base_spe_context_destroy` cleans up what is left when an SPE executable has exited. Closes open file handles and unmaps memory areas.

Parameters:

specxt Specifies the SPE context

Definition at line 406 of file create.c.

References `__spe_context_update_event()`.

```

407 {
408     int ret = free_spe_context(spe);
409
410     __spe_context_update_event();

```

```

411         return ret;
412     }
413 }
```

Here is the call graph for this function:



3.3.1.4 void _base_spe_context_lock (spe_context_ptr_t spe, enum fd_name fd)

_base_spe_context_lock locks members of the SPE context

Parameters:

specx Specifies the SPE context

fd Specifies the file

Definition at line 91 of file create.c.

References spe_context::base_private, and spe_context_base_priv::fd_lock.

Referenced by _base_spe_close_if_open(), and _base_spe_open_if_closed().

```

92 {
93     pthread_mutex_lock(&spe->base_private->fd_lock[fdesc]);
94 }
```

3.3.1.5 void _base_spe_context_unlock (spe_context_ptr_t spe, enum fd_name fd)

_base_spe_context_unlock unlocks members of the SPE context

Parameters:

specx Specifies the SPE context

fd Specifies the file

Definition at line 96 of file create.c.

References spe_context::base_private, and spe_context_base_priv::fd_lock.

Referenced by _base_spe_close_if_open(), and _base_spe_open_if_closed().

```

97 {
98     pthread_mutex_unlock(&spe->base_private->fd_lock[fdesc]);
99 }
```

3.3.1.6 spe_gang_context_ptr_t _base_spe_gang_context_create (unsigned int flags)

creates the directory in SPUFS that will contain all SPEs that are considered a gang Note: I would like to generalize this to a "group" or "set" Additional attributes maintained at the group level should be used to define scheduling constraints such "temporal" (e.g., scheduled all at the same time, i.e., a gang) "topology" (e.g., "closeness" of SPEs for optimal communication)

Definition at line 364 of file create.c.

References `spe_gang_context::base_private`, `DEBUG_PRINTF`, and `spe_gang_context_base_priv::gangname`.

```

365 {
366     char pathname[256];
367     struct spe_gang_context_base_priv *pgctx = NULL;
368     struct spe_gang_context *gctx = NULL;
369
370     gctx = malloc(sizeof(*gctx));
371     if (!gctx) {
372         DEBUG_PRINTF("ERROR: Could not allocate spe context.\n");
373         return NULL;
374     }
375     memset(gctx, 0, sizeof(*gctx));
376
377     pgctx = malloc(sizeof(*pgctx));
378     if (!pgctx) {
379         DEBUG_PRINTF("ERROR: Could not allocate spe context.\n");
380         free(gctx);
381         return NULL;
382     }
383     memset(pgctx, 0, sizeof(*pgctx));
384
385     gctx->base_private = pgctx;
386
387     sprintf(gctx->base_private->gangname, "gang-%i-%lu", getpid(),
388             (unsigned long)gctx);
389     sprintf(pathname, "/spu/%s", gctx->base_private->gangname);
390
391     gctx->base_private->fd_gang_dir = spu_create(pathname, SPU_CREATE GANG,
392                                                 S_IRUSR | S_IWUSR | S_IXUSR);
393
394     if (gctx->base_private->fd_gang_dir < 0) {
395         DEBUG_PRINTF("ERROR: Could not create Gang %s\n", pathname);
396         free_spe_gang_context(gctx);
397         errno = EFAULT;
398         return NULL;
399     }
400
401     gctx->base_private->flags = flags;
402
403     return gctx;
404 }
```

3.3.1.7 int _base_spe_gang_context_destroy (spe_gang_context_ptr_t gctx)

`_base_spe_gang_context_destroy` destroys a gang context and frees associated resources

Parameters:

`gctx` Specifies the SPE gang context

Definition at line 415 of file create.c.

```

416 {
417     return free_spe_gang_context(gctx);
418 }
```

3.3.1.8 int _base_spe_open_if_closed (struct spe_context *spe, enum fd_name fdesc, int locked)

Definition at line 101 of file create.c.


References `_base_spe_context_lock()`, `_base_spe_context_unlock()`, `spe_context::base_private`, `spe_context_base_priv::fd_spe_dir`, `fd_attr::mode`, `fd_attr::name`, `spe_context_base_priv::spe_fds_array`, and `spe_context_base_priv::spe_fds_refcount`.

Referenced by `__base_spe_event_source_acquire()`, `_base_spe_in_mbox_status()`, `_base_spe_in_mbox_write()`, `_base_spe_mssync_start()`, `_base_spe_mssync_status()`, `_base_spe_out_intr_mbox_read()`, `_base_spe_out_intr_mbox_status()`, `_base_spe_out_mbox_read()`, `_base_spe_out_mbox_status()`, and `_base_spe_signal_write()`.

```

102 {
103     if (!locked)
104         _base_spe_context_lock(spe, fdesc);
105
106     /* already open? */
107     if (spe->base_private->spe_fds_array[fdesc] != -1) {
108         spe->base_private->spe_fds_refcount[fdesc]++;
109     } else {
110         spe->base_private->spe_fds_array[fdesc] =
111             openat(spe->base_private->fd_spe_dir,
112                     spe_fd_attr[fdesc].name,
113                     spe_fd_attr[fdesc].mode);
114
115         if (spe->base_private->spe_fds_array[(int)fdesc] > 0)
116             spe->base_private->spe_fds_refcount[(int)fdesc]++;
117     }
118
119     if (!locked)
120         _base_spe_context_unlock(spe, fdesc);
121
122     return spe->base_private->spe_fds_array[(int)fdesc];
123 }
```


Here is the call graph for this function:




3.4 create.h File Reference

```
#include "spebase.h"
```

Include dependency graph for create.h:



This graph shows which files directly or indirectly include this file:



Functions

- `int _base_spe_open_if_closed (struct spe_context *spe, enum fd_name fdesc, int locked)`
- `void _base_spe_close_if_open (struct spe_context *spe, enum fd_name fdesc)`

3.4.1 Function Documentation

3.4.1.1 void _base_spe_close_if_open (struct spe_context * *spe*, enum fd_name *fdesc*)

Definition at line 125 of file `create.c`.

References `_base_spe_context_lock()`, `_base_spe_context_unlock()`, `spe_context::base_private`, `spe_context_base_priv::spe_fds_array`, and `spe_context_base_priv::spe_fds_refcount`.

Referenced by `_base_spe_event_source_release()`, and `_base_spe_signal_write()`.

```


126 {
127     _base_spe_context_lock(spe, fdesc);
128
129     if (spe->base_private->spe_fds_array[(int)fdesc] != -1 &&
130         spe->base_private->spe_fds_refcount[(int)fdesc] == 1) {
131
132         spe->base_private->spe_fds_refcount[(int)fdesc]--;
133         close(spe->base_private->spe_fds_array[(int)fdesc]);
134
135         spe->base_private->spe_fds_array[(int)fdesc] = -1;
136     } else if (spe->base_private->spe_fds_refcount[(int)fdesc] > 0) {
137         spe->base_private->spe_fds_refcount[(int)fdesc]--;
138     }
  
```

```

139
140     _base_spe_context_unlock(spe, fdesc);
141 }

```

Here is the call graph for this function:



3.4.1.2 int _base_spe_open_if_closed (struct spe_context *spe, enum fd_name fdesc, int locked)

Definition at line 101 of file create.c.

References `_base_spe_context_lock()`, `_base_spe_context_unlock()`, `spe_context::base_private`, `spe_context_base_priv::fd_spe_dir`, `fd_attr::mode`, `fd_attr::name`, `spe_context_base_priv::spe_fds_array`, and `spe_context_base_priv::spe_fds_refcount`.


Referenced by `_base_spe_event_source_acquire()`, `_base_spe_in_mbox_status()`, `_base_spe_in_mbox_write()`, `_base_spe_mssync_start()`, `_base_spe_mssync_status()`, `_base_spe_out_intr_mbox_read()`, `_base_spe_out_intr_mbox_status()`, `_base_spe_out_mbox_read()`, `_base_spe_out_mbox_status()`, and `_base_spe_signal_write()`.

```

102 {
103     if (!locked)
104         _base_spe_context_lock(spe, fdesc);
105
106     /* already open? */
107     if (spe->base_private->spe_fds_array[fdesc] != -1) {
108         spe->base_private->spe_fds_refcount[fdesc]++;
109     } else {
110         spe->base_private->spe_fds_array[fdesc] =
111             openat(spe->base_private->fd_spe_dir,
112                     spe_fd_attr[fdesc].name,
113                     spe_fd_attr[fdesc].mode);
114
115         if (spe->base_private->spe_fds_array[(int)fdesc] > 0)
116             spe->base_private->spe_fds_refcount[(int)fdesc]++;
117     }
118
119     if (!locked)
120         _base_spe_context_unlock(spe, fdesc);
121
122     return spe->base_private->spe_fds_array[(int)fdesc];
123 }

```

Here is the call graph for this function:




3.5 design.txt File Reference

3.6 dma.c File Reference

```
#include <errno.h>
#include <fcntl.h>
#include <stdio.h>
#include <stdint.h>
#include <string.h>
#include <unistd.h>
#include <sys/poll.h>
#include "create.h"
#include "dma.h"
```

Include dependency graph for dma.c:



Functions

- int `_base_spe_mfcio_put` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- int `_base_spe_mfcio_putb` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- int `_base_spe_mfcio_putf` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- int `_base_spe_mfcio_get` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- int `_base_spe_mfcio_getb` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- int `_base_spe_mfcio_getf` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- int `_base_spe_mfcio_tag_status_read` (`spe_context_ptr_t` spectx, unsigned int mask, unsigned int behavior, unsigned int *tag_status)
- int `_base_spe_mssync_start` (`spe_context_ptr_t` spectx)
- int `_base_spe_mssync_status` (`spe_context_ptr_t` spectx)

3.6.1 Function Documentation

3.6.1.1 int _base_spe_mfcio_get (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The `_base_spe_mfcio_get` function places a get DMA command on the proxy command queue of the SPE thread specified by *speid*. The get command transfers *size* bytes of data starting at the effective address specified by *ea* to the local store address specified by *ls*. The DMA is identified by the tag id specified by *tag* and performed according to the transfer class and replacement class specified by *tid* and *rid* respectively.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 160 of file dma.c.

References MFC_CMD_GET.

```
167 {  
168     return spe_do_mfc_get(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_GET);  
169 }
```

3.6.1.2 int _base_spe_mfcio_getb (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The `_base_spe_mfcio_getb` function is identical to `_base_spe_mfcio_get` except that it places a getb (get with barrier) DMA command on the proxy command queue. The barrier form ensures that this command and all sequence commands with the same tag identifier as this command are locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 171 of file dma.c.

References MFC_CMD_GETB.

```
178 {
179     return spe_do_mfc_get(spectx, ls, ea, size, tag, rid, rid, MFC_CMD_GETB);
180 }
```

3.6.1.3 int _base_spe_mfcio_getf (spe_context_ptr_t spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)

The _base_spe_mfcio_getf function is identical to _base_spe_mfcio_get except that it places a getf (get with fence) DMA command on the proxy command queue. The fence form ensure that this command is locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

- spectx* Specifies the SPE context
- ls* Specifies the starting local store destination address.
- ea* Specifies the starting effective address source address.
- size* Specifies the size, in bytes, to be transferred.
- tag* Specifies the tag id used to identify the DMA command.
- tid* Specifies the transfer class identifier of the DMA command.
- rid* Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 182 of file dma.c.

References MFC_CMD_GETF.

```
189 {
190     return spe_do_mfc_get(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_GETF);
191 }
```

3.6.1.4 int _base_spe_mfcio_put (spe_context_ptr_t spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)

The _base_spe_mfcio_put function places a put DMA command on the proxy command queue of the SPE thread specified by speid. The put command transfers size bytes of data starting at the local store address specified by ls to the effective address specified by ea. The DMA is identified by the tag id specified by tag and performed according transfer class and replacement class specified by tid and rid respectively.

Parameters:

- spectx* Specifies the SPE context
- ls* Specifies the starting local store destination address.
- ea* Specifies the starting effective address source address.
- size* Specifies the size, in bytes, to be transferred.

tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 126 of file dma.c.

References MFC_CMD_PUT.

```
133 {
134     return spe_do_mfc_put(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_PUT);
135 }
```

3.6.1.5 int _base_spe_mfcio_putb (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_putb function is identical to _base_spe_mfcio_put except that it places a putb (put with barrier) DMA command on the proxy command queue. The barrier form ensures that this command and all sequence commands with the same tag identifier as this command are locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 137 of file dma.c.

References MFC_CMD_PUTB.

```
144 {
145     return spe_do_mfc_put(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_PUTB);
146 }
```

3.6.1.6 int _base_spe_mfcio_putf (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_putf function is identical to _base_spe_mfcio_put except that it places a putf (put with fence) DMA command on the proxy command queue. The fence form ensures that this command is locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 148 of file dma.c.

References MFC_CMD_PUTF.

```
155 {
156     return spe_do_mfc_put(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_PUTF);
157 }
```

3.6.1.7 int _base_spe_mfcio_tag_status_read (spe_context_ptr_t *spectx*, unsigned int *mask*, unsigned int *behavior*, unsigned int * *tag_status*)

_base_spe_mfcio_tag_status_read

No Idea

Definition at line 307 of file dma.c.

References spe_context_base_priv::active_tagmask, spe_context::base_private, spe_context_base_priv::flags, SPE_MAP_PS, SPE_TAG_ALL, SPE_TAG_ANY, and SPE_TAG_IMMEDIATE.

```
308 {
309     if ( mask != 0 ) {
310         if (!(spectx->base_private->flags & SPE_MAP_PS))
311             mask = 0;
312     } else {
313         if ((spectx->base_private->flags & SPE_MAP_PS))
314             mask = spectx->base_private->active_tagmask;
315     }
316
317     if (!tag_status) {
318         errno = EINVAL;
319         return -1;
320     }
321
322     switch (behavior) {
323     case SPE_TAG_ALL:
324         return spe_mfcio_tag_status_read_all(spectx, mask, tag_status);
325     case SPE_TAG_ANY:
326         return spe_mfcio_tag_status_read_any(spectx, mask, tag_status);
327     case SPE_TAG_IMMEDIATE:
328         return spe_mfcio_tag_status_read_immediate(spectx, mask, tag_status);
329     default:
330         errno = EINVAL;
331         return -1;
332     }
333 }
```

3.6.1.8 int _base_spe_mssync_start (spe_context_ptr_t *spectx*)

_base_spe_mssync_start starts Multisource Synchronisation

Parameters:

spectx Specifies the SPE context


Definition at line 335 of file dma.c.

References _base_spe_open_if_closed(), spe_context::base_private, FD_MSS, spe_context_base_priv::flags, spe_mssync_area::MFC_MSSync, spe_context_base_priv::mssync_mmap_base, and SPE_MAP_PS.

```

336 {
337     int ret, fd;
338     unsigned int data = 1; /* Any value can be written here */
339
340     volatile struct spe_mssync_area *mss_area =
341         spectx->base_private->mssync_mmap_base;
342
343     if (spectx->base_private->flags & SPE_MAP_PS) {
344         mss_area->MFC_MSSync = data;
345         return 0;
346     } else {
347         fd = _base_spe_open_if_closed(spectx, FD_MSS, 0);
348         if (fd != -1) {
349             ret = write(fd, &data, sizeof (data));
350             if ((ret < 0) && (errno != EIO)) {
351                 perror("spe_mssync_start: internal error");
352             }
353             return ret < 0 ? -1 : 0;
354         } else
355             return -1;
356     }
357 }
```

Here is the call graph for this function:



3.6.1.9 int _base_spe_mssync_status (spe_context_ptr_t *spectx*)

_base_spe_mssync_status retrieves status of Multisource Synchronisation

Parameters:


spectx Specifies the SPE context

Definition at line 359 of file dma.c.

References _base_spe_open_if_closed(), spe_context::base_private, FD_MSS, spe_context_base_priv::flags, spe_mssync_area::MFC_MSSync, spe_context_base_priv::mssync_mmap_base, and SPE_MAP_PS.

```
360 {
361     int ret, fd;
362     unsigned int data;
363
364     volatile struct spe_mssync_area *mss_area =
365         spectx->base_private->mssync_mmap_base;
366
367     if (spectx->base_private->flags & SPE_MAP_PS) {
368         return mss_area->MFC_MSSync;
369     } else {
370         fd = _base_spe_open_if_closed(spectx, FD_MSS, 0);
371         if (fd != -1) {
372             ret = read(fd, &data, sizeof (data));
373             if ((ret < 0) && (errno != EIO)) {
374                 perror("spe_mssync_start: internal error");
375             }
376             return ret < 0 ? -1 : data;
377         } else
378             return -1;
379     }
380 }
```


Here is the call graph for this function:




3.7 dma.h File Reference

```
#include <stdint.h>
#include "spebase.h"
```

Include dependency graph for dma.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [mfc_command_parameter_area](#)

Enumerations

- enum [mfc_cmd](#) {

 [MFC_CMD_PUT](#) = 0x20, [MFC_CMD_PUTB](#) = 0x21, [MFC_CMD_PUTF](#) = 0x22, [MFC_CMD_GET](#) = 0x40,

 [MFC_CMD_GETB](#) = 0x41, [MFC_CMD_GETF](#) = 0x42 }

3.7.1 Enumeration Type Documentation

3.7.1.1 enum mfc_cmd

Enumerator:

[MFC_CMD_PUT](#)
[MFC_CMD_PUTB](#)
[MFC_CMD_PUTF](#)
[MFC_CMD_GET](#)
[MFC_CMD_GETB](#)
[MFC_CMD_GETF](#)

MFC_CMD_GETB

MFC_CMD_GETF


Definition at line 37 of file dma.h.

```
37      {
38      MFC_CMD_PUT   = 0x20,
39      MFC_CMD_PUTB  = 0x21,
40      MFC_CMD_PUTF  = 0x22,
41      MFC_CMD_GET   = 0x40,
42      MFC_CMD_GETB  = 0x41,
43      MFC_CMD_GETF  = 0x42,
44 };
```

3.8 elf_loader.c File Reference

```
#include <elf.h>
#include <errno.h>
#include <fcntl.h>
#include <malloc.h>
#include <stdlib.h>
#include <stdio.h>
#include <string.h>
#include <unistd.h>
#include <sys/mman.h>
#include <sys/types.h>
#include <sys/stat.h>
#include "elf_loader.h"
#include "spebase.h"
```

Include dependency graph for elf_loader.c:



Defines

- #define **_PRINTF**(fmt, args...) { fprintf(stderr,fmt , ## args); }
- #define **DEBUG_PRINTF**(fmt, args...)
- #define **TAG**

Functions

- int _base_spe_verify_spe_elf_image (spe_program_handle_t *handle)
- int _base_spe_parse_isolated_elf (spe_program_handle_t *handle, uint64_t *addr, uint32_t *size)
- int _base_spe_load_spe_elf (spe_program_handle_t *handle, void *ld_buffer, struct **spe_ld_info** *ld_info)
- int _base_spe_toe_ear (spe_program_handle_t *speh)

3.8.1 Define Documentation

3.8.1.1 #define __PRINTF(fmt, args...) { fprintf(stderr,fmt ,## args); }

Definition at line 40 of file elf_loader.c.

3.8.1.2 #define DEBUG_PRINTF(fmt, args...)

Definition at line 45 of file elf_loader.c.

Referenced by _base_spe_context_create(), _base_spe_context_run(), _base_spe_count_physical_cpus(), _base_spe_count_physical_spes(), _base_spe_gang_context_create(), _base_spe_handle_library_callback(), _base_spe_load_spe_elf(), _base_spe_out_mbox_read(), _base_spe_parse_isolated_elf(), _base_spe_program_load(), and _base_spe_program_load_complete().

3.8.1.3 #define TAG

Definition at line 46 of file elf_loader.c.

3.8.2 Function Documentation

3.8.2.1 int _base_spe_load_spe_elf (spe_program_handle_t * handle, void * ld_buffer, struct spe_ld_info * ld_info)

Definition at line 201 of file elf_loader.c.

References DEBUG_PRINTF, spe_program_handle::elf_image, and spe_ld_info::entry.

Referenced by _base_spe_program_load().

```
202 {
203     Elf32_Ehdr *ehdr;
204     Elf32_Phdr *phdr;
205     Elf32_Phdr *ph, *prev_ph;
206
207     Elf32_Shdr *shdr;
208     Elf32_Shdr *sh;
209
210     Elf32_Off toe_addr = 0;
211     long toe_size = 0;
212
213     char* str_table = 0;
214
215     int num_load_seg = 0;
216     void *elf_start;
217     int ret;
218
219     DEBUG_PRINTF ("load_spe_elf(%p, %p)\n", handle, ld_buffer);
220
221     elf_start = handle->elf_image;
222
223     DEBUG_PRINTF ("load_spe_elf(%p, %p)\n", handle->elf_image, ld_buffer);
224     ehdr = (Elf32_Ehdr *) (handle->elf_image);
225
226     /* Check for a Valid SPE ELF Image (again) */
227     if ((ret=check_spe_elf(ehdr)))
228         return ret;
229
230     /* Start processing headers */
```

```

231     phdr = (Elf32_Phdr *) ((char *) ehdr + ehdr->e_phoff);
232     shdr = (Elf32_Shdr *) ((char *) ehdr + ehdr->e_shoff);
233     str_table = (char*)ehdr + shdr[ehdr->e_shstrndx].sh_offset;
234
235     /* traverse the sections to locate the toe segment */
236     /* by specification, the toe sections are grouped together in a segment */
237     for (sh = shdr; sh < &shdr[ehdr->e_shnum]; ++sh)
238     {
239         DEBUG_PRINTF("section name: %s ( start: 0x%04x, size: 0x%04x)\n", str_table+sh->sh_name);
240         if (strcmp(".toe", str_table+sh->sh_name) == 0) {
241             DEBUG_PRINTF("section offset: %d\n", sh->sh_offset);
242             toe_size += sh->sh_size;
243             if ((toe_addr == 0) || (toe_addr > sh->sh_addr))
244                 toe_addr = sh->sh_addr;
245         }
246         /* Disabled : Actually not needed, only good for testing
247         if (strcmp(".bss", str_table+sh->sh_name) == 0) {
248             DEBUG_PRINTF("zeroing .bss section:\n");
249             DEBUG_PRINTF("section offset: 0x%04x\n", sh->sh_offset);
250             DEBUG_PRINTF("section size: 0x%04x\n", sh->sh_size);
251             memset(ld_buffer + sh->sh_offset, 0, sh->sh_size);
252         } */
253
254 #ifdef DEBUG
255         if (strcmp(".note.spu_name", str_table+sh->sh_name) == 0)
256             display_debug_output(elf_start, sh);
257 #endif /*DEBUG*/
258     }
259
260     /*
261      * Load all PT_LOAD segments onto the SPE local store buffer.
262      */
263     DEBUG_PRINTF("Segments: 0x%x\n", ehdr->e_phnum);
264     for (ph = phdr, prev_ph = NULL; ph < &phdr[ehdr->e_phnum]; ++ph) {
265         switch (ph->p_type) {
266             case PT_LOAD:
267                 if (!overlay(ph, prev_ph)) {
268                     if (ph->p_filesz < ph->p_memsz) {
269                         DEBUG_PRINTF("padding loaded image with zeros:\n");
270                         DEBUG_PRINTF("start: 0x%04x\n", ph->p_vaddr + ph->p_filesz);
271                         DEBUG_PRINTF("length: 0x%04x\n", ph->p_memsz - ph->p_filesz);
272                         memset(ld_buffer + ph->p_vaddr + ph->p_filesz, 0, ph->p_memsz);
273                     }
274                     copy_to_ld_buffer(handle, ld_buffer, ph,
275                                     toe_addr, toe_size);
276                     num_load_seg++;
277                 }
278                 break;
279             case PT_NOTE:
280                 DEBUG_PRINTF("SPE_LOAD found PT_NOTE\n");
281                 break;
282             }
283         }
284         if (num_load_seg == 0)
285         {
286             DEBUG_PRINTF ("no segments to load");
287             errno = EINVAL;
288             return -errno;
289         }
290
291     /* Remember where the code wants to be started */
292     ld_info->entry = ehdr->e_entry;
293     DEBUG_PRINTF ("entry = 0x%x\n", ehdr->e_entry);
294
295     return 0;
296
297 }

```

3.8.2.2 int _base_spe_parse_isolated_elf (spe_program_handle_t * *handle*, uint64_t * *addr*, uint32_t * *size*)

Definition at line 111 of file elf_loader.c.

References DEBUG_PRINTF, and spe_program_handle::elf_image.

```

113 {
114     Elf32_Ehdr *ehdr = (Elf32_Ehdr *) handle->elf_image;
115     Elf32_Phdr *phdr;
116
117     if (!ehdr) {
118         DEBUG_PRINTF("No ELF image has been loaded\n");
119         errno = EINVAL;
120         return -errno;
121     }
122
123     if (ehdr->e_phentsize != sizeof(*phdr)) {
124         DEBUG_PRINTF("Invalid program header format (phdr size=%d)\n",
125                     ehdr->e_phentsize);
126         errno = EINVAL;
127         return -errno;
128     }
129
130     if (ehdr->e_phnum != 1) {
131         DEBUG_PRINTF("Invalid program header count (%d), expected 1\n",
132                     ehdr->e_phnum);
133         errno = EINVAL;
134         return -errno;
135     }
136
137     phdr = (Elf32_Phdr *) (handle->elf_image + ehdr->e_phoff);
138
139     if (phdr->p_type != PT_LOAD || phdr->p_memsz == 0) {
140         DEBUG_PRINTF("SPE program segment is not loadable (type=%x)\n",
141                     phdr->p_type);
142         errno = EINVAL;
143         return -errno;
144     }
145
146     if (addr)
147         *addr = (uint64_t) (unsigned long)
148             (handle->elf_image + phdr->p_offset);
149
150     if (size)
151         *size = phdr->p_memsz;
152
153     return 0;
154 }
```

3.8.2.3 int _base_spe_toe_ear (spe_program_handle_t * *speh*)

Definition at line 354 of file elf_loader.c.

References spe_program_handle::elf_image, and spe_program_handle::toe_shadow.

Referenced by _base_spe_image_open().

```

355 {
356     Elf32_Ehdr *ehdr;
357     Elf32_Shdr *shdr, *sh;
358     char *str_table;
359     char **ch;
```

```

360     int ret;
361     long toe_size;
362
363     ehdr = (Elf32_Ehdr*) (speh->elf_image);
364     shdr = (Elf32_Shdr*) ((char*) ehdr + ehdr->e_shoff);
365     str_table = (char*)ehdr + shdr[ehdr->e_shstrndx].sh_offset;
366
367     toe_size = 0;
368     for (sh = shdr; sh < &shdr[ehdr->e_shnum]; ++sh)
369         if (strcmp(".toe", str_table + sh->sh_name) == 0)
370             toe_size += sh->sh_size;
371
372     ret = 0;
373     if (toe_size > 0) {
374         for (sh = shdr; sh < &shdr[ehdr->e_shnum]; ++sh)
375             if (sh->sh_type == SHT_SYMTAB || sh->sh_type ==
376                 SHT_DYNSYM)
377                 ret = toe_check_syms(ehdr, sh);
378     if (!ret && toe_size != 16) {
379         /* Paranoia */
380         fprintf(stderr, "Unexpected toe size of %ld\n",
381                 toe_size);
382         errno = EINVAL;
383         ret = 1;
384     }
385 }
386 if (!ret && toe_size) {
387     /*
388      * Allocate toe_shadow, and fill it with elf_image.
389      */
390     speh->toe_shadow = malloc(toe_size);
391     if (speh->toe_shadow) {
392         ch = (char**) speh->toe_shadow;
393         if (sizeof(char*) == 8) {
394             ch[0] = (char*) speh->elf_image;
395             ch[1] = 0;
396         } else {
397             ch[0] = 0;
398             ch[1] = (char*) speh->elf_image;
399             ch[2] = 0;
400             ch[3] = 0;
401         }
402     } else {
403         errno = ENOMEM;
404         ret = 1;
405     }
406 }
407 return ret;
408 }
```

3.8.2.4 int _base_spe_verify_spe_elf_image (spe_program_handle_t * handle)

verifies integrity of an SPE image

Definition at line 99 of file elf_loader.c.

References spe_program_handle::elf_image.

Referenced by _base_spe_emulated_loader_present(), and _base_spe_image_open().

```



100 {
101     Elf32_Ehdr *ehdr;
102     void *elf_start;
103
104     elf_start = handle->elf_image;
```

```
105     ehdr = (Elf32_Ehdr *) (handle->elf_image);  
106     return check_spe_elf(ehdr);  
107 }  
108 }
```

3.9 elf_loader.h File Reference

```
#include "spebase.h"
#include <elf.h>

Include dependency graph for elf_loader.h:
```



Data Structures

- union [addr64](#)
- struct [spe_ld_info](#)

Defines

- #define [LS_SIZE](#) 0x40000
- #define [SPE_LDR_PROG_start](#) (LS_SIZE - 512)
- #define [SPE_LDR_PARAMS_start](#) (LS_SIZE - 128)

Functions

- int _base_spe_verify_spe_elf_image ([spe_program_handle_t](#) *handle)
- int _base_spe_load_spe_elf ([spe_program_handle_t](#) *handle, void *ld_buffer, struct [spe_ld_info](#) *ld_info)
- int _base_spe_parse_isolated_elf ([spe_program_handle_t](#) *handle, uint64_t *addr, uint32_t *size)
- int _base_spe_toe_ear ([spe_program_handle_t](#) *speh)

3.9.1 Define Documentation

3.9.1.1 #define LS_SIZE 0x40000

Definition at line 23 of file elf_loader.h.

Referenced by _base_spe_context_create(), _base_spe_context_run(), and _base_spe_ls_size_get().

3.9.1.2 #define SPE_LDR_PARAMS_start (LS_SIZE - 128)

Definition at line 26 of file elf_loader.h.

3.9.1.3 #define SPE_LDR_PROG_start (LS_SIZE - 512)

Definition at line 25 of file elf_loader.h.

3.9.2 Function Documentation

3.9.2.1 int _base_spe_load_spe_elf (spe_program_handle_t * handle, void * ld_buffer, struct spe_ld_info * ld_info)

Definition at line 201 of file elf_loader.c.

References DEBUG_PRINTF, spe_program_handle::elf_image, and spe_ld_info::entry.

Referenced by _base_spe_program_load().

```

202 {
203     Elf32_Ehdr *ehdr;
204     Elf32_Phdr *phdr;
205     Elf32_Phdr *ph, *prev_ph;
206
207     Elf32_Shdr *shdr;
208     Elf32_Shdr *sh;
209
210     Elf32_Off toe_addr = 0;
211     long toe_size = 0;
212
213     char* str_table = 0;
214
215     int num_load_seg = 0;
216     void *elf_start;
217     int ret;
218
219     DEBUG_PRINTF ("load_spe_elf(%p, %p)\n", handle, ld_buffer);
220
221     elf_start = handle->elf_image;
222
223     DEBUG_PRINTF ("load_spe_elf(%p, %p)\n", handle->elf_image, ld_buffer);
224     ehdr = (Elf32_Ehdr *) (handle->elf_image);
225
226     /* Check for a Valid SPE ELF Image (again) */
227     if ((ret=check_spe_elf(ehdr)))
228         return ret;
229
230     /* Start processing headers */
231     phdr = (Elf32_Phdr *) ((char *) ehdr + ehdr->e_phoff);
232     shdr = (Elf32_Shdr *) ((char *) ehdr + ehdr->e_shoff);
233     str_table = (char*)ehdr + shdr[ehdr->e_shstrndx].sh_offset;

```

```

234
235     /* traverse the sections to locate the toe segment */
236     /* by specification, the toe sections are grouped together in a segment */
237     for (sh = shdr; sh < &shdr[ehdr->e_shnum]; ++sh)
238     {
239         DEBUG_PRINTF("section name: %s ( start: 0x%04x, size: 0x%04x)\n", str_table+sh->sh_name);
240         if (strcmp(".toe", str_table+sh->sh_name) == 0) {
241             DEBUG_PRINTF("section offset: %d\n", sh->sh_offset);
242             toe_size += sh->sh_size;
243             if ((toe_addr == 0) || (toe_addr > sh->sh_addr))
244                 toe_addr = sh->sh_addr;
245         }
246         /* Disabled : Actually not needed, only good for testing
247         if (strcmp(".bss", str_table+sh->sh_name) == 0) {
248             DEBUG_PRINTF("zeroing .bss section:\n");
249             DEBUG_PRINTF("section offset: 0x%04x\n", sh->sh_offset);
250             DEBUG_PRINTF("section size: 0x%04x\n", sh->sh_size);
251             memset(ld_buffer + sh->sh_offset, 0, sh->sh_size);
252         } */
253
254 #ifdef DEBUG
255     if (strcmp(".note.spu_name", str_table+sh->sh_name) == 0)
256         display_debug_output(elf_start, sh);
257 #endif /*DEBUG*/
258     }
259
260     /*
261      * Load all PT_LOAD segments onto the SPE local store buffer.
262      */
263     DEBUG_PRINTF("Segments: 0x%x\n", ehdr->e_phnum);
264     for (ph = phdr, prev_ph = NULL; ph < &phdr[ehdr->e_phnum]; ++ph) {
265         switch (ph->p_type) {
266             case PT_LOAD:
267                 if (!overlay(ph, prev_ph)) {
268                     if (ph->p_filesz < ph->p_memsz) {
269                         DEBUG_PRINTF("padding loaded image with zeros:\n");
270                         DEBUG_PRINTF("start: 0x%04x\n", ph->p_vaddr + ph->p_filesz);
271                         DEBUG_PRINTF("length: 0x%04x\n", ph->p_memsz - ph->p_filesz);
272                         memset(ld_buffer + ph->p_vaddr + ph->p_filesz, 0, ph->p_memsz);
273                     }
274                     copy_to_ld_buffer(handle, ld_buffer, ph,
275                                     toe_addr, toe_size);
276                     num_load_seg++;
277                 }
278                 break;
279             case PT_NOTE:
280                 DEBUG_PRINTF("SPE_LOAD found PT_NOTE\n");
281                 break;
282             }
283         }
284     if (num_load_seg == 0)
285     {
286         DEBUG_PRINTF ("no segments to load");
287         errno = EINVAL;
288         return -errno;
289     }
290
291     /* Remember where the code wants to be started */
292     ld_info->entry = ehdr->e_entry;
293     DEBUG_PRINTF ("entry = 0x%x\n", ehdr->e_entry);
294
295     return 0;
296 }
297 }
```

3.9.2.2 int _base_spe_parse_isolated_elf (spe_program_handle_t * handle, uint64_t * addr, uint32_t * size)

Definition at line 111 of file elf_loader.c.

References DEBUG_PRINTF, and spe_program_handle::elf_image.

```

113 {
114     Elf32_Ehdr *ehdr = (Elf32_Ehdr *)handle->elf_image;
115     Elf32_Phdr *phdr;
116
117     if (!ehdr) {
118         DEBUG_PRINTF("No ELF image has been loaded\n");
119         errno = EINVAL;
120         return -errno;
121     }
122
123     if (ehdr->e_phentsize != sizeof(*phdr)) {
124         DEBUG_PRINTF("Invalid program header format (phdr size=%d)\n",
125                     ehdr->e_phentsize);
126         errno = EINVAL;
127         return -errno;
128     }
129
130     if (ehdr->e_phnum != 1) {
131         DEBUG_PRINTF("Invalid program header count (%d), expected 1\n",
132                     ehdr->e_phnum);
133         errno = EINVAL;
134         return -errno;
135     }
136
137     phdr = (Elf32_Phdr *) (handle->elf_image + ehdr->e_phoff);
138
139     if (phdr->p_type != PT_LOAD || phdr->p_memsz == 0) {
140         DEBUG_PRINTF("SPE program segment is not loadable (type=%x)\n",
141                     phdr->p_type);
142         errno = EINVAL;
143         return -errno;
144     }
145
146     if (addr)
147         *addr = (uint64_t)(unsigned long)
148             (handle->elf_image + phdr->p_offset);
149
150     if (size)
151         *size = phdr->p_memsz;
152
153     return 0;
154 }
```

3.9.2.3 int _base_spe_toe_ear (spe_program_handle_t * speh)

Definition at line 354 of file elf_loader.c.

References spe_program_handle::elf_image, and spe_program_handle::toe_shadow.

Referenced by _base_spe_image_open().

```

355 {
356     Elf32_Ehdr *ehdr;
357     Elf32_Shdr *shdr, *sh;
358     char *str_table;
359     char **ch;
```

```

360     int ret;
361     long toe_size;
362
363     ehdr = (Elf32_Ehdr*) (speh->elf_image);
364     shdr = (Elf32_Shdr*) ((char*) ehdr + ehdr->e_shoff);
365     str_table = (char*)ehdr + shdr[ehdr->e_shstrndx].sh_offset;
366
367     toe_size = 0;
368     for (sh = shdr; sh < &shdr[ehdr->e_shnum]; ++sh)
369         if (strcmp(".toe", str_table + sh->sh_name) == 0)
370             toe_size += sh->sh_size;
371
372     ret = 0;
373     if (toe_size > 0) {
374         for (sh = shdr; sh < &shdr[ehdr->e_shnum]; ++sh)
375             if (sh->sh_type == SHT_SYMTAB || sh->sh_type ==
376                 SHT_DYNSYM)
377                 ret = toe_check_syms(ehdr, sh);
378     if (!ret && toe_size != 16) {
379         /* Paranoia */
380         fprintf(stderr, "Unexpected toe size of %ld\n",
381                 toe_size);
382         errno = EINVAL;
383         ret = 1;
384     }
385 }
386 if (!ret && toe_size) {
387     /*
388      * Allocate toe_shadow, and fill it with elf_image.
389      */
390     speh->toe_shadow = malloc(toe_size);
391     if (speh->toe_shadow) {
392         ch = (char**) speh->toe_shadow;
393         if (sizeof(char*) == 8) {
394             ch[0] = (char*) speh->elf_image;
395             ch[1] = 0;
396         } else {
397             ch[0] = 0;
398             ch[1] = (char*) speh->elf_image;
399             ch[2] = 0;
400             ch[3] = 0;
401         }
402     } else {
403         errno = ENOMEM;
404         ret = 1;
405     }
406 }
407 return ret;
408 }
```

3.9.2.4 int _base_spe_verify_spe_elf_image (spe_program_handle_t * handle)

verifies integrity of an SPE image

Definition at line 99 of file elf_loader.c.

References spe_program_handle::elf_image.

Referenced by _base_spe_emulated_loader_present(), and _base_spe_image_open().

```

100 {
101     Elf32_Ehdr *ehdr;
102     void *elf_start;
103
104     elf_start = handle->elf_image;
```

```
105     ehdr = (Elf32_Ehdr *) (handle->elf_image);  
106     return check_spe_elf(ehdr);  
107 }  
108 }
```

3.10 handler_utils.h File Reference

Data Structures

- struct `spe_reg128`

Defines

- `#define LS_SIZE 0x40000`
- `#define LS_ADDR_MASK (LS_SIZE - 1)`
- `#define __PRINTF(fmt, args...) { fprintf(stderr,fmt , ## args); }`
- `#define DEBUG_PRINTF(fmt, args...)`
- `#define LS_ARG_ADDR(_index) (&((struct spe_reg128 *) ((char *) ls + ls_args))[_index])`
- `#define DECL_RET() struct spe_reg128 *ret = LS_ARG_ADDR(0)`
- `#define GET_LS_PTR(_off) (void *) ((char *) ls + (_off) & LS_ADDR_MASK))`
- `#define GET_LS_PTR_NULL(_off) ((_off) ? GET_LS_PTR(_off) : NULL)`
- `#define DECL_0_ARGS() unsigned int ls_args = (opdata & 0xffff)`
- `#define DECL_1_ARGS()`
- `#define DECL_2_ARGS()`
- `#define DECL_3_ARGS()`
- `#define DECL_4_ARGS()`
- `#define DECL_5_ARGS()`
- `#define DECL_6_ARGS()`
- `#define PUT_LS_RC(_a, _b, _c, _d)`

3.10.1 Define Documentation

3.10.1.1 `#define __PRINTF(fmt, args...) { fprintf(stderr,fmt , ## args); }`

Definition at line 32 of file handler_utils.h.

3.10.1.2 `#define DEBUG_PRINTF(fmt, args...)`

Definition at line 36 of file handler_utils.h.

3.10.1.3 `#define DECL_0_ARGS() unsigned int ls_args = (opdata & 0xffff)`

Definition at line 51 of file handler_utils.h.

3.10.1.4 `#define DECL_1_ARGS()`

Value:

```
DECL_0_ARGS(); \
    struct spe_reg128 *arg0 = LS_ARG_ADDR(0)
```

Definition at line 54 of file handler_utils.h.

3.10.1.5 #define DECL_2_ARGS()**Value:**

```
DECL_1_ARGS () ;  
    struct spe_reg128 *arg1 = LS_ARG_ADDR(1) \
```

Definition at line 58 of file handler_utils.h.

3.10.1.6 #define DECL_3_ARGS()**Value:**

```
DECL_2_ARGS () ;  
    struct spe_reg128 *arg2 = LS_ARG_ADDR(2) \
```

Definition at line 62 of file handler_utils.h.

3.10.1.7 #define DECL_4_ARGS()**Value:**

```
DECL_3_ARGS () ;  
    struct spe_reg128 *arg3 = LS_ARG_ADDR(3) \
```

Definition at line 66 of file handler_utils.h.

3.10.1.8 #define DECL_5_ARGS()**Value:**

```
DECL_4_ARGS () ;  
    struct spe_reg128 *arg4 = LS_ARG_ADDR(4) \
```

Definition at line 70 of file handler_utils.h.

3.10.1.9 #define DECL_6_ARGS()**Value:**

```
DECL_5_ARGS () ;  
    struct spe_reg128 *arg5 = LS_ARG_ADDR(5) \
```

Definition at line 74 of file handler_utils.h.

3.10.1.10 #define DECL_RET() struct spe_reg128 *ret = LS_ARG_ADDR(0)

Definition at line 42 of file handler_utils.h.

3.10.1.11 #define GET_LS_PTR(_off) (void *) ((char *) ls + ((_off) & LS_ADDR_MASK))

Definition at line 45 of file handler_utils.h.

3.10.1.12 #define GET_LS_PTR_NULL(_off) ((_off) ? GET_LS_PTR(_off) : NULL)

Definition at line 48 of file handler_utils.h.

3.10.1.13 #define LS_ADDR_MASK (LS_SIZE - 1)

Definition at line 29 of file handler_utils.h.

3.10.1.14 #define LS_ARG_ADDR(_index) (&((struct spe_reg128 *) ((char *) ls + ls_args))[_index])

Definition at line 39 of file handler_utils.h.

3.10.1.15 #define LS_SIZE 0x40000

Definition at line 28 of file handler_utils.h.

3.10.1.16 #define PUT_LS_RC(_a, _b, _c, _d)**Value:**


```
ret->slot[0] = (unsigned int) (_a);          \
ret->slot[1] = (unsigned int) (_b);          \
ret->slot[2] = (unsigned int) (_c);          \
ret->slot[3] = (unsigned int) (_d);          \
__asm__ __volatile__ ("sync" : : : "memory")
```

Definition at line 78 of file handler_utils.h.

3.11 image.c File Reference

```
#include <errno.h>
#include <fcntl.h>
#include <stdlib.h>
#include <sys/mman.h>
#include <sys/stat.h>
#include <unistd.h>
#include "elf_loader.h"
#include "spebase.h"
```

Include dependency graph for image.c:



Data Structures

- struct [image_handle](#)

Functions

- [spe_program_handle_t * _base_spe_image_open \(const char *filename\)](#)
- [int _base_spe_image_close \(spe_program_handle_t *handle\)](#)

3.11.1 Function Documentation

3.11.1.1 int _base_spe_image_close (spe_program_handle_t * *handle*)

`_base_spe_image_close` unmaps an SPE ELF object that was previously mapped using `spe_open_image`.

Parameters:

handle handle to open file

Return values:

0 On success, `spe_close_image` returns 0.

-I On failure, -1 is returned and errno is set appropriately.

Possible values for errno:

EINVAL From spe_close_image, this indicates that the file, specified by filename, was not previously mapped by a call to spe_open_image.

Definition at line 96 of file image.c.

References spe_program_handle::elf_image, image_handle::map_size, image_handle::speh, and spe_program_handle::toe_shadow.

```

97 {
98     int ret = 0;
99     struct image_handle *ih;
100
101    if (!handle) {
102        errno = EINVAL;
103        return -1;
104    }
105
106    ih = (struct image_handle *)handle;
107
108    if (!ih->speh.elf_image || !ih->map_size) {
109        errno = EINVAL;
110        return -1;
111    }
112
113    if (ih->speh.toe_shadow)
114        free(ih->speh.toe_shadow);
115
116    ret = munmap(ih->speh.elf_image, ih->map_size );
117    free(handle);
118
119    return ret;
120 }
```

3.11.1.2 spe_program_handle_t* _base_spe_image_open (const char *filename)

_base_spe_image_open maps an SPE ELF executable indicated by filename into system memory and returns the mapped address appropriate for use by the spe_create_thread API. It is often more convenient/appropriate to use the loading methodologies where SPE ELF objects are converted to PPE static or shared libraries with symbols which point to the SPE ELF objects after these special libraries are loaded. These libraries are then linked with the associated PPE code to provide a direct symbol reference to the SPE ELF object. The symbols in this scheme are equivalent to the address returned from the spe_open_image function. SPE ELF objects loaded using this function are not shared with other processes, but SPE ELF objects loaded using the other scheme, mentioned above, can be shared if so desired.

Parameters:

filename Specifies the filename of an SPE ELF executable to be loaded and mapped into system memory.

Returns:

On success, spe_open_image returns the address at which the specified SPE ELF object has been mapped. On failure, NULL is returned and errno is set appropriately.

Possible values for errno include:

EACCES The calling process does not have permission to access the specified file.

EFAULT The filename parameter points to an address that was not contained in the calling process's address space.

A number of other errno values could be returned by the open(2), fstat(2), mmap(2), munmap(2), or close(2) system calls which may be utilized by the spe_open_image or spe_close_image functions.

See also:

spe_create_thread


Definition at line 37 of file image.c.

References _base_spe_toe_ear(), _base_spe_verify_spe_elf_image(), spe_program_handle::elf_image, spe_program_handle::handle_size, image_handle::map_size, image_handle::speh, and spe_program_handle::toe_shadow.

```
38 {
39     /* allocate an extra integer in the spe handle to keep the mapped size information */
40     struct image_handle *ret;
41     int binfd = -1, f_stat;
42     struct stat statbuf;
43     size_t ps = getpagesize ();
44
45     ret = malloc(sizeof(struct image_handle));
46     if (!ret)
47         return NULL;
48
49     ret->speh.handle_size = sizeof(spe_program_handle_t);
50     ret->speh.toe_shadow = NULL;
51
52     binfd = open(filename, O_RDONLY);
53     if (binfd < 0)
54         goto ret_err;
55
56     f_stat = fstat(binfd, &statbuf);
57     if (f_stat < 0)
58         goto ret_err;
59
60     /* Sanity: is it executable ?
61      */
62     if (!(statbuf.st_mode & (S_IXUSR | S_IXGRP | S_IXOTH))) {
63         errno=EACCES;
64         goto ret_err;
65     }
66
67     /* now store the size at the extra allocated space */
68     ret->map_size = (statbuf.st_size + ps - 1) & ~(ps - 1);
69
70     ret->speh.elf_image = mmap(NULL, ret->map_size,
71                               PROT_WRITE | PROT_READ,
72                               MAP_PRIVATE, binfd, 0);
73     if (ret->speh.elf_image == MAP_FAILED)
74         goto ret_err;
75
76     /*Verify that this is a valid SPE ELF object*/
77     if(!_base_spe_verify_spe_elf_image((spe_program_handle_t *)ret)))
78         goto ret_err;
79
80     if (_base_spe_toe_ear(&ret->speh))
81         goto ret_err;
82
83     /* ok */
84     close(binfd);
85     return (spe_program_handle_t *)ret;
86
87     /* err & cleanup */
88 ret_err:
89     if (binfd >= 0)
90         close(binfd);
```

```
91         free(ret);
92         return NULL;
93     }
94 }
```


Here is the call graph for this function:



3.12 info.c File Reference

```
#include <dirent.h>
#include <errno.h>
#include <stdio.h>
#include "info.h"
```

Include dependency graph for info.c:



Functions

- [int _base_spe_count_physical_cpus \(int cpu_node\)](#)
- [int _base_spe_count_usable_spes \(int cpu_node\)](#)
- [int _base_spe_count_physical_spes \(int cpu_node\)](#)
- [int _base_spe_cpu_info_get \(int info_requested, int cpu_node\)](#)

3.12.1 Function Documentation

3.12.1.1 int _base_spe_count_physical_cpus (int *cpu_node*)

Definition at line 30 of file info.c.

References DEBUG_PRINTF, and THREADS_PER_BE.

Referenced by _base_spe_count_physical_spes(), and _base_spe_cpu_info_get().

```

31 {
32     const char    *buff = "/sys/devices/system/cpu";
33     DIR        *dirp;
34     int ret = -2;
35     struct dirent  *dptr;
36
37     DEBUG_PRINTF ("spe_count_physical_cpus()\n");
38
39     // make sure, cpu_node is in the correct range
40     if (cpu_node != -1) {
41         errno = EINVAL;
42         return -1;
43     }
44 }
```

```

45      // Count number of CPUs in /sys/devices/system/cpu
46      if((dirp=open(dirp))==NULL) {
47          fprintf(stderr,"Error opening %s ",buff);
48          perror("dirlist");
49          errno = EINVAL;
50          return -1;
51      }
52      while((dptr=readdir(dirp))) {
53          ret++;
54      }
55      closedir(dirp);
56      return ret/THREADS_PER_BE;
57 }

```

3.12.1.2 int _base_spe_count_physical_spes (int *cpu_node*)

Definition at line 71 of file info.c.

References _base_spe_count_physical_cpus(), and DEBUG_PRINTF.

Referenced by _base_spe_count_usable_spes(), and _base_spe_cpu_info_get().

```

72 {
73     const char      *buff = "/sys/devices/system/spu";
74     DIR      *dirp;
75     int ret = -2;
76     struct dirent  *dptr;
77     int no_of_bes;
78
79     DEBUG_PRINTF ("spe_count_physical_spes()\n");
80
81     // make sure, cpu_node is in the correct range
82     no_of_bes = _base_spe_count_physical_cpus(-1);
83     if (cpu_node < -1 || cpu_node >= no_of_bes ) {
84         errno = EINVAL;
85         return -1;
86     }
87
88     // Count number of SPUs in /sys/devices/system/spu
89     if((dirp=open(buff))==NULL) {
90         fprintf(stderr,"Error opening %s ",buff);
91         perror("dirlist");
92         errno = EINVAL;
93         return -1;
94     }
95     while((dptr=readdir(dirp))) {
96         ret++;
97     }
98     closedir(dirp);
99
100    if(cpu_node != -1) ret /= no_of_bes; // FIXME
101    return ret;
102 }

```

Here is the call graph for this function:



3.12.1.3 int _base_spe_count_usable_spes (int *cpu_node*)


Definition at line 62 of file info.c.

References _base_spe_count_physical_spes().

Referenced by _base_spe_cpu_info_get().

```
63 {
64     return _base_spe_count_physical_spes(cpu_node); // FIXME
65 }
```

Here is the call graph for this function:



3.12.1.4 int _base_spe_cpu_info_get (int *info_requested*, int *cpu_node*)


_base_spe_info_get

Definition at line 105 of file info.c.

References _base_spe_count_physical_cpus(), _base_spe_count_physical_spes(), _base_spe_count_usable_spes(), SPE_COUNT_PHYSICAL_CPU_NODES, SPE_COUNT_PHYSICAL_SPES, and SPE_COUNT_USABLE_SPES.

```
105
106     int ret = 0;
107     errno = 0;
108
109     switch (info_requested) {
110     case SPE_COUNT_PHYSICAL_CPU_NODES:
111         ret = _base_spe_count_physical_cpus(cpu_node);
112         break;
113     case SPE_COUNT_PHYSICAL_SPES:
114         ret = _base_spe_count_physical_spes(cpu_node);
115         break;
116     case SPE_COUNT_USABLE_SPES:
117         ret = _base_spe_count_usable_spes(cpu_node);
118         break;
119     default:
120         errno = EINVAL;
121         ret = -1;
122     }
123
124 }
```


Here is the call graph for this function:




3.13 info.h File Reference

```
#include "spebase.h"
```

Include dependency graph for info.h:



This graph shows which files directly or indirectly include this file:



Defines

- #define THREADS_PER_BE 2

Functions

- int _base_spe_count_physical_cpus (int cpu_node)
- int _base_spe_count_physical_spes (int cpu_node)
- int _base_spe_count_usable_spes (int cpu_node)

3.13.1 Define Documentation

3.13.1.1 #define THREADS_PER_BE 2

Definition at line 25 of file info.h.

Referenced by _base_spe_count_physical_cpus().

3.13.2 Function Documentation

3.13.2.1 int _base_spe_count_physical_cpus (int *cpu_node*)

Definition at line 30 of file info.c.

References DEBUG_PRINTF, and THREADS_PER_BE.

Referenced by _base_spe_count_physical_spes(), and _base_spe_cpu_info_get().

```

31 {
32     const char    *buff = "/sys/devices/system/cpu";
33     DIR      *dirp;
34     int ret = -2;
35     struct dirent  *dptr;
36
37     DEBUG_PRINTF ("spe_count_physical_cpus()\n");
38
39     // make sure, cpu_node is in the correct range
40     if (cpu_node != -1) {
41         errno = EINVAL;
42         return -1;
43     }
44
45     // Count number of CPUs in /sys/devices/system/cpu
46     if((dirp=open(dir(buff)))==NULL) {
47         fprintf(stderr,"Error opening %s ",buff);
48         perror("dirlist");
49         errno = EINVAL;
50         return -1;
51     }
52     while((dptr=readdir(dirp))) {
53         ret++;
54     }
55     closedir(dirp);
56     return ret/THREADS_PER_BE;
57 }
```

3.13.2.2 int _base_spe_count_physical_spes (int *cpu_node*)

Definition at line 71 of file info.c.

References _base_spe_count_physical_cpus(), and DEBUG_PRINTF.

Referenced by _base_spe_count_usable_spes(), and _base_spe_cpu_info_get().

```

72 {
73     const char    *buff = "/sys/devices/system/spu";
74     DIR      *dirp;
75     int ret = -2;
76     struct dirent  *dptr;
77     int no_of_bes;
78
79     DEBUG_PRINTF ("spe_count_physical_spes()\n");
80
81     // make sure, cpu_node is in the correct range
82     no_of_bes = _base_spe_count_physical_cpus(-1);
83     if (cpu_node < -1 || cpu_node >= no_of_bes ) {
84         errno = EINVAL;
85         return -1;
86     }
87
88     // Count number of SPUs in /sys/devices/system/spu
89     if((dirp=open(dir(buff)))==NULL) {
90         fprintf(stderr,"Error opening %s ",buff);
91         perror("dirlist");
92         errno = EINVAL;
93         return -1;
94     }
95     while((dptr=readdir(dirp))) {
```

```
96             ret++;
97         }
98         closedir(dirp);
99
100        if(cpu_node != -1) ret /= no_of_bes; // FIXME
101
102    }
```

Here is the call graph for this function:



3.13.2.3 int _base_spe_count_usable_spes (int *cpu_node*)

Definition at line 62 of file info.c.

References _base_spe_count_physical_spes().

Referenced by _base_spe_cpu_info_get().

```
63 {
64     return _base_spe_count_physical_spes(cpu_node); // FIXME
65 }
```


Here is the call graph for this function:



3.14 lib_builtin.c File Reference

```
#include <stdio.h>
#include <stdlib.h>
#include <errno.h>
#include "spebase.h"
#include "lib_builtin.h"
#include "default_c99_handler.h"
#include "default_posix1_handler.h"
#include "default_libea_handler.h"

Include dependency graph for lib_builtin.c:
```



Defines

- #define **HANDLER_IDX**(x) (x & 0xff)

Functions

- int **_base_spe_callback_handler_register** (void *handler, unsigned int callnum, unsigned int mode)
- int **_base_spe_callback_handler_deregister** (unsigned int callnum)
- void * **_base_spe_callback_handler_query** (unsigned int callnum)
- int **_base_spe_handle_library_callback** (struct **spe_context** *spe, int callnum, unsigned int npc)

3.14.1 Define Documentation

3.14.1.1 #define HANDLER_IDX(x) (x & 0xff)

Definition at line 29 of file lib_builtin.c.

3.14.2 Function Documentation

3.14.2.1 int _base_spe_callback_handler_deregister (unsigned int *callnum*)

unregister a handler function for the specified number NOTE: unregistering a handler from call zero and one is ignored.

Definition at line 78 of file lib_builtin.c.

References MAX_CALLNUM, and RESERVED.

```

79 {
80     errno = 0;
81     if (callnum > MAX_CALLNUM) {
82         errno = EINVAL;
83         return -1;
84     }
85     if (callnum < RESERVED) {
86         errno = EACCES;
87         return -1;
88     }
89     if (handlers[callnum] == NULL) {
90         errno = ESRCH;
91         return -1;
92     }
93     handlers[callnum] = NULL;
94     return 0;
95 }
96 }
```

3.14.2.2 void* _base_spe_callback_handler_query (unsigned int *callnum*)

query a handler function for the specified number

Definition at line 98 of file lib_builtin.c.

References MAX_CALLNUM.

```

99 {
100     errno = 0;
101
102     if (callnum > MAX_CALLNUM) {
103         errno = EINVAL;
104         return NULL;
105     }
106     if (handlers[callnum] == NULL) {
107         errno = ESRCH;
108         return NULL;
109     }
110     return handlers[callnum];
111 }
```

3.14.2.3 int _base_spe_callback_handler_register (void * *handler*, unsigned int *callnum*, unsigned int *mode*)

register a handler function for the specified number NOTE: registering a handler to call zero and one is ignored.

Definition at line 40 of file lib_builtin.c.

References MAX_CALLBACK_NUM, RESERVED, SPE_CALLBACK_NEW, and SPE_CALLBACK_UPDATE.

```

41 {
42     errno = 0;
43
44     if (callnum > MAX_CALLBACK_NUM) {
45         errno = EINVAL;
46         return -1;
47     }
48
49     switch(mode) {
50     case SPE_CALLBACK_NEW:
51         if (callnum < RESERVED) {
52             errno = EACCES;
53             return -1;
54         }
55         if (handlers[callnum] != NULL) {
56             errno = EACCES;
57             return -1;
58         }
59         handlers[callnum] = handler;
60         break;
61
62     case SPE_CALLBACK_UPDATE:
63         if (handlers[callnum] == NULL) {
64             errno = ESRCH;
65             return -1;
66         }
67         handlers[callnum] = handler;
68         break;
69     default:
70         errno = EINVAL;
71         return -1;
72         break;
73     }
74     return 0;
75 }
76 }
```

3.14.2.4 int _base_spe_handle_library_callback (struct spe_context *spe, int callnum, unsigned int npc)

Definition at line 113 of file lib_builtin.c.

References spe_context::base_private, DEBUG_PRINTF, spe_context_base_priv::flags, spe_context_base_priv::mem_mmap_base, SPE_EMULATE_PARAM_BUFFER, and SPE_ISOLATE_EMULATE.

Referenced by _base_spe_context_run().

```


115 {
116     int (*handler)(void *, unsigned int);
117     int rc;
118
119     errno = 0;
120     if (!handlers[callnum]) {
121         DEBUG_PRINTF ("No SPE library handler registered for this call.\n");
122         errno=ENOSYS;
123         return -1;
124     }
125
126     handler=handlers[callnum];
127 }
```

```
128     /* For emulated isolation mode, position the
129      * npc so that the buffer for the PPE-assisted
130      * library calls can be accessed. */
131     if (spe->base_private->flags & SPE_ISOLATE_EMULATE)
132         npc = SPE_EMULATE_PARAM_BUFFER;
133
134     rc = handler(spe->base_private->mem_mmap_base, npc);
135     if (rc) {
136         DEBUG_PRINTF ("SPE library call unsupported.\n");
137         errno=ENOSYS;
138         return rc;
139     }
140     return 0;
141 }
```


3.15 lib_builtin.h File Reference

```
#include "spebase.h"
```

Include dependency graph for lib_builtin.h:



This graph shows which files directly or indirectly include this file:



Defines

- #define [MAX_CALLNUM](#) 255
- #define [RESERVED](#) 4

Functions

- [int _base_spe_handle_library_callback \(struct spe_context *spe, int callnum, unsigned int npc\)](#)

3.15.1 Define Documentation

3.15.1.1 #define MAX_CALLNUM 255

Definition at line 25 of file lib_builtin.h.

Referenced by [_base_spe_callback_handler_deregister\(\)](#), [_base_spe_callback_handler_query\(\)](#), and [_base_spe_callback_handler_register\(\)](#).

3.15.1.2 #define RESERVED 4

Definition at line 26 of file lib_builtin.h.

Referenced by [_base_spe_callback_handler_deregister\(\)](#), and [_base_spe_callback_handler_register\(\)](#).

3.15.2 Function Documentation

3.15.2.1 int _base_spe_handle_library_callback (struct spe_context * *spe*, int *callnum*, unsigned int *npc*)

Definition at line 113 of file lib_builtin.c.

References *spe_context::base_private*, *DEBUG_PRINTF*, *spe_context_base_priv::flags*, *spe_context_base_priv::mem_mmap_base*, *SPE_EMULATE_PARAM_BUFFER*, and *SPE_ISOLATE_EMULATE*.


Referenced by *_base_spe_context_run()*.

```
115 {
116     int (*handler)(void *, unsigned int);
117     int rc;
118
119     errno = 0;
120     if (!handlers[callnum]) {
121         DEBUG_PRINTF ("No SPE library handler registered for this call.\n");
122         errno=ENOSYS;
123         return -1;
124     }
125
126     handler=handlers[callnum];
127
128     /* For emulated isolation mode, position the
129      * npc so that the buffer for the PPE-assisted
130      * library calls can be accessed. */
131     if (spe->base_private->flags & SPE_ISOLATE_EMULATE)
132         npc = SPE_EMULATE_PARAM_BUFFER;
133
134     rc = handler(spe->base_private->mem_mmap_base, npc);
135     if (rc) {
136         DEBUG_PRINTF ("SPE library call unsupported.\n");
137         errno=ENOSYS;
138         return rc;
139     }
140
141 }
```


3.16 libspe2-types.h File Reference

```
#include <limits.h>
#include "cbea_map.h"
```

Include dependency graph for libspe2-types.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct `spe_program_handle`
- struct `spe_context`
- struct `spe_gang_context`
- struct `spe_stop_info`
- union `spe_event_data`
- struct `spe_event_unit`

Defines

- #define `SPE_CFG_SIGNIFY1_OR` 0x000000010
- #define `SPE_CFG_SIGNIFY2_OR` 0x000000020
- #define `SPE_MAP_PS` 0x000000040
- #define `SPE_ISOLATE` 0x000000080
- #define `SPE_ISOLATE_EMULATE` 0x00000100
- #define `SPE_EVENTS_ENABLE` 0x00001000
- #define `SPE_AFFINITY_MEMORY` 0x00002000
- #define `SPE_EXIT` 1
- #define `SPE_STOP_AND_SIGNAL` 2
- #define `SPE_RUNTIME_ERROR` 3
- #define `SPE_RUNTIME_EXCEPTION` 4
- #define `SPE_RUNTIME_FATAL` 5
- #define `SPE_CALLBACK_ERROR` 6

- #define **SPE_ISOLATION_ERROR** 7
- #define **SPE_SPU_STOPPED_BY_STOP** 0x02
- #define **SPE_SPU_HALT** 0x04
- #define **SPE_SPU_WAITING_ON_CHANNEL** 0x08
- #define **SPE_SPU_SINGLE_STEP** 0x10
- #define **SPE_SPU_INVALID_INSTR** 0x20
- #define **SPE_SPU_INVALID_CHANNEL** 0x40
- #define **SPE_DMA_ALIGNMENT** 0x0008
- #define **SPE_DMA_SEGMENTATION** 0x0020
- #define **SPE_DMA_STORAGE** 0x0040
- #define **SIGSPE** SIGURG
- #define **SPE_EVENT_OUT_INTR_MBOX** 0x00000001
- #define **SPE_EVENT_IN_MBOX** 0x00000002
- #define **SPE_EVENT_TAG_GROUP** 0x00000004
- #define **SPE_EVENT_SPE_STOPPED** 0x00000008
- #define **SPE_EVENT_ALL_EVENTS**
- #define **SPE_MBOX_ALL_BLOCKING** 1
- #define **SPE_MBOX_ANY_BLOCKING** 2
- #define **SPE_MBOX_ANY_NONBLOCKING** 3
- #define **SPE_TAG_ALL** 1
- #define **SPE_TAG_ANY** 2
- #define **SPE_TAG_IMMEDIATE** 3
- #define **SPE_DEFAULT_ENTRY** UINT_MAX
- #define **SPE_RUN_USER_REGS** 0x00000001
- #define **SPE_NO_CALLBACKS** 0x00000002
- #define **SPE_CALLBACK_NEW** 1
- #define **SPE_CALLBACK_UPDATE** 2
- #define **SPE_COUNT_PHYSICAL_CPU_NODES** 1
- #define **SPE_COUNT_PHYSICAL_SPES** 2
- #define **SPE_COUNT_USABLE_SPES** 3
- #define **SPE_SIG_NOTIFY_REG_1** 0x0001
- #define **SPE_SIG_NOTIFY_REG_2** 0x0002

Typedefs

- typedef struct **spe_program_handle** **spe_program_handle_t**
- typedef struct **spe_context** * **spe_context_ptr_t**
- typedef struct **spe_gang_context** * **spe_gang_context_ptr_t**
- typedef struct **spe_stop_info** **spe_stop_info_t**
- typedef union **spe_event_data** **spe_event_data_t**
- typedef struct **spe_event_unit** **spe_event_unit_t**
- typedef void * **spe_event_handler_ptr_t**
- typedef int **spe_event_handler_t**

Enumerations

- enum **ps_area** {

 SPE_MSSYNC_AREA, **SPE_MFC_COMMAND_AREA**, **SPE_CONTROL_AREA**, **SPE_SIG_NOTIFY_1_AREA**,

 SPE_SIG_NOTIFY_2_AREA }

3.16.1 Define Documentation

3.16.1.1 #define SIGSPE SIGURG

SIGSPE maps to SIGURG

Definition at line 219 of file libspe2-types.h.

3.16.1.2 #define SPE_AFFINITY_MEMORY 0x00002000

Definition at line 182 of file libspe2-types.h.

Referenced by _base_spe_context_create().

3.16.1.3 #define SPE_CALLBACK_ERROR 6

Definition at line 194 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.4 #define SPE_CALLBACK_NEW 1

Definition at line 260 of file libspe2-types.h.

Referenced by _base_spe_callback_handler_register().

3.16.1.5 #define SPE_CALLBACK_UPDATE 2

Definition at line 261 of file libspe2-types.h.

Referenced by _base_spe_callback_handler_register().

3.16.1.6 #define SPE_CFG_SIGNIFY1_OR 0x00000010

Flags for spe_context_create

Definition at line 176 of file libspe2-types.h.

Referenced by _base_spe_context_create().

3.16.1.7 #define SPE_CFG_SIGNIFY2_OR 0x00000020

Definition at line 177 of file libspe2-types.h.

Referenced by _base_spe_context_create().

3.16.1.8 #define SPE_COUNT_PHYSICAL_CPU_NODES 1

Definition at line 265 of file libspe2-types.h.

Referenced by _base_spe_cpu_info_get().

3.16.1.9 #define SPE_COUNT_PHYSICAL_SPES 2

Definition at line 266 of file libspe2-types.h.

Referenced by _base_spe_cpu_info_get().

3.16.1.10 #define SPE_COUNT_USABLE_SPES 3

Definition at line 267 of file libspe2-types.h.

Referenced by _base_spe_cpu_info_get().

3.16.1.11 #define SPE_DEFAULT_ENTRY UINT_MAX

Flags for _base_spe_context_run

Definition at line 253 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.12 #define SPE_DMA_ALIGNMENT 0x0008

Runtime exceptions

Definition at line 210 of file libspe2-types.h.

3.16.1.13 #define SPE_DMA_SEGMENTATION 0x0020

Definition at line 212 of file libspe2-types.h.

3.16.1.14 #define SPE_DMA_STORAGE 0x0040

Definition at line 213 of file libspe2-types.h.

3.16.1.15 #define SPE_EVENT_ALL_EVENTS**Value:**

```
SPE_EVENT_OUT_INTR_MBOX | \
    SPE_EVENT_IN_MBOX | \
    SPE_EVENT_TAG_GROUP | \
    SPE_EVENT_SPE_STOPPED
```

Definition at line 229 of file libspe2-types.h.

3.16.1.16 #define SPE_EVENT_IN_MBOX 0x00000002

Definition at line 225 of file libspe2-types.h.

Referenced by _event_spe_event_handler_deregister(), and _event_spe_event_handler_register().

3.16.1.17 #define SPE_EVENT_OUT_INTR_MBOX 0x00000001

Supported SPE events

Definition at line 224 of file libspe2-types.h.

Referenced by _event_spe_event_handler_deregister(), and _event_spe_event_handler_register().

3.16.1.18 #define SPE_EVENT_SPE_STOPPED 0x00000008

Definition at line 227 of file libspe2-types.h.

Referenced by _event_spe_event_handler_deregister(), and _event_spe_event_handler_register().

3.16.1.19 #define SPE_EVENT_TAG_GROUP 0x00000004

Definition at line 226 of file libspe2-types.h.

Referenced by _event_spe_event_handler_deregister(), and _event_spe_event_handler_register().

3.16.1.20 #define SPE_EVENTS_ENABLE 0x00001000

Definition at line 181 of file libspe2-types.h.

Referenced by _base_spe_context_create(), and _base_spe_context_run().

3.16.1.21 #define SPE_EXIT 1

Symbolic constants for stop reasons as returned in spe_stop_info_t

Definition at line 189 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.22 #define SPE_ISOLATE 0x00000080

Definition at line 179 of file libspe2-types.h.

Referenced by _base_spe_context_create(), _base_spe_context_run(), and _base_spe_program_load().

3.16.1.23 #define SPE_ISOLATE_EMULATE 0x00000100

Definition at line 180 of file libspe2-types.h.

Referenced by _base_spe_context_create(), _base_spe_context_run(), _base_spe_handle_library_callback(), and _base_spe_program_load().

3.16.1.24 #define SPE_ISOLATION_ERROR 7

Definition at line 195 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.25 #define SPE_MAP_PS 0x00000040

Definition at line 178 of file libspe2-types.h.

Referenced by _base_spe_context_create(), _base_spe_in_mbox_status(), _base_spe_in_mbox_write(), _base_spe_mfcio_tag_status_read(), _base_spe_mssync_start(), _base_spe_mssync_status(), _base_spe_out_intr_mbox_status(), _base_spe_out_mbox_read(), _base_spe_out_mbox_status(), _base_spe_signal_write(), and _event_spe_event_handler_register().

3.16.1.26 #define SPE_MBOX_ALL_BLOCKING 1

Behavior flags for mailbox read/write functions

Definition at line 237 of file libspe2-types.h.

Referenced by _base_spe_in_mbox_write(), and _base_spe_out_intr_mbox_read().

3.16.1.27 #define SPE_MBOX_ANY_BLOCKING 2

Definition at line 238 of file libspe2-types.h.

Referenced by _base_spe_in_mbox_write(), and _base_spe_out_intr_mbox_read().

3.16.1.28 #define SPE_MBOX_ANY_NONBLOCKING 3

Definition at line 239 of file libspe2-types.h.

Referenced by _base_spe_in_mbox_write(), and _base_spe_out_intr_mbox_read().

3.16.1.29 #define SPE_NO_CALLBACKS 0x00000002

Definition at line 255 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.30 #define SPE_RUN_USER_REGS 0x00000001

Definition at line 254 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.31 #define SPE_RUNTIME_ERROR 3

Definition at line 191 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.32 #define SPE_RUNTIME_EXCEPTION 4

Definition at line 192 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.33 #define SPE_RUNTIME_FATAL 5

Definition at line 193 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.34 #define SPE_SIG_NOTIFY_REG_1 0x0001

Signal Targets

Definition at line 272 of file libspe2-types.h.

Referenced by _base_spe_signal_write().

3.16.1.35 #define SPE_SIG_NOTIFY_REG_2 0x0002

Definition at line 273 of file libspe2-types.h.

Referenced by _base_spe_signal_write().

3.16.1.36 #define SPE_SPU_HALT 0x04

Definition at line 201 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.37 #define SPE_SPU_INVALID_CHANNEL 0x40

Definition at line 205 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.38 #define SPE_SPU_INVALID_INSTR 0x20

Definition at line 204 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.39 #define SPE_SPU_SINGLE_STEP 0x10

Definition at line 203 of file libspe2-types.h.

3.16.1.40 #define SPE_SPU_STOPPED_BY_STOP 0x02

Runtime errors

Definition at line 200 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.41 #define SPE_SPU_WAITING_ON_CHANNEL 0x08

Definition at line 202 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.42 #define SPE_STOP_AND_SIGNAL 2

Definition at line 190 of file libspe2-types.h.

Referenced by _base_spe_context_run().

3.16.1.43 #define SPE_TAG_ALL 1

Behavior flags tag status functions

Definition at line 245 of file libspe2-types.h.

Referenced by _base_spe_mfcio_tag_status_read().

3.16.1.44 #define SPE_TAG_ANY 2

Definition at line 246 of file libspe2-types.h.

Referenced by _base_spe_mfcio_tag_status_read().

3.16.1.45 #define SPE_TAG_IMMEDIATE 3

Definition at line 247 of file libspe2-types.h.

Referenced by _base_spe_mfcio_tag_status_read().

3.16.2 Typedef Documentation

3.16.2.1 typedef struct spe_context* spe_context_ptr_t

spe_context_ptr_t This pointer serves as the identifier for a specific SPE context throughout the API (where needed)

Definition at line 83 of file libspe2-types.h.

3.16.2.2 typedef union spe_event_data spe_event_data_t

spe_event_data_t User data to be associated with an event

3.16.2.3 typedef void* spe_event_handler_ptr_t

Definition at line 159 of file libspe2-types.h.

3.16.2.4 typedef int spe_event_handler_t

Definition at line 160 of file libspe2-types.h.

3.16.2.5 `typedef struct spe_event_unit spe_event_unit_t`

`spe_event_t`

3.16.2.6 `typedef struct spe_gang_context* spe_gang_context_ptr_t`

`spe_gang_context_ptr_t` This pointer serves as the identifier for a specific SPE gang context throughout the API (where needed)

Definition at line 106 of file libspe2-types.h.

3.16.2.7 `typedef struct spe_program_handle spe_program_handle_t`

SPE program handle Structure `spe_program_handle` per CESOF specification libspe2 applications usually only keep a pointer to the program handle and do not use the structure directly.

3.16.2.8 `typedef struct spe_stop_info spe_stop_info_t`

`spe_stop_info_t`

3.16.3 Enumeration Type Documentation**3.16.3.1 `enum ps_area`**

Enumerator:

SPE_MSSYNC_AREA
SPE_MFC_COMMAND_AREA
SPE_CONTROL_AREA
SPE_SIG_NOTIFY_1_AREA
SPE_SIG_NOTIFY_2_AREA


Definition at line 171 of file libspe2-types.h.

171 { *SPE_MSSYNC_AREA*, *SPE_MFC_COMMAND_AREA*, *SPE_CONTROL_AREA*, *SPE_SIG_NOTIFY_1_AREA*, *SPE_SIG_NOTIFY_2_AREA*

3.17 libspe2.h File Reference

```
#include <errno.h>
#include <stdio.h>
#include "libspe2-types.h"
```

Include dependency graph for libspe2.h:



Functions

- `spe_context_ptr_t spe_context_create (unsigned int flags, spe_gang_context_ptr_t gang)`
- `spe_context_ptr_t spe_context_create_affinity (unsigned int flags, spe_context_ptr_t affinity_neighbor, spe_gang_context_ptr_t gang)`
- `int spe_context_destroy (spe_context_ptr_t spe)`
- `spe_gang_context_ptr_t spe_gang_context_create (unsigned int flags)`
- `int spe_gang_context_destroy (spe_gang_context_ptr_t gang)`
- `spe_program_handle_t * spe_image_open (const char *filename)`
- `int spe_image_close (spe_program_handle_t *program)`
- `int spe_program_load (spe_context_ptr_t spe, spe_program_handle_t *program)`
- `int spe_context_run (spe_context_ptr_t spe, unsigned int *entry, unsigned int runflags, void *argp, void *envp, spe_stop_info_t *stopinfo)`
- `int spe_stop_info_read (spe_context_ptr_t spe, spe_stop_info_t *stopinfo)`
- `spe_event_handler_ptr_t spe_event_handler_create (void)`
- `int spe_event_handler_destroy (spe_event_handler_ptr_t evhandler)`
- `int spe_event_handler_register (spe_event_handler_ptr_t evhandler, spe_event_unit_t *event)`
- `int spe_event_handler_deregister (spe_event_handler_ptr_t evhandler, spe_event_unit_t *event)`
- `int spe_event_wait (spe_event_handler_ptr_t evhandler, spe_event_unit_t *events, int max_events, int timeout)`
- `int spe_mfcio_put (spe_context_ptr_t spe, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- `int spe_mfcio_putb (spe_context_ptr_t spe, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- `int spe_mfcio_putf (spe_context_ptr_t spe, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- `int spe_mfcio_get (spe_context_ptr_t spe, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- `int spe_mfcio_getb (spe_context_ptr_t spe, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- `int spe_mfcio_getf (spe_context_ptr_t spe, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- `int spe_mfcio_tag_status_read (spe_context_ptr_t spe, unsigned int mask, unsigned int behavior, unsigned int *tag_status)`

- int `spe_out_mbox_read` (`spe_context_ptr_t` spe, unsigned int *mbox_data, int count)
- int `spe_out_mbox_status` (`spe_context_ptr_t` spe)
- int `spe_in_mbox_write` (`spe_context_ptr_t` spe, unsigned int *mbox_data, int count, unsigned int behavior)
- int `spe_in_mbox_status` (`spe_context_ptr_t` spe)
- int `spe_out_intr_mbox_read` (`spe_context_ptr_t` spe, unsigned int *mbox_data, int count, unsigned int behavior)
- int `spe_out_intr_mbox_status` (`spe_context_ptr_t` spe)
- int `spe_mssync_start` (`spe_context_ptr_t` spe)
- int `spe_mssync_status` (`spe_context_ptr_t` spe)
- int `spe_signal_write` (`spe_context_ptr_t` spe, unsigned int signal_reg, unsigned int data)
- void * `spe_ls_area_get` (`spe_context_ptr_t` spe)
- int `spe_ls_size_get` (`spe_context_ptr_t` spe)
- void * `spe_ps_area_get` (`spe_context_ptr_t` spe, enum `ps_area` area)
- int `spe_callback_handler_register` (void *handler, unsigned int callnum, unsigned int mode)
- int `spe_callback_handler_deregister` (unsigned int callnum)
- void * `spe_callback_handler_query` (unsigned int callnum)
- int `spe_cpu_info_get` (int info_requested, int cpu_node)


3.17.1 Function Documentation

- 3.17.1.1 `int spe_callback_handler_deregister (unsigned int callnum)`
- 3.17.1.2 `void* spe_callback_handler_query (unsigned int callnum)`
- 3.17.1.3 `int spe_callback_handler_register (void * handler, unsigned int callnum, unsigned int mode)`
- 3.17.1.4 `spe_context_ptr_t spe_context_create (unsigned int flags, spe_gang_context_ptr_t gang)`
- 3.17.1.5 `spe_context_ptr_t spe_context_create_affinity (unsigned int flags, spe_context_ptr_t affinity_neighbor, spe_gang_context_ptr_t gang)`
- 3.17.1.6 `int spe_context_destroy (spe_context_ptr_t spe)`
- 3.17.1.7 `int spe_context_run (spe_context_ptr_t spe, unsigned int * entry, unsigned int runflags, void * argp, void * envp, spe_stop_info_t * stopinfo)`
- 3.17.1.8 `int spe_cpu_info_get (int info_requested, int cpu_node)`
- 3.17.1.9 `spe_event_handler_ptr_t spe_event_handler_create (void)`
- 3.17.1.10 `int spe_event_handler_deregister (spe_event_handler_ptr_t evhandler, spe_event_unit_t * event)`
- 3.17.1.11 `int spe_event_handler_destroy (spe_event_handler_ptr_t evhandler)`
- 3.17.1.12 `int spe_event_handler_register (spe_event_handler_ptr_t evhandler, spe_event_unit_t * event)`
- 3.17.1.13 `int spe_event_wait (spe_event_handler_ptr_t evhandler, spe_event_unit_t * events, int max_events, int timeout)`
- 3.17.1.14 `spe_gang_context_ptr_t spe_gang_context_create (unsigned int flags)`
- 3.17.1.15 `int spe_gang_context_destroy (spe_gang_context_ptr_t gang)`
- 3.17.1.16 `int spe_image_close (spe_program_handle_t * program)`
- 3.17.1.17 `spe_program_handle_t* spe_image_open (const char *filename)`
- 3.17.1.18 `int spe_in_mbox_status (spe_context_ptr_t spe)`
- 3.17.1.19 `int spe_in_mbox_write (spe_context_ptr_t spe, unsigned int * mbox_data, int count, unsigned int behavior)`
- 3.17.1.20 `void* spe_ls_area_get (spe_context_ptr_t spe)`
- 3.17.1.21 `int spe_ls_size_get (spe_context_ptr_t spe)`
- 3.17.1.22 `int spe_mfcio_get (spe_context_ptr_t spe, unsigned int ls, void * ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- 3.17.1.23 `int spe_mfcio_getb (spe_context_ptr_t spe, unsigned int ls, void * ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- 3.17.1.24 `int spe_mfcio_getf (spe_context_ptr_t spe, unsigned int ls, void * ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)`
- 3.17.1.25 `int spe_mfcio_put (spe_context_ptr_t spe, unsigned int ls, void * ea, unsigned int size,`

3.18 load.c File Reference

```
#include <fcntl.h>
#include <stdio.h>
#include <string.h>
#include <unistd.h>
#include <stdlib.h>
#include <errno.h>
#include "elf_loader.h"
#include "spebase.h"
```

Include dependency graph for load.c:



Defines

- #define SPE_EMULATED_LOADER_FILE "/usr/lib/spe/emulated-loader.bin"

Functions

- void _base_spe_program_load_complete (spe_context_ptr_t spectx)
- int _base_spe_emulated_loader_present (void)
- int _base_spe_program_load (spe_context_ptr_t spe, spe_program_handle_t *program)

3.18.1 Define Documentation

3.18.1.1 #define SPE_EMULATED_LOADER_FILE "/usr/lib/spe/emulated-loader.bin"

Definition at line 30 of file load.c.

3.18.2 Function Documentation

3.18.2.1 int _base_spe_emulated_loader_present (void)

Check if the emulated loader is present in the filesystem

Returns:

Non-zero if the loader is available, otherwise zero.

Definition at line 145 of file load.c.

References `_base_spe_verify_spe_elf_image()`.

Referenced by `_base_spe_context_create()`.

```

146 {
147     spe_program_handle_t *loader = emulated_loader_program();
148
149     if (!loader)
150         return 0;
151
152     return !_base_spe_verify_spe_elf_image(loader);
153 }
```

Here is the call graph for this function:



3.18.2.2 int _base_spe_program_load (spe_context_ptr_t *spectx*, spe_program_handle_t * *program*)

`_base_spe_program_load` loads an ELF image into a context

Parameters:

spectx Specifies the SPE context

program handle to the ELF image

Definition at line 189 of file load.c.

References `_base_spe_load_spe_elf()`, `_base_spe_program_load_complete()`, `spe_context::base_private`, `DEBUG_PRINTF`, `spe_context_base_priv::emulated_entry`, `spe_ld_info::entry`, `spe_context_base_priv::entry`, `spe_context_base_priv::flags`, `spe_context_base_priv::loaded_program`, `spe_context_base_priv::mem_mmap_base`, `SPE_ISOLATE`, and `SPE_ISOLATE_EMULATE`.


```

190 {
191     int rc = 0;
192     struct spe_ld_info ld_info;
193
194     spe->base_private->loaded_program = program;
195
196     if (spe->base_private->flags & SPE_ISOLATE) {
197         rc = spe_start_isolated_app(spe, program);
198
199     } else if (spe->base_private->flags & SPE_ISOLATE_EMULATE) {
200         rc = spe_start_emulated_isolated_app(spe, program, &ld_info);
201
202     } else {
203         rc = _base_spe_load_spe_elf(program,
204                                     spe->base_private->mem_mmap_base, &ld_info);
205         if (!rc)
206             _base_spe_program_load_complete(spe);
207     }
208 }
```

```

209     if (rc != 0) {
210         DEBUG_PRINTF ("Load SPE ELF failed..\n");
211         return -1;
212     }
213
214     spe->base_private->entry = ld_info.entry;
215     spe->base_private->emulated_entry = ld_info.entry;
216
217     return 0;
218 }
```

Here is the call graph for this function:



3.18.2.3 void _base_spe_program_load_complete (spe_context_ptr_t spectx)

Register the SPE program's start address with the oprofile and gdb, by writing to the object-id file.

Definition at line 37 of file load.c.

References `_spe_context_update_event()`, `spe_context::base_private`, `DEBUG_PRINTF`, `spe_program_handle::elf_image`, `spe_context_base_priv::fd_spe_dir`, and `spe_context_base_priv::loaded_program`.

Referenced by `_base_spe_context_run()`, and `_base_spe_program_load()`.

```

38 {
39     int objfd, len;
40     char buf[20];
41     spe_program_handle_t *program;
42
43     program = spectx->base_private->loaded_program;
44
45     if (!program || !program->elf_image) {
46         DEBUG_PRINTF ("%s called, but no program loaded\n", __func__);
47         return;
48     }
49
50     objfd = openat (spectx->base_private->fd_spe_dir, "object-id", O_RDWR);
51     if (objfd < 0)
52         return;
53
54     len = sprintf (buf, "%p", program->elf_image);
55     write (objfd, buf, len + 1);
56     close (objfd);
57
58     __spe_context_update_event ();
59 }
```


Here is the call graph for this function:



3.19 mbox.c File Reference

```
#include <errno.h>
#include <fcntl.h>
#include <poll.h>
#include <stdio.h>
#include <unistd.h>
#include "create.h"
#include "mbox.h"
```

Include dependency graph for mbox.c:



Functions

- [int _base_spe_out_mbox_read \(spe_context_ptr_t spectx, unsigned int mbox_data\[\], int count\)](#)
- [int _base_spe_in_mbox_write \(spe_context_ptr_t spectx, unsigned int *mbox_data, int count, int behavior_flag\)](#)
- [int _base_spe_in_mbox_status \(spe_context_ptr_t spectx\)](#)
- [int _base_spe_out_mbox_status \(spe_context_ptr_t spectx\)](#)
- [int _base_spe_out_intr_mbox_status \(spe_context_ptr_t spectx\)](#)
- [int _base_spe_out_intr_mbox_read \(spe_context_ptr_t spectx, unsigned int mbox_data\[\], int count, int behavior_flag\)](#)
- [int _base_spe_signal_write \(spe_context_ptr_t spectx, unsigned int signal_reg, unsigned int data\)](#)

3.19.1 Function Documentation

3.19.1.1 int _base_spe_in_mbox_status (spe_context_ptr_t *spectx*)

The `_base_spe_in_mbox_status` function fetches the status of the SPU inbound mailbox for the SPE thread specified by the `speid` parameter. A 0 value is return if the mailbox is full. A non-zero value specifies the number of available (32-bit) mailbox entries.

Parameters:

`spectx` Specifies the SPE context whose mailbox status is to be read.

Returns:

On success, returns the current status of the mailbox, respectively. On failure, -1 is returned.

See also:

`spe_read_out_mbox`, `spe_write_in_mbox`, `read` (2)


Definition at line 202 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `FD_WBOX_STAT`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, and `spe_spu_control_area::SPU_Mbox_Stat`.

```

203 {
204     int rc, ret;
205     volatile struct spe_spu_control_area *cntl_area =
206         spectx->base_private->cntl_mmap_base;
207
208     if (spectx->base_private->flags & SPE_MAP_PS) {
209         ret = (cntl_area->SPU_Mbox_Stat >> 8) & 0xFF;
210     } else {
211         rc = read(_base_spe_open_if_closed(spectx, FD_WBOX_STAT, 0), &ret, 4);
212         if (rc != 4)
213             ret = -1;
214     }
215
216     return ret;
217 }
218 }
```

Here is the call graph for this function:



3.19.1.2 `int _base_spe_in_mbox_write (spe_context_ptr_t spectx, unsigned int *mbox_data, int count, int behavior_flag)`

Definition at line 112 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `FD_WBOX`, `FD_WBOX_NB`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, `SPE_MBOX_ALL_BLOCKING`, `SPE_MBOX_ANY_BLOCKING`, and `SPE_MBOX_ANY_NONBLOCKING`.

```

116 {
117     int rc;
118     int total;
119     unsigned int *aux;
120     struct pollfd fds;
121
122     if (mbox_data == NULL || count < 1) {
123         errno = EINVAL;
124         return -1;
125     }
126
127     switch (behavior_flag) {
128         case SPE_MBOX_ALL_BLOCKING: // write all, even if blocking
```

```


129         total = rc = 0;
130         if (spectx->base_private->flags & SPE_MAP_PS) {
131             do {
132                 aux = mbox_data + total;
133                 total += _base_spe_in_mbox_write_ps(spectx, aux, count - total);
134                 if (total < count) { // we could not write everything, wait for space
135                     fds.fd = _base_spe_open_if_closed(spectx, FD_WBOX, 0);
136                     fds.events = POLLOUT;
137                     rc = poll(&fds, 1, -1);
138                     if (rc == -1)
139                         return -1;
140                 }
141             } while (total < count);
142         } else {
143             while (total < 4*count) {
144                 rc = write(_base_spe_open_if_closed(spectx, FD_WBOX, 0),
145                             (const char *)mbox_data + total, 4*count - total);
146                 if (rc == -1) {
147                     break;
148                 }
149                 total += rc;
150             }
151             total /=4;
152         }
153     break;
154
155 case SPE_MBOX_ANY_BLOCKING: // write at least one, even if blocking
156     total = rc = 0;
157     if (spectx->base_private->flags & SPE_MAP_PS) {
158         do {
159             total = _base_spe_in_mbox_write_ps(spectx, mbox_data, count);
160             if (total == 0) { // we could not anything, wait for space
161                 fds.fd = _base_spe_open_if_closed(spectx, FD_WBOX, 0);
162                 fds.events = POLLOUT;
163                 rc = poll(&fds, 1, -1);
164                 if (rc == -1)
165                     return -1;
166             }
167         } while (total == 0);
168     } else {
169         rc = write(_base_spe_open_if_closed(spectx, FD_WBOX, 0), mbox_data, 4*count);
170         total = rc/4;
171     }
172     break;
173
174 case SPE_MBOX_ANY_NONBLOCKING: // only write, if non blocking
175     total = rc = 0;
176     // write directly if we map the PS else write via spufs
177     if (spectx->base_private->flags & SPE_MAP_PS) {
178         total = _base_spe_in_mbox_write_ps(spectx, mbox_data, count);
179     } else {
180         rc = write(_base_spe_open_if_closed(spectx, FD_WBOX_NB, 0), mbox_data, 4*count);
181         if (rc == -1 && errno == EAGAIN) {
182             rc = 0;
183             errno = 0;
184         }
185         total = rc/4;
186     }
187     break;
188
189 default:
190     errno = EINVAL;
191     return -1;
192 }
193
194 if (rc == -1) {
195     errno = EIO;

```

```

196             return -1;
197         }
198
199     return total;
200 }
```

Here is the call graph for this function:



3.19.1.3 int _base_spe_out_intr_mbox_read (spe_context_ptr_t *spectx*, unsigned int *mbox_data*[], int *count*, int *behavior_flag*)

The `_base_spe_out_intr_mbox_read` function reads the contents of the SPE outbound interrupting mailbox for the SPE context.

Definition at line 255 of file mbox.c.

References `_base_spe_open_if_closed()`, `FD_IBOX`, `FD_IBOX_NB`, `SPE_MBOX_ALL_BLOCKING`, `SPE_MBOX_ANY_BLOCKING`, and `SPE_MBOX_ANY_NONBLOCKING`.

```


259 {
260     int rc;
261     int total;
262
263     if (mbox_data == NULL || count < 1) {
264         errno = EINVAL;
265         return -1;
266     }
267
268     switch (behavior_flag) {
269     case SPE_MBOX_ALL_BLOCKING: // read all, even if blocking
270         total = rc = 0;
271         while (total < 4*count) {
272             rc = read(_base_spe_open_if_closed(spectx, FD_IBOX, 0),
273                       (char *)mbox_data + total, 4*count - total);
274             if (rc == -1) {
275                 break;
276             }
277             total += rc;
278         }
279         break;
280
281     case SPE_MBOX_ANY_BLOCKING: // read at least one, even if blocking
282         total = rc = read(_base_spe_open_if_closed(spectx, FD_IBOX, 0), mbox_data, 4*count);
283         break;
284
285     case SPE_MBOX_ANY_NONBLOCKING: // only read, if non blocking
286         rc = read(_base_spe_open_if_closed(spectx, FD_IBOX_NB, 0), mbox_data, 4*count);
287         if (rc == -1 && errno == EAGAIN) {
288             rc = 0;
289             errno = 0;
290         }
291         total = rc;
292         break;
293
294     default:
295         errno = EINVAL;
```

```

296             return -1;
297         }
298
299         if (rc == -1) {
300             errno = EIO;
301             return -1;
302         }
303
304         return rc / 4;
305     }

```

Here is the call graph for this function:



3.19.1.4 int _base_spe_out_intr_mbox_status (spe_context_ptr_t *spectx*)

The `_base_spe_out_intr_mbox_status` function fetches the status of the SPU outbound interrupt mailbox for the SPE thread specified by the *spectx* parameter. A 0 value is returned if the mailbox is empty. A non-zero value specifies the number of 32-bit unread mailbox entries.

Parameters:

spectx Specifies the SPE context whose mailbox status is to be read.

Returns:

On success, returns the current status of the mailbox, respectively. On failure, -1 is returned.

See also:

`spe_read_out_mbox`, `spe_write_in_mbox`, `read (2)`

Definition at line 238 of file mbox.c.


References `_base_spe_open_if_closed()`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `FD_IBOX_STAT`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, and `spe_spu_control_area::SPU_Mbox_Stat`.

```

239 {
240     int rc, ret;
241     volatile struct spe_spu_control_area *cntl_area =
242         spectx->base_private->cntl_mmap_base;
243
244     if (spectx->base_private->flags & SPE_MAP_PS) {
245         ret = (cntl_area->SPU_Mbox_Stat >> 16) & 0xFF;
246     } else {
247         rc = read(_base_spe_open_if_closed(spectx, FD_IBOX_STAT, 0), &ret, 4);
248         if (rc != 4)
249             ret = -1;
250
251     }
252     return ret;
253 }

```

Here is the call graph for this function:



3.19.1.5 int _base_spe_out_mbox_read (spe_context_ptr_t spectx, unsigned int mbox_data[], int count)

The `_base_spe_out_mbox_read` function reads the contents of the SPE outbound interrupting mailbox for the SPE thread speid.

The call will not block until the read request is satisfied, but instead return up to count currently available mailbox entries.

`spe_stat_out_intr_mbox` can be called to ensure that data is available prior to reading the outbound interrupting mailbox.

Parameters:

`spectx` Specifies the SPE thread whose outbound mailbox is to be read.

`mbox_data`

`count`

Return values:

>0 the number of 32-bit mailbox messages read

=0 no data available

-1 error condition and errno is set

Possible values for errno:

EINVAL speid is invalid

Exxxx what else do we need here??

Definition at line 58 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `DEBUG_PRINTF`, `FD_MBOX`, `spe_context_base_priv::flags`, and `SPE_MAP_PS`.

```


61 {
62     int rc;
63
64     if (mbox_data == NULL || count < 1) {
65         errno = EINVAL;
66         return -1;
67     }
68
69     if (spectx->base_private->flags & SPE_MAP_PS) {
70         rc = _base_spe_out_mbox_read_ps(spectx, mbox_data, count);
71     } else {
72         rc = read(_base_spe_open_if_closed(spectx, FD_MBOX, 0), mbox_data, count*4);
73         DEBUG_PRINTF("%s read rc: %d\n", __FUNCTION__, rc);
74         if (rc != -1) {
75             rc /= 4;
76         } else {
77             if (errno == EAGAIN ) { // no data ready to be read
78                 errno = 0;

```

```

79                     rc = 0;
80                 }
81             }
82         }
83     return rc;
84 }
```

Here is the call graph for this function:



3.19.1.6 int _base_spe_out_mbox_status (spe_context_ptr_t spectx)

The `_base_spe_out_mbox_status` function fetches the status of the SPU outbound mailbox for the SPE thread specified by the `speid` parameter. A 0 value is returned if the mailbox is empty. A non-zero value specifies the number of 32-bit unread mailbox entries.

Parameters:

`spectx` Specifies the SPE context whose mailbox status is to be read.

Returns:

On success, returns the current status of the mailbox, respectively. On failure, -1 is returned.

See also:

`spe_read_out_mbox`, `spe_write_in_mbox`, `read` (2)


Definition at line 220 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `FD_MBOX_STAT`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, and `spe_spu_control_area::SPU_Mbox_Status`.

```

221 {
222     int rc, ret;
223     volatile struct spe_spu_control_area *cntl_area =
224         spectx->base_private->cntl_mmap_base;
225
226     if (spectx->base_private->flags & SPE_MAP_PS) {
227         ret = cntl_area->SPU_Mbox_Status & 0xFF;
228     } else {
229         rc = read(_base_spe_open_if_closed(spectx, FD_MBOX_STAT, 0), &ret, 4);
230         if (rc != 4)
231             ret = -1;
232     }
233
234     return ret;
235
236 }
```

Here is the call graph for this function:



3.19.1.7 int _base_spe_signal_write (spe_context_ptr_t *spectx*, unsigned int *signal_reg*, unsigned int *data*)

The _base_spe_signal_write function writes data to the signal notification register specified by signal_reg for the SPE thread specified by the speid parameter.

Parameters:

spectx Specifies the SPE context whose signal register is to be written to.

signal_reg Specified the signal notification register to be written. Valid signal notification registers are:

SPE_SIG_NOTIFY_REG_1 SPE signal notification register 1

SPE_SIG_NOTIFY_REG_2 SPE signal notification register 2

data The 32-bit data to be written to the specified signal notification register.

Returns:

On success, spe_write_signal returns 0. On failure, -1 is returned.

See also:

[spe_get_ps_area](#), [spe_write_in_mbox](#)

Definition at line 307 of file mbox.c.

References *_base_spe_close_if_open()*, *_base_spe_open_if_closed()*, *spe_context::base_private*, *FD_SIG1*, *FD_SIG2*, *spe_context_base_priv::flags*, *spe_context_base_priv::signal1_mmap_base*, *spe_context_base_priv::signal2_mmap_base*, *SPE_MAP_PS*, *SPE_SIG_NOTIFY_REG_1*, *SPE_SIG_NOTIFY_REG_2*, *spe_sig_notify_1_area::SPU_Sig_Notify_1*, and *spe_sig_notify_2_area::SPU_Sig_Notify_2*.


```

310 {
311     int rc;
312
313     if (spectx->base_private->flags & SPE_MAP_PS) {
314         if (signal_reg == SPE_SIG_NOTIFY_REG_1) {
315             spe_sig_notify_1_area_t *sig = spectx->base_private->signal1_mmap_base;
316
317             sig->SPU_Sig_Notify_1 = data;
318         } else if (signal_reg == SPE_SIG_NOTIFY_REG_2) {
319             spe_sig_notify_2_area_t *sig = spectx->base_private->signal2_mmap_base;
320
321             sig->SPU_Sig_Notify_2 = data;
322         } else {
323             errno = EINVAL;
324             return -1;
325         }
326         rc = 0;
327     } else {
328         if (signal_reg == SPE_SIG_NOTIFY_REG_1)
329             rc = write(_base_spe_open_if_closed(spectx, FD_SIG1, 0), &data, 4);
330         else if (signal_reg == SPE_SIG_NOTIFY_REG_2)
331             rc = write(_base_spe_open_if_closed(spectx, FD_SIG2, 0), &data, 4);
332         else {
333             errno = EINVAL;
334             return -1;
335         }
336
337         if (rc == 4)
338             rc = 0;
339
340         if (signal_reg == SPE_SIG_NOTIFY_REG_1)

```

```
341             _base_spe_close_if_open(spectx,FD_SIG1);
342         else if (signal_reg == SPE_SIGNAL_NOTIFY_REG_2)
343             _base_spe_close_if_open(spectx,FD_SIG2);
344     }
345
346     return rc;
347 }
```


Here is the call graph for this function:




3.20 mbox.h File Reference

```
#include "spebase.h"
```

Include dependency graph for mbox.h:




This graph shows which files directly or indirectly include this file:



3.21 run.c File Reference

```
#include <errno.h>
#include <fcntl.h>
#include <stdio.h>
#include <stdint.h>
#include <stdlib.h>
#include <string.h>
#include <syscall.h>
#include <unistd.h>
#include <sys/types.h>
#include <sys/spu.h>
#include "elf_loader.h"
#include "lib_builtin.h"
#include "spebase.h"
```

Include dependency graph for run.c:



Data Structures

- struct [spe_context_info](#)

Defines

- #define [GNU_SOURCE](#) 1

Functions

- int [_base_spe_context_run](#) ([spe_context_ptr_t](#) spe, unsigned int *entry, unsigned int runflags, void *argp, void *envp, [spe_stop_info_t](#) *stopinfo)

Variables

- __thread struct [spe_context_info](#) * [__spe_current_active_context](#)

3.21.1 Define Documentation

3.21.1.1 #define GNU_SOURCE 1

Definition at line 20 of file run.c.

3.21.2 Function Documentation

3.21.2.1 int _base_spe_context_run (spe_context_ptr_t spe, unsigned int * entry, unsigned int runflags, void * argp, void * envp, spe_stop_info_t * stopinfo)

_base_spe_context_run starts execution of an SPE context with a loaded image

Parameters:

spectx Specifies the SPE context

entry entry point for the SPE programm. If set to 0, entry point is determined by the ELF loader.

runflags valid values are:

SPE_RUN_USER_REGS Specifies that the SPE setup registers r3, r4, and r5 are initialized with the 48 bytes pointed to by argp.

SPE_NO_CALLBACKS do not use built in library functions.

argp An (optional) pointer to application specific data, and is passed as the second parameter to the SPE program.

envp An (optional) pointer to environment specific data, and is passed as the third parameter to the SPE program.

Definition at line 98 of file run.c.

References __spe_current_active_context, _base_spe_handle_library_callback(), _base_spe_program_load_complete(), spe_context::base_private, DEBUG_PRINTF, spe_context_base_priv::emulated_entry, spe_context_base_priv::entry, spe_context_base_priv::fd_spe_dir, spe_context_base_priv::flags, LS_SIZE, spe_context_base_priv::mem_mmap_base, spe_context_info::npc, spe_context_info::prev, spe_stop_info::result, spe_stop_info::spe_callback_error, SPE_CALLBACK_ERROR, SPE_DEFAULT_ENTRY, SPE_EVENTS_ENABLE, SPE_EXIT, spe_stop_info::spe_exit_code, spe_context_info::spe_id, SPE_ISOLATE, SPE_ISOLATE_EMULATE, spe_stop_info::spe_isolation_error, SPE_ISOLATION_ERROR, SPE_NO_CALLBACKS, SPE_PROGRAM_ISO_LOAD_COMPLETE, SPE_PROGRAM_ISOLATED_STOP, SPE_PROGRAM_LIBRARY_CALL, SPE_PROGRAM_NORMAL_END, SPE_RUN_USER_REGS, spe_stop_info::spe_runtime_error, SPE_RUNTIME_ERROR, spe_stop_info::spe_runtime_exception, SPE_RUNTIME_EXCEPTION, spe_stop_info::spe_runtime_fatal, SPE_RUNTIME_FATAL, spe_stop_info::spe_signal_code, SPE_SPU_HALT, SPE_SPU_INVALID_CHANNEL, SPE_SPU_INVALID_INSTR, SPE_SPU_STOPPED_BY_STOP, SPE_SPU_WAITING_ON_CHANNEL, SPE_STOP_AND_SIGNAL, spe_stop_info::spu_status, spe_context_info::status, spe_stop_info::stop_reason, addr64::ui, and addr64::ull.

Referenced by _event_spe_context_run().

```

101 {
102     int retval = 0, run_rc;
103     unsigned int run_status, tmp_entry;
104     spe_stop_info_t stopinfo_buf;
105     struct spe_context_info this_context_info __attribute__((cleanup(cleanupspeinfo)));
106
107     /* If the caller hasn't set a stopinfo buffer, provide a buffer on the
108      * stack instead. */

```

```

109     if (!stopinfo)
110         stopinfo = &stopinfo_buf;
111
112
113     /* In emulated isolated mode, the npc will always return as zero.
114      * use our private entry point instead */
115     if (spe->base_private->flags & SPE_ISOLATE_EMULATE)
116         tmp_entry = spe->base_private->emulated_entry;
117
118     else if (*entry == SPE_DEFAULT_ENTRY)
119         tmp_entry = spe->base_private->entry;
120     else
121         tmp_entry = *entry;
122
123     /* If we're starting the SPE binary from its original entry point,
124      * setup the arguments to main() */
125     if (tmp_entry == spe->base_private->entry &&
126         !(spe->base_private->flags &
127           (SPE_ISOLATE | SPE_ISOLATE_EMULATE))) {
128
129         addr64 argp64, envp64, tid64, ls64;
130         unsigned int regs[128][4];
131
132         /* setup parameters */
133         argp64.ull = (uint64_t)(unsigned long)argp;
134         envp64.ull = (uint64_t)(unsigned long)envp;
135         tid64.ull = (uint64_t)(unsigned long)spe;
136
137         /* make sure the register values are 0 */
138         memset(regs, 0, sizeof(regs));
139
140         /* set sensible values for stack_ptr and stack_size */
141         regs[1][0] = (unsigned int) LS_SIZE - 16;           /* stack_ptr */
142         regs[2][0] = 0;                                     /* stack_size */
143
144         if (runflags & SPE_RUN_USER_REGS) {
145             /* When SPE_USER_REGS is set, argp points to an array
146              * of 3x128b registers to be passed directly to the SPE
147              * program.
148              */
149             memcpy(regs[3], argp, sizeof(unsigned int) * 12);
150         } else {
151             regs[3][0] = tid64.ui[0];
152             regs[3][1] = tid64.ui[1];
153
154             regs[4][0] = argp64.ui[0];
155             regs[4][1] = argp64.ui[1];
156
157             regs[5][0] = envp64.ui[0];
158             regs[5][1] = envp64.ui[1];
159         }
160
161         /* Store the LS base address in R6 */
162         ls64.ull = (uint64_t)(unsigned long)spe->base_private->mem_mmap_base;
163         regs[6][0] = ls64.ui[0];
164         regs[6][1] = ls64.ui[1];
165
166         if (set_regs(spe, regs))
167             return -1;
168     }
169
170     /*Leave a trail of breadcrumbs for the debugger to follow */
171     if (!__spe_current_active_context) {
172         __spe_current_active_context = &this_context_info;
173         if (!__spe_current_active_context)
174             return -1;
175         __spe_current_active_context->prev = NULL;

```

```

176     } else {
177         struct spe_context_info *newinfo;
178         newinfo = &this_context_info;
179         if (!newinfo)
180             return -1;
181         newinfo->prev = __spe_current_active_context;
182         __spe_current_active_context = newinfo;
183     }
184     /*remember the ls-addr*/
185     __spe_current_active_context->spe_id = spe->base_private->fd_spe_dir;
186
187 do_run:
188     /*Remember the npc value*/
189     __spe_current_active_context->npc = tmp_entry;
190
191     /* run SPE context */
192     run_rc = spu_run(spe->base_private->fd_spe_dir,
193                      &tmp_entry, &run_status);
194
195     /*Remember the npc value*/
196     __spe_current_active_context->npc = tmp_entry;
197     __spe_current_active_context->status = run_status;
198
199     DEBUG_PRINTF("spu_run returned run_rc=0x%08x, entry=0x%04x, "
200                 "ext_status=0x%04x.\n", run_rc, tmp_entry, run_status);
201
202     /* set up return values and stopinfo according to spu_run exit
203      * conditions. This is overwritten on error.
204      */
205     stopinfo->spu_status = run_rc;
206
207     if (spe->base_private->flags & SPE_ISOLATE_EMULATE) {
208         /* save the entry point, and pretend that the npc is zero */
209         spe->base_private->emulated_entry = tmp_entry;
210         *entry = 0;
211     } else {
212         *entry = tmp_entry;
213     }
214
215     /* Return with stopinfo set on syscall error paths */
216     if (run_rc == -1) {
217         DEBUG_PRINTF("spu_run returned error %d, errno=%d\n",
218                     run_rc, errno);
219         stopinfo->stop_reason = SPE_RUNTIME_FATAL;
220         stopinfo->result.spe_runtime_fatal = errno;
221         retval = -1;
222
223         /* For isolated contexts, pass EPERM up to the
224          * caller.
225          */
226         if (!(spe->base_private->flags & SPE_ISOLATE
227               && errno == EPERM))
228             errno = EFAULT;
229
230     } else if (run_rc & SPE_SPU_INVALID_INSTR) {
231         DEBUG_PRINTF("SPU has tried to execute an invalid "
232                     "instruction. %d\n", run_rc);
233         stopinfo->stop_reason = SPE_RUNTIME_ERROR;
234         stopinfo->result.spe_runtime_error = SPE_SPU_INVALID_INSTR;
235         errno = EFAULT;
236         retval = -1;
237
238     } else if ((spe->base_private->flags & SPE_EVENTS_ENABLE) && run_status) {
239         /* Report asynchronous error if return val are set and
240            * SPU events are enabled.
241            */
242         stopinfo->stop_reason = SPE_RUNTIME_EXCEPTION;

```

```

243         stopinfo->result.spe_runtime_exception = run_status;
244         stopinfo->spu_status = -1;
245         errno = EIO;
246         retval = -1;
247
248     } else if ((run_rc & SPE_SPU_STOPPED_BY_STOP) & 0x00ff) {
249         /* Stop & signals are broken down into three groups
250          * 1. SPE library call
251          * 2. SPE user defined stop & signal
252          * 3. SPE program end.
253          *
254          * These groups are signified by the 14-bit stop code:
255          */
256         int stopcode = (run_rc >> 16) & 0x3fff;
257
258         /* Check if this is a library callback, and callbacks are
259          * allowed (ie, running without SPE_NO_CALLBACKS)
260          */
261         if (((stopcode & 0xff00) == SPE_PROGRAM_LIBRARY_CALL
262              && !(runflags & SPE_NO_CALLBACKS))) {
263
264             int callback_rc, callback_number = stopcode & 0xff;
265
266             /* execute library callback */
267             DEBUG_PRINTF("SPE library call: %d\n", callback_number);
268             callback_rc = _base_spe_handle_library_callback(spe,
269                                               callback_number, *entry);
270
271             if (callback_rc) {
272                 /* library callback failed; set errno and
273                  * return immediately */
274                 DEBUG_PRINTF("SPE library call failed: %d\n",
275                             callback_rc);
276                 stopinfo->stop_reason = SPE_CALLBACK_ERROR;
277                 stopinfo->result.spe_callback_error =
278                     callback_rc;
279                 errno = EFAULT;
280                 retval = -1;
281             } else {
282                 /* successful library callback - restart the SPE
283                  * program at the next instruction */
284                 tmp_entry += 4;
285                 goto do_run;
286             }
287
288         } else if ((stopcode & 0xff00) == SPE_PROGRAM_NORMAL_END) {
289             /* The SPE program has exited by exit(X) */
290             stopinfo->stop_reason = SPE_EXIT;
291             stopinfo->result.spe_exit_code = stopcode & 0xff;
292
293             if (spe->base_private->flags & SPE_ISOLATE) {
294                 /* Issue an isolated exit, and re-run the SPE.
295                  * We should see a return value without the
296                  * 0x80 bit set. */
297                 if (!issue_isolated_exit(spe))
298                     goto do_run;
299                 retval = -1;
300             }
301
302         } else if ((stopcode & 0xffff0) == SPE_PROGRAM_ISOLATED_STOP) {
303
304             /* 0x2206: isolated app has been loaded by loader;
305                * provide a hook for the debugger to catch this,
306                * and restart
307                */
308             if (stopcode == SPE_PROGRAM_ISO_LOAD_COMPLETE) {
309                 _base_spe_program_load_complete(spe);


```

```

310             goto do_run;
311         } else {
312             stopinfo->stop_reason = SPE_ISOLATION_ERROR;
313             stopinfo->result.spe_isolation_error =
314                 stopcode & 0xf;
315         }
316     } else if (spe->base_private->flags & SPE_ISOLATE &&
317                 !(run_rc & 0x80)) {
318         /* We've successfully exited isolated mode */
319         retval = 0;
320     } else {
321         /* User defined stop & signal, including
322          * callbacks when disabled */
323         stopinfo->stop_reason = SPE_STOP_AND_SIGNAL;
324         stopinfo->result.spe_signal_code = stopcode;
325         retval = stopcode;
326     }
327 }
328
329 } else if (run_rc & SPE_SPU_HALT) {
330     DEBUG_PRINTF("SPU was stopped by halt. %d\n", run_rc);
331     stopinfo->stop_reason = SPE_RUNTIME_ERROR;
332     stopinfo->result.spe_runtime_error = SPE_SPU_HALT;
333     errno = EFAULT;
334     retval = -1;
335
336 } else if (run_rc & SPE_SPU_WAITING_ON_CHANNEL) {
337     DEBUG_PRINTF("SPU is waiting on channel. %d\n", run_rc);
338     stopinfo->stop_reason = SPE_RUNTIME_EXCEPTION;
339     stopinfo->result.spe_runtime_exception = run_status;
340     stopinfo->spu_status = -1;
341     errno = EIO;
342     retval = -1;
343
344 } else if (run_rc & SPE_SPU_INVALID_CHANNEL) {
345     DEBUG_PRINTF("SPU has tried to access an invalid "
346                  "channel. %d\n", run_rc);
347     stopinfo->stop_reason = SPE_RUNTIME_ERROR;
348     stopinfo->result.spe_runtime_error = SPE_SPU_INVALID_CHANNEL;
349     errno = EFAULT;
350     retval = -1;
351
352 } else {
353     DEBUG_PRINTF("spu_run returned invalid data: 0x%04x\n", run_rc);
354     stopinfo->stop_reason = SPE_RUNTIME_FATAL;
355     stopinfo->result.spe_runtime_fatal = -1;
356     stopinfo->spu_status = -1;
357     errno = EFAULT;
358     retval = -1;
359
360 }
361
362 freespeinfo();
363 return retval;
364
365 }

```

Here is the call graph for this function:



3.21.3 Variable Documentation


3.21.3.1 `_thread struct spe_context_info* __spe_current_active_context`

Referenced by `_base_spe_context_run()`.

3.22 spe_event.c File Reference

```
#include <stdlib.h>
#include "speevent.h"
#include <errno.h>
#include <unistd.h>
#include <sys/epoll.h>
#include <poll.h>
#include <fcntl.h>
```

Include dependency graph for spe_event.c:



Defines

- #define __SPE_EVENT_ALL
- #define __SPE_EPOLL_SIZE 10
- #define __SPE_EPOLL_FD_GET(handler) (*(int*)(handler))
- #define __SPE_EPOLL_FD_SET(handler, fd) (*(int*)(handler) = (fd))
- #define __SPE_EVENT_CONTEXT_PRIV_GET(spe) ((spe_context_event_priv_ptr_t)(spe) → event_private)
- #define __SPE_EVENT_CONTEXT_PRIV_SET(spe, evctx) ((spe) → event_private = (evctx))
- #define __SPE_EVENTS_ENABLED(spe) ((spe) → base_private → flags & SPE_EVENTS_ENABLE)

Functions

- void _event_spe_context_lock (spe_context_ptr_t spe)
- void _event_spe_context_unlock (spe_context_ptr_t spe)
- int _event_spe_stop_info_read (spe_context_ptr_t spe, spe_stop_info_t *stopinfo)
- spe_event_handler_ptr_t _event_spe_event_handler_create (void)
- int _event_spe_event_handler_destroy (spe_event_handler_ptr_t evhandler)
- int _event_spe_event_handler_register (spe_event_handler_ptr_t evhandler, spe_event_unit_t *event)
- int _event_spe_event_handler_deregister (spe_event_handler_ptr_t evhandler, spe_event_unit_t *event)

- int _event_spe_event_wait (spe_event_handler_ptr_t evhandler, spe_event_unit_t *events, int max_events, int timeout)
- int _event_spe_context_finalize (spe_context_ptr_t spe)
- struct spe_context_event_priv * _event_spe_context_initialize (spe_context_ptr_t spe)
- int _event_spe_context_run (spe_context_ptr_t spe, unsigned int *entry, unsigned int runflags, void *argp, void *envp, spe_stop_info_t *stopinfo)

3.22.1 Define Documentation

3.22.1.1 #define __SPE_EPOLL_FD_GET(handler) (*(int*)(handler))

Definition at line 37 of file spe_event.c.

Referenced by _event_spe_event_handler_deregister(), _event_spe_event_handler_destroy(), _event_spe_event_handler_register(), and _event_spe_event_wait().

3.22.1.2 #define __SPE_EPOLL_FD_SET(handler, fd) (*(int*)(handler) = (fd))

Definition at line 38 of file spe_event.c.

Referenced by _event_spe_event_handler_create().

3.22.1.3 #define __SPE_EPOLL_SIZE 10

Definition at line 35 of file spe_event.c.

Referenced by _event_spe_event_handler_create().

3.22.1.4 #define __SPE_EVENT_ALL

Value:

```
( SPE_EVENT_OUT_INTR_MBOX | SPE_EVENT_IN_MBOX | \
    SPE_EVENT_TAG_GROUP | SPE_EVENT_SPE_STOPPED )
```

Definition at line 31 of file spe_event.c.

Referenced by _event_spe_event_handler_deregister(), and _event_spe_event_handler_register().

3.22.1.5 #define __SPE_EVENT_CONTEXT_PRIV_GET(spe) ((spe_context_event_priv_ptr_t)(spe) → event_private)

Definition at line 40 of file spe_event.c.

Referenced by _event_spe_context_finalize(), _event_spe_context_lock(), _event_spe_context_run(), _event_spe_context_unlock(), _event_spe_event_handler_deregister(), _event_spe_event_handler_register(), and _event_spe_stop_info_read().

3.22.1.6 #define __SPE_EVENT_CONTEXT_PRIV_SET(spe, evctx) ((spe) → event_private = (evctx))

Definition at line 42 of file spe_event.c.

Referenced by `_event_spe_context_finalize()`.

3.22.1.7 #define __SPE_EVENTS_ENABLED(spe) ((spe) → base_private → flags & SPE_EVENTS_ENABLE)

Definition at line 45 of file `spe_event.c`.

Referenced by `_event_spe_event_handler_deregister()`, and `_event_spe_event_handler_register()`.

3.22.2 Function Documentation

3.22.2.1 int _event_spe_context_finalize (spe_context_ptr_t spe)

Definition at line 416 of file `spe_event.c`.

References `__SPE_EVENT_CONTEXT_PRIV_GET`, `__SPE_EVENT_CONTEXT_PRIV_SET`, `spe_context_event_priv::lock`, `spe_context_event_priv::stop_event_pipe`, and `spe_context_event_priv::stop_event_read_lock`.

```
417 {
418     spe_context_event_priv_ptr_t evctx;
419
420     if (!spe) {
421         errno = ESRCH;
422         return -1;
423     }
424
425     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(spe);
426     __SPE_EVENT_CONTEXT_PRIV_SET(spe, NULL);
427
428     close(evctx->stop_event_pipe[0]);
429     close(evctx->stop_event_pipe[1]);
430
431     pthread_mutex_destroy(&evctx->lock);
432     pthread_mutex_destroy(&evctx->stop_event_read_lock);
433
434     free(evctx);
435
436     return 0;
437 }
```

3.22.2.2 struct spe_context_event_priv* _event_spe_context_initialize (spe_context_ptr_t spe) [read]

Definition at line 439 of file `spe_event.c`.

References `spe_context_event_priv::events`, `spe_context_event_priv::lock`, `spe_event_unit::spe`, `spe_context_event_priv::stop_event_pipe`, and `spe_context_event_priv::stop_event_read_lock`.

```
440 {
441     spe_context_event_priv_ptr_t evctx;
442     int rc;
443     int i;
444
445     evctx = calloc(1, sizeof(*evctx));
446     if (!evctx) {
447         return NULL;
448     }
```

```

449
450     rc = pipe(evctx->stop_event_pipe);
451     if (rc == -1) {
452         free(evctx);
453         return NULL;
454     }
455     rc = fcntl(evctx->stop_event_pipe[0], F_GETFL);
456     if (rc != -1) {
457         rc = fcntl(evctx->stop_event_pipe[0], F_SETFL, rc | O_NONBLOCK);
458     }
459     if (rc == -1) {
460         close(evctx->stop_event_pipe[0]);
461         close(evctx->stop_event_pipe[1]);
462         free(evctx);
463         errno = EIO;
464         return NULL;
465     }
466
467     for (i = 0; i < sizeof(evctx->events) / sizeof(evctx->events[0]); i++) {
468         evctx->events[i].spe = spe;
469     }
470
471     pthread_mutex_init(&evctx->lock, NULL);
472     pthread_mutex_init(&evctx->stop_event_read_lock, NULL);
473
474     return evctx;
475 }
```

3.22.2.3 void _event_spe_context_lock (spe_context_ptr_t spe)

Definition at line 49 of file spe_event.c.

References __SPE_EVENT_CONTEXT_PRIV_GET.

Referenced by _event_spe_event_handler_deregister(), _event_spe_event_handler_register(), and _event_spe_event_wait().

```

50 {
51     pthread_mutex_lock(&__SPE_EVENT_CONTEXT_PRIV_GET(spe)->lock);
52 }
```

3.22.2.4 int _event_spe_context_run (spe_context_ptr_t spe, unsigned int * entry, unsigned int runflags, void * argp, void * envp, spe_stop_info_t * stopinfo)

Definition at line 477 of file spe_event.c.

References __SPE_EVENT_CONTEXT_PRIV_GET, _base_spe_context_run(), and spe_context_event_priv::stop_event_pipe.


```

478 {
479     spe_context_event_priv_ptr_t evctx;
480     spe_stop_info_t stopinfo_buf;
481     int rc;
482
483     if (!stopinfo) {
484         stopinfo = &stopinfo_buf;
485     }
486     rc = _base_spe_context_run(spe, entry, runflags, argp, envp, stopinfo);
487
488     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(spe);
```

```

489     if (write(evctx->stop_event_pipe[1], stopinfo, sizeof(*stopinfo)) != sizeof(*stopinfo)) {
490         /* error check. */
491     }
492
493     return rc;
494 }
```

Here is the call graph for this function:



3.22.2.5 void _event_spe_context_unlock (spe_context_ptr_t spe)

Definition at line 54 of file spe_event.c.

References `__SPE_EVENT_CONTEXT_PRIV_GET`.

Referenced by `_event_spe_event_handler_deregister()`, `_event_spe_event_handler_register()`, and `_event_spe_event_wait()`.

```

55 {
56     pthread_mutex_unlock(&__SPE_EVENT_CONTEXT_PRIV_GET(spe)->lock);
57 }
```

3.22.2.6 spe_event_handler_ptr_t _event_spe_event_handler_create (void)

Definition at line 110 of file spe_event.c.

References `__SPE_EPOLL_FD_SET`, and `__SPE_EPOLL_SIZE`.

```

111 {
112     int epfd;
113     spe_event_handler_t *evhandler;
114
115     evhandler = calloc(1, sizeof(*evhandler));
116     if (!evhandler) {
117         return NULL;
118     }
119
120     epfd = epoll_create(__SPE_EPOLL_SIZE);
121     if (epfd == -1) {
122         free(evhandler);
123         return NULL;
124     }
125
126     __SPE_EPOLL_FD_SET(evhandler, epfd);
127
128     return evhandler;
129 }
```

3.22.2.7 int _event_spe_event_handler_deregister (spe_event_handler_ptr_t evhandler, spe_event_unit_t * event)

Definition at line 273 of file spe_event.c.

References __base_spe_event_source_acquire(), __SPE_EPOLL_FD_GET, __SPE_EVENT_ALL, __SPE_EVENT_CONTEXT_PRIV_GET, __SPE_EVENT_IN_MBOX, __SPE_EVENT_OUT_INTR_MBOX, __SPE_EVENT_SPE_STOPPED, __SPE_EVENT_TAG_GROUP, __SPE_EVENTS_ENABLED, _event_spe_context_lock(), _event_spe_context_unlock(), spe_context_event_priv::events, spe_event_unit::events, FD_IBOX, FD_MFC, FD_WBOX, spe_event_unit::spe, SPE_EVENT_IN_MBOX, SPE_EVENT_OUT_INTR_MBOX, SPE_EVENT_SPE_STOPPED, SPE_EVENT_TAG_GROUP, and spe_context_event_priv::stop_event_pipe.

```


274 {
275     int epfd;
276     const int ep_op = EPOLL_CTL_DEL;
277     spe_context_event_priv_ptr_t evctx;
278     int fd;
279
280     if (!evhandler) {
281         errno = ESRCH;
282         return -1;
283     }
284     if (!event || !event->spe) {
285         errno = EINVAL;
286         return -1;
287     }
288     if (!__SPE_EVENTS_ENABLED(event->spe)) {
289         errno = ENOTSUP;
290         return -1;
291     }
292
293     epfd = __SPE_EPOLL_FD_GET(evhandler);
294     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(event->spe);
295
296     if (event->events & ~__SPE_EVENT_ALL) {
297         errno = ENOTSUP;
298         return -1;
299     }
300
301     _event_spe_context_lock(event->spe); /* for spe->event_private->events */
302
303     if (event->events & SPE_EVENT_OUT_INTR_MBOX) {
304         fd = __base_spe_event_source_acquire(event->spe, FD_IBOX);
305         if (fd == -1) {
306             _event_spe_context_unlock(event->spe);
307             return -1;
308         }
309         if (epoll_ctl(epfd, ep_op, fd, NULL) == -1) {
310             _event_spe_context_unlock(event->spe);
311             return -1;
312         }
313         evctx->events[__SPE_EVENT_OUT_INTR_MBOX].events = 0;
314     }
315
316     if (event->events & SPE_EVENT_IN_MBOX) {
317         fd = __base_spe_event_source_acquire(event->spe, FD_WBOX);
318         if (fd == -1) {
319             _event_spe_context_unlock(event->spe);
320             return -1;
321         }
322         if (epoll_ctl(epfd, ep_op, fd, NULL) == -1) {
323             _event_spe_context_unlock(event->spe);
324             return -1;
325         }
326         evctx->events[__SPE_EVENT_IN_MBOX].events = 0;
327     }
328
329     if (event->events & SPE_EVENT_TAG_GROUP) {
330         fd = __base_spe_event_source_acquire(event->spe, FD_MFC);
331         if (fd == -1) {

```

```

332     _event_spe_context_unlock(event->spe);
333     return -1;
334 }
335 if (epoll_ctl(epfd, EP_OP, fd, NULL) == -1) {
336     _event_spe_context_unlock(event->spe);
337     return -1;
338 }
339 evctx->events[__SPE_EVENT_TAG_GROUP].events = 0;
340 }
341
342 if (event->events & SPE_EVENT_SPE_STOPPED) {
343     fd = evctx->stop_event_pipe[0];
344     if (epoll_ctl(epfd, EP_OP, fd, NULL) == -1) {
345         _event_spe_context_unlock(event->spe);
346         return -1;
347     }
348     evctx->events[__SPE_EVENT_SPE_STOPPED].events = 0;
349 }
350
351 _event_spe_context_unlock(event->spe);
352
353 return 0;
354 }
```

Here is the call graph for this function:



3.22.2.8 int _event_spe_event_handler_destroy (spe_event_handler_ptr_t evhandler)

Definition at line 135 of file spe_event.c.

References __SPE_EPOLL_FD_GET.

```

136 {
137     int epfd;
138
139     if (!evhandler) {
140         errno = ESRCH;
141         return -1;
142     }
143
144     epfd = __SPE_EPOLL_FD_GET(evhandler);
145     close(epfd);
146
147     free(evhandler);
148
149 }
```

3.22.2.9 int _event_spe_event_handler_register (spe_event_handler_ptr_t evhandler, spe_event_unit_t * event)

Definition at line 155 of file spe_event.c.

References __base_spe_event_source_acquire(), __SPE_EPOLL_FD_GET, __SPE_EVENT_ALL, __SPE_EVENT_CONTEXT_PRIV_GET, __SPE_EVENT_IN_MBOX, __SPE_EVENT_OUT_INTR_MBOX, __SPE_EVENT_SPE_STOPPED, __SPE_EVENT_TAG_GROUP, __SPE_EVENTS_ENABLED, _event_spe_context_lock(), _event_spe_context_unlock(), spe_context::base_private, spe_event_unit::data, spe_context_event_priv::events, spe_event_unit::events, FD_IBOX, FD_MFC, FD_WBOX, spe_context_base_priv::flags, spe_event_data::ptr, spe_event_unit::spe, SPE_EVENT_IN_MBOX, SPE_EVENT_OUT_INTR_MBOX, SPE_EVENT_SPE_STOPPED, SPE_EVENT_TAG_GROUP, SPE_MAP_PS, and spe_context_event_priv::stop_event_pipe.


```

156 {
157     int epfd;
158     const int ep_op = EPOLL_CTL_ADD;
159     spe_context_event_priv_ptr_t evctx;
160     spe_event_unit_t *ev_buf;
161     struct epoll_event ep_event;
162     int fd;
163
164     if (!evhandler) {
165         errno = ESRCH;
166         return -1;
167     }
168     if (!event || !event->spe) {
169         errno = EINVAL;
170         return -1;
171     }
172     if (!__SPE_EVENTS_ENABLED(event->spe)) {
173         errno = ENOTSUP;
174         return -1;
175     }
176
177     epfd = __SPE_EPOLL_FD_GET(evhandler);
178     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(event->spe);
179
180     if (event->events & ~__SPE_EVENT_ALL) {
181         errno = ENOTSUP;
182         return -1;
183     }
184
185     _event_spe_context_lock(event->spe); /* for spe->event_private->events */
186
187     if (event->events & SPE_EVENT_OUT_INTR_MBOX) {
188         fd = __base_spe_event_source_acquire(event->spe, FD_IBOX);
189         if (fd == -1) {
190             _event_spe_context_unlock(event->spe);
191             return -1;
192         }
193
194         ev_buf = &evctx->events[__SPE_EVENT_OUT_INTR_MBOX];
195         ev_buf->events = SPE_EVENT_OUT_INTR_MBOX;
196         ev_buf->data = event->data;
197
198         ep_event.events = EPOLLIN;
199         ep_event.data.ptr = ev_buf;
200         if (epoll_ctl(epfd, ep_op, fd, &ep_event) == -1) {
201             _event_spe_context_unlock(event->spe);
202             return -1;
203         }
204     }
205
206     if (event->events & SPE_EVENT_IN_MBOX) {
207         fd = __base_spe_event_source_acquire(event->spe, FD_WBOX);
208         if (fd == -1) {
209             _event_spe_context_unlock(event->spe);
210             return -1;
211         }

```

```
212     ev_buf = &evctx->events[__SPE_EVENT_IN_MBOX];
213     ev_buf->events = SPE_EVENT_IN_MBOX;
214     ev_buf->data = event->data;
215
216     ep_event.events = EPOLLOUT;
217     ep_event.data.ptr = ev_buf;
218     if (epoll_ctl(epfd, EPOLLIN, fd, &ep_event) == -1) {
219         _event_spe_context_unlock(event->spe);
220         return -1;
221     }
222 }
223
224
225 if (event->events & SPE_EVENT_TAG_GROUP) {
226     fd = __base_spe_event_source_acquire(event->spe, FD_MFC);
227     if (fd == -1) {
228         _event_spe_context_unlock(event->spe);
229         return -1;
230     }
231
232     if (event->spe->base_private->flags & SPE_MAP_PS) {
233         _event_spe_context_unlock(event->spe);
234         errno = ENOTSUP;
235         return -1;
236     }
237
238     ev_buf = &evctx->events[__SPE_EVENT_TAG_GROUP];
239     ev_buf->events = SPE_EVENT_TAG_GROUP;
240     ev_buf->data = event->data;
241
242     ep_event.events = EPOLLIN;
243     ep_event.data.ptr = ev_buf;
244     if (epoll_ctl(epfd, EPOLLIN, fd, &ep_event) == -1) {
245         _event_spe_context_unlock(event->spe);
246         return -1;
247     }
248 }
249
250 if (event->events & SPE_EVENT_SPE_STOPPED) {
251     fd = evctx->stop_event_pipe[0];
252
253     ev_buf = &evctx->events[__SPE_EVENT_SPE_STOPPED];
254     ev_buf->events = SPE_EVENT_SPE_STOPPED;
255     ev_buf->data = event->data;
256
257     ep_event.events = EPOLLIN;
258     ep_event.data.ptr = ev_buf;
259     if (epoll_ctl(epfd, EPOLLIN, fd, &ep_event) == -1) {
260         _event_spe_context_unlock(event->spe);
261         return -1;
262     }
263 }
264
265 _event_spe_context_unlock(event->spe);
266
267 return 0;
268 }
```

Here is the call graph for this function:



3.22.2.10 int _event_spe_event_wait (spe_event_handler_ptr_t evhandler, spe_event_unit_t *events, int max_events, int timeout)

Definition at line 360 of file spe_event.c.

References `__SPE_EPOLL_FD_GET`, `_event_spe_context_lock()`, `_event_spe_context_unlock()`, and `spe_event_unit::spe`.


```

361 {
362     int epfd;
363     struct epoll_event *ep_events;
364     int rc;
365
366     if (!evhandler) {
367         errno = ESRCH;
368         return -1;
369     }
370     if (!events || max_events <= 0) {
371         errno = EINVAL;
372         return -1;
373     }
374
375     epfd = __SPE_EPOLL_FD_GET(evhandler);
376
377     ep_events = malloc(sizeof(*ep_events) * max_events);
378     if (!ep_events) {
379         return -1;
380     }
381
382     for ( ; ; ) {
383         rc = epoll_wait(epfd, ep_events, max_events, timeout);
384         if (rc == -1) { /* error */
385             if (errno == EINTR) {
386                 if (timeout >= 0) { /* behave as timeout */
387                     rc = 0;
388                     break;
389                 }
390             /* else retry */
391         }
392         else {
393             break;
394         }
395     }
396     else if (rc > 0) {
397         int i;
398         for (i = 0; i < rc; i++) {
399             spe_event_unit_t *ev = (spe_event_unit_t *) (ep_events[i].data.ptr);
400             _event_spe_context_lock(ev->spe); /* lock ev itself */
401             events[i] = *ev;
402             _event_spe_context_unlock(ev->spe);
403         }
404         break;
  
```

```

405      }
406      else /* timeout */
407          break;
408      }
409  }
410
411  free(ep_events);
412
413  return rc;
414 }
```

Here is the call graph for this function:



3.22.2.11 int _event_spe_stop_info_read (spe_context_ptr_t spe, spe_stop_info_t *stopinfo)

Definition at line 59 of file spe_event.c.

References __SPE_EVENT_CONTEXT_PRIV_GET, spe_context_event_priv::stop_event_pipe, and spe_context_event_priv::stop_event_read_lock.

```


60 {
61     spe_context_event_priv_ptr_t evctx;
62     int rc;
63     int fd;
64     size_t total;
65
66     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(spe);
67     fd = evctx->stop_event_pipe[0];
68
69     pthread_mutex_lock(&evctx->stop_event_read_lock); /* for atomic read */
70
71     rc = read(fd, stopinfo, sizeof(*stopinfo));
72     if (rc == -1) {
73         pthread_mutex_unlock(&evctx->stop_event_read_lock);
74         return -1;
75     }
76
77     total = rc;
78     while (total < sizeof(*stopinfo)) { /* this loop will be executed in few cases */
79         struct pollfd fds;
80         fds.fd = fd;
81         fds.events = POLLIN;
82         rc = poll(&fds, 1, -1);
83         if (rc == -1) {
84             if (errno != EINTR) {
85                 break;
86             }
87         }
88         else if (rc == 1) {
89             rc = read(fd, (char *)stopinfo + total, sizeof(*stopinfo) - total);
90             if (rc == -1) {
91                 if (errno != EAGAIN) {
92                     break;
93                 }
94             }
95         }
96         total += rc;
```

```
97      }
98  }
99 }
100 pthread_mutex_unlock(&evctx->stop_event_read_lock);
102
103 return rc == -1 ? -1 : 0;
104 }
```


3.23 spebase.h File Reference

```
#include <pthread.h>
#include "libspe2-types.h"
```

Include dependency graph for spebase.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [spe_context_base_priv](#)
- struct [spe_gang_context_base_priv](#)

Defines

- #define [_PRINTF](#)(fmt, args...) { fprintf(stderr,fmt , ## args); }
- #define [DEBUG_PRINTF](#)(fmt, args...)
- #define [LS_SIZE](#) 0x40000
- #define [PSMAP_SIZE](#) 0x20000
- #define [MFC_SIZE](#) 0x1000
- #define [MSS_SIZE](#) 0x1000
- #define [CNTL_SIZE](#) 0x1000
- #define [SIGNAL_SIZE](#) 0x1000
- #define [MSSYNC_OFFSET](#) 0x000000
- #define [MFC_OFFSET](#) 0x03000
- #define [CNTL_OFFSET](#) 0x04000
- #define [SIGNAL1_OFFSET](#) 0x14000
- #define [SIGNAL2_OFFSET](#) 0x1c000
- #define [SPE_EMULATE_PARAM_BUFFER](#) 0x3e000
- #define [SPE_PROGRAM_NORMAL_END](#) 0x2000
- #define [SPE_PROGRAM_LIBRARY_CALL](#) 0x2100
- #define [SPE_PROGRAM_ISOLATED_STOP](#) 0x2200
- #define [SPE_PROGRAM_ISO_LOAD_COMPLETE](#) 0x2206

Enumerations

- enum fd_name {

FD_MBOX, FD_MBOX_STAT, FD_IBOX, FD_IBOX_NB,

FD_IBOX_STAT, FD_WBOX, FD_WBOX_NB, FD_WBOX_STAT,

FD_SIG1, FD_SIG2, FD_MFC, FD_MSS,

NUM_MBOX_FDS }

Functions

- `spe_context_ptr_t _base_spe_context_create` (unsigned int flags, `spe_gang_context_ptr_t` gctx, `spe_context_ptr_t` aff_spe)
- `spe_gang_context_ptr_t _base_spe_gang_context_create` (unsigned int flags)
- `int _base_spe_program_load` (`spe_context_ptr_t` spectx, `spe_program_handle_t` *program)
- `void _base_spe_program_load_complete` (`spe_context_ptr_t` spectx)
- `int _base_spe_emulated_loader_present` (void)
- `int _base_spe_context_destroy` (`spe_context_ptr_t` spectx)
- `int _base_spe_gang_context_destroy` (`spe_gang_context_ptr_t` gctx)
- `int _base_spe_context_run` (`spe_context_ptr_t` spe, unsigned int *entry, unsigned int runflags, void *argp, void *envp, `spe_stop_info_t` *stopinfo)
- `int _base_spe_image_close` (`spe_program_handle_t` *handle)
- `spe_program_handle_t * _base_spe_image_open` (const char *filename)
- `int _base_spe_mfcio_put` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- `int _base_spe_mfcio_putb` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- `int _base_spe_mfcio_putf` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- `int _base_spe_mfcio_get` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- `int _base_spe_mfcio_getb` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- `int _base_spe_mfcio_getf` (`spe_context_ptr_t` spectx, unsigned int ls, void *ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)
- `int _base_spe_out_mbox_read` (`spe_context_ptr_t` spectx, unsigned int mbox_data[], int count)
- `int _base_spe_in_mbox_write` (`spe_context_ptr_t` spectx, unsigned int mbox_data[], int count, int behavior_flag)
- `int _base_spe_in_mbox_status` (`spe_context_ptr_t` spectx)
- `int _base_spe_out_mbox_status` (`spe_context_ptr_t` spectx)
- `int _base_spe_out_intr_mbox_status` (`spe_context_ptr_t` spectx)
- `int _base_spe_out_intr_mbox_read` (`spe_context_ptr_t` spectx, unsigned int mbox_data[], int count, int behavior_flag)
- `int _base_spe_signal_write` (`spe_context_ptr_t` spectx, unsigned int signal_reg, unsigned int data)
- `int _base_spe_callback_handler_register` (void *handler, unsigned int callnum, unsigned int mode)
- `int _base_spe_callback_handler_deregister` (unsigned int callnum)
- `void * _base_spe_callback_handler_query` (unsigned int callnum)
- `int _base_spe_stop_reason_get` (`spe_context_ptr_t` spectx)
- `int _base_spe_mfcio_tag_status_read` (`spe_context_ptr_t` spectx, unsigned int mask, unsigned int behavior, unsigned int *tag_status)
- `int _base_spe_stop_event_source_get` (`spe_context_ptr_t` spectx)

- int __base_spe_stop_event_target_get (spe_context_ptr_t spectx)
- int __base_spe_stop_status_get (spe_context_ptr_t spectx)
- int __base_spe_event_source_acquire (struct spe_context *spectx, enum fd_name fdesc)
- void __base_spe_event_source_release (struct spe_context *spectx, enum fd_name fdesc)
- void * __base_spe_ps_area_get (struct spe_context *spectx, enum ps_area area)
- int __base_spe_spe_dir_get (struct spe_context *spectx)
- void * __base_spe_ls_area_get (struct spe_context *spectx)
- int __base_spe_ls_size_get (spe_context_ptr_t spe)
- void __base_spe_context_lock (spe_context_ptr_t spe, enum fd_name fd)
- void __base_spe_context_unlock (spe_context_ptr_t spe, enum fd_name fd)
- int __base_spe_cpu_info_get (int info_requested, int cpu_node)
- void __spe_context_update_event (void)
- int __base_spe_mssync_start (spe_context_ptr_t spectx)
- int __base_spe_mssync_status (spe_context_ptr_t spectx)

3.23.1 Detailed Description

[spebase.h](#) contains the public API funtions

Definition in file [spebase.h](#).

3.23.2 Define Documentation

3.23.2.1 #define __PRINTF(fmt, args...) { fprintf(stderr,fmt ,## args); }

Definition at line 34 of file [spebase.h](#).

3.23.2.2 #define CNTL_OFFSET 0x04000

Definition at line 124 of file [spebase.h](#).

Referenced by [_base_spe_context_create\(\)](#).

3.23.2.3 #define CNTL_SIZE 0x1000

Definition at line 119 of file [spebase.h](#).

Referenced by [_base_spe_context_create\(\)](#).

3.23.2.4 #define DEBUG_PRINTF(fmt, args...)

Definition at line 38 of file [spebase.h](#).

3.23.2.5 #define LS_SIZE 0x40000

Definition at line 115 of file [spebase.h](#).

3.23.2.6 #define MFC_OFFSET 0x03000

Definition at line 123 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.7 #define MFC_SIZE 0x1000

Definition at line 117 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.8 #define MSS_SIZE 0x1000

Definition at line 118 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.9 #define MSSYNC_OFFSET 0x00000

Definition at line 122 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.10 #define PSMAP_SIZE 0x20000

Definition at line 116 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.11 #define SIGNAL1_OFFSET 0x14000

Definition at line 125 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.12 #define SIGNAL2_OFFSET 0x1c000

Definition at line 126 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.13 #define SIGNAL_SIZE 0x1000

Definition at line 120 of file spebase.h.

Referenced by _base_spe_context_create().

3.23.2.14 #define SPE_EMULATE_PARAM_BUFFER 0x3e000

Location of the PPE-assisted library call buffer for emulated isolation contexts.

Definition at line 132 of file spebase.h.

Referenced by `_base_spe_handle_library_callback()`.

3.23.2.15 #define SPE_PROGRAM_ISO_LOAD_COMPLETE 0x2206

Definition at line 143 of file spebase.h.

Referenced by `_base_spe_context_run()`.

3.23.2.16 #define SPE_PROGRAM_ISOLATED_STOP 0x2200

Isolated exit codes: 0x220x

Definition at line 142 of file spebase.h.

Referenced by `_base_spe_context_run()`.

3.23.2.17 #define SPE_PROGRAM_LIBRARY_CALL 0x2100

Definition at line 137 of file spebase.h.

Referenced by `_base_spe_context_run()`.

3.23.2.18 #define SPE_PROGRAM_NORMAL_END 0x2000

Definition at line 136 of file spebase.h.

Referenced by `_base_spe_context_run()`.

3.23.3 Enumeration Type Documentation

3.23.3.1 enum fd_name

NOTE: NUM_MBOX_FDS must always be the last element in the enumeration

Enumerator:

FD_MBOX
FD_MBOX_STAT
FD_IBOX
FD_IBOX_NB
FD_IBOX_STAT
FD_WBOX
FD_WBOX_NB
FD_WBOX_STAT
FD_SIG1
FD_SIG2
FD_MFC
FD_MSS
NUM_MBOX_FDS

Definition at line 42 of file spebase.h.

```

42      {
43      FD_MBOX,
44      FD_MBOX_STAT,
45      FD_IBOX,
46      FD_IBOX_NB,
47      FD_IBOX_STAT,
48      FD_WBOX,
49      FD_WBOX_NB,
50      FD_WBOX_STAT,
51      FD_SIG1,
52      FD_SIG2,
53      FD_MFC,
54      FD_MSS,
55      NUM_MBOX_FDS
56 };
```

3.23.4 Function Documentation

3.23.4.1 int __base_spe_event_source_acquire (struct spe_context * *spectx*, enum fd_name *fdesc*)

__base_spe_event_source_acquire opens a file descriptor to the specified event source

Parameters:

spectx Specifies the SPE context

fdesc Specifies the event source

3.23.4.2 void __base_spe_event_source_release (struct spe_context * *spectx*, enum fd_name *fdesc*)

__base_spe_event_source_release releases the file descriptor to the specified event source

Parameters:

spectx Specifies the SPE context

fdesc Specifies the event source


Definition at line 79 of file accessors.c.

References *_base_spe_close_if_open()*.

```

80 {
81     __base_spe_close_if_open(spe, fdesc);
82 }
```

Here is the call graph for this function:



3.23.4.3 int __base_spe_spe_dir_get (struct spe_context * *spectx*)

`__base_spe_spe_dir_get` return the file descriptor of the SPE directory in spufs

Parameters:

spectx Specifies the SPE context

3.23.4.4 int __base_spe_stop_event_source_get (spe_context_ptr_t *spe*)

`__base_spe_stop_event_source_get`

Parameters:

spectx Specifies the SPE context

speevent users read from this end

Definition at line 92 of file accessors.c.

References `spe_context::base_private`, and `spe_context_base_priv::ev_pipe`.

```
93 {
94     return spe->base_private->ev_pipe[1];
95 }
```

3.23.4.5 int __base_spe_stop_event_target_get (spe_context_ptr_t *spe*)

`__base_spe_stop_event_target_get`

Parameters:

spectx Specifies the SPE context

speevent writes to this end

Definition at line 100 of file accessors.c.

References `spe_context::base_private`, and `spe_context_base_priv::ev_pipe`.

```
101 {
102     return spe->base_private->ev_pipe[0];
103 }
```

3.23.4.6 void __spe_context_update_event (void)

`__spe_context_update_event` internal function for gdb notification.

Referenced by `_base_spe_context_destroy()`, and `_base_spe_program_load_complete()`.

3.23.4.7 int _base_spe_callback_handler_deregister (unsigned int *callnum*)

unregister a handler function for the specified number NOTE: unregistering a handler from call zero and one is ignored.

Definition at line 78 of file lib_builtin.c.

References MAX_CALLNUM, and RESERVED.

```

79 {
80     errno = 0;
81     if (callnum > MAX_CALLNUM) {
82         errno = EINVAL;
83         return -1;
84     }
85     if (callnum < RESERVED) {
86         errno = EACCES;
87         return -1;
88     }
89     if (handlers[callnum] == NULL) {
90         errno = ESRCH;
91         return -1;
92     }
93     handlers[callnum] = NULL;
94     return 0;
95 }
96 }
```

3.23.4.8 void* _base_spe_callback_handler_query (unsigned int *callnum*)

query a handler function for the specified number

Definition at line 98 of file lib_builtin.c.

References MAX_CALLNUM.

```

99 {
100     errno = 0;
101
102     if (callnum > MAX_CALLNUM) {
103         errno = EINVAL;
104         return NULL;
105     }
106     if (handlers[callnum] == NULL) {
107         errno = ESRCH;
108         return NULL;
109     }
110     return handlers[callnum];
111 }
```

3.23.4.9 int _base_spe_callback_handler_register (void * *handler*, unsigned int *callnum*, unsigned int *mode*)

register a handler function for the specified number NOTE: registering a handler to call zero and one is ignored.

Definition at line 40 of file lib_builtin.c.

References MAX_CALLNUM, RESERVED, SPE_CALLBACK_NEW, and SPE_CALLBACK_UPDATE.

```

41 {
42     errno = 0;
43
44     if (callnum > MAX_CALLNUM) {
45         errno = EINVAL;
46         return -1;
47     }
48
49     switch(mode) {
50     case SPE_CALLBACK_NEW:
51         if (callnum < RESERVED) {
52             errno = EACCES;
53             return -1;
54         }
55         if (handlers[callnum] != NULL) {
56             errno = EACCES;
57             return -1;
58         }
59         handlers[callnum] = handler;
60         break;
61
62     case SPE_CALLBACK_UPDATE:
63         if (handlers[callnum] == NULL) {
64             errno = ESRCH;
65             return -1;
66         }
67         handlers[callnum] = handler;
68         break;
69     default:
70         errno = EINVAL;
71         return -1;
72         break;
73     }
74     return 0;
75
76 }

```

3.23.4.10 `_base_spe_context_create(unsigned int flags, spe_gang_context_ptr_t gctx, spe_context_ptr_t aff_spe)`

`_base_spe_context_create` creates a single SPE context, i.e., the corresponding directory is created in SPUFS either as a subdirectory of a gang or individually (maybe this is best considered a gang of one)

Parameters:

flags

gctx specify NULL if not belonging to a gang

aff_spe specify NULL to skip affinity information

Definition at line 183 of file create.c.

References `_base_spe_emulated_loader_present()`, `spe_gang_context::base_private`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `CNTL_OFFSET`, `CNTL_SIZE`, `DEBUG_PRINTF`, `spe_context_base_priv::fd_lock`, `spe_context_base_priv::fd_spe_dir`, `spe_context_base_priv::flags`, `spe_gang_context_base_priv::gangname`, `spe_context_base_priv::loaded_program`, `LS_SIZE`, `spe_context_base_priv::mem_mmap_base`, `spe_context_base_priv::mfc_mmap_base`, `MFC_OFFSET`, `MFC_SIZE`, `MSS_SIZE`, `spe_context_base_priv::mssync_mmap_base`, `MSSYNC_OFFSET`, `spe_context_base_priv::psmap_mmap_base`, `PSMAP_SIZE`, `spe_context_base_priv::signal1_mmap_base`, `SIGNAL1_OFFSET`, `spe_context_base_priv::signal2_mmap_base`, `SIGNAL2_OFFSET`, `SIGNAL_SIZE`, `SPE_AFFINITY_MEMORY`, `SPE_CFG_SIGNIFY1_OR`, `SPE_CFG_SIGNIFY2_OR`,

SPE_EVENTS_ENABLE, spe_context_base_priv::spe_fds_array, SPE_ISOLATE, SPE_ISOLATE_EMULATE, and SPE_MAP_PS.

```

185 {
186     char pathname[256];
187     int i, aff_spe_fd = 0;
188     unsigned int spu_createflags = 0;
189     struct spe_context *spe = NULL;
190     struct spe_context_base_priv *priv;
191
192     /* We need a loader present to run in emulated isolated mode */
193     if (flags & SPE_ISOLATE_EMULATE
194         && !_base_spe_emulated_loader_present()) {
195         errno = EINVAL;
196         return NULL;
197     }
198
199     /* Put some sane defaults into the SPE context */
200     spe = malloc(sizeof(*spe));
201     if (!spe) {
202         DEBUG_PRINTF("ERROR: Could not allocate spe context.\n");
203         return NULL;
204     }
205     memset(spe, 0, sizeof(*spe));
206
207     spe->base_private = malloc(sizeof(*spe->base_private));
208     if (!spe->base_private) {
209         DEBUG_PRINTF("ERROR: Could not allocate "
210                     "spe->base_private context.\n");
211         free(spe);
212         return NULL;
213     }
214
215     /* just a convenience variable */
216     priv = spe->base_private;
217
218     priv->fd_spe_dir = -1;
219     priv->mem_mmap_base = MAP_FAILED;
220     priv->psmap_mmap_base = MAP_FAILED;
221     priv->mssync_mmap_base = MAP_FAILED;
222     priv->mfc_mmap_base = MAP_FAILED;
223     priv->cntl_mmap_base = MAP_FAILED;
224     priv->signal1_mmap_base = MAP_FAILED;
225     priv->signal2_mmap_base = MAP_FAILED;
226     priv->loaded_program = NULL;
227
228     for (i = 0; i < NUM_MBOX_FDS; i++) {
229         priv->spe_fds_array[i] = -1;
230         pthread_mutex_init(&priv->fd_lock[i], NULL);
231     }
232
233     /* initialise spu_createflags */
234     if (flags & SPE_ISOLATE) {
235         flags |= SPE_MAP_PS;
236         spu_createflags |= SPU_CREATE_ISOLATE | SPU_CREATE_NOSCHED;
237     }
238
239     if (flags & SPE_EVENTS_ENABLE)
240         spu_createflags |= SPU_CREATE_EVENTS_ENABLED;
241
242     if (aff_spe)
243         spu_createflags |= SPU_CREATE_AFFINITY_SPU;
244
245     if (flags & SPE_AFFINITY_MEMORY)
246         spu_createflags |= SPU_CREATE_AFFINITY_MEM;
247
248     /* Make the SPUFS directory for the SPE */

```

```

249     if (gctx == NULL)
250         sprintf(pathname, "/spu/sputhread-%i-%lu",
251                 getpid(), (unsigned long)spe);
252     else
253         sprintf(pathname, "/spu/%s/sputhread-%i-%lu",
254                 gctx->base_private->gangname, getpid(),
255                 (unsigned long)spe);
256
257     if (aff_spe)
258         aff_spe_fd = aff_spe->base_private->fd_spe_dir;
259
260     priv->fd_spe_dir = spu_create(pathname, spu_createflags,
261                                   S_IRUSR | S_IWUSR | S_IXUSR, aff_spe_fd);
262
263     if (priv->fd_spe_dir < 0) {
264         DEBUG_PRINTF("ERROR: Could not create SPE %s\n", pathname);
265         perror("spu_create()");
266         free_spe_context(spe);
267         /* we mask most errors, but leave ENODEV */
268         if (errno != ENODEV)
269             errno = EFAULT;
270         return NULL;
271     }
272
273     priv->flags = flags;
274
275     /* Map the required areas into process memory */
276     priv->mem_mmap_base = mapfileat(priv->fd_spe_dir, "mem", LS_SIZE);
277     if (priv->mem_mmap_base == MAP_FAILED) {
278         DEBUG_PRINTF("ERROR: Could not map SPE memory.\n");
279         free_spe_context(spe);
280         errno = ENOMEM;
281         return NULL;
282     }
283
284     if (flags & SPE_MAP_PS) {
285         /* It's possible to map the entire problem state area with
286          * one mmap - try this first */
287         priv->psmap_mmap_base = mapfileat(priv->fd_spe_dir,
288                                           "psmap", PSMAP_SIZE);
289
290         if (priv->psmap_mmap_base != MAP_FAILED) {
291             priv->mssync_mmap_base =
292                 priv->psmap_mmap_base + MSSYNC_OFFSET;
293             priv->mfc_mmap_base =
294                 priv->psmap_mmap_base + MFC_OFFSET;
295             priv->cntl_mmap_base =
296                 priv->psmap_mmap_base + CNTL_OFFSET;
297             priv->signal1_mmap_base =
298                 priv->psmap_mmap_base + SIGNAL1_OFFSET;
299             priv->signal2_mmap_base =
300                 priv->psmap_mmap_base + SIGNAL2_OFFSET;
301
302         } else {
303             /* map each region separately */
304             priv->mfc_mmap_base =
305                 mapfileat(priv->fd_spe_dir, "mfc", MFC_SIZE);
306             priv->mssync_mmap_base =
307                 mapfileat(priv->fd_spe_dir, "mss", MSS_SIZE);
308             priv->cntl_mmap_base =
309                 mapfileat(priv->fd_spe_dir, "cntl", CNTL_SIZE);
310             priv->signal1_mmap_base =
311                 mapfileat(priv->fd_spe_dir, "signal1",
312                           SIGNAL_SIZE);
312             priv->signal2_mmap_base =
313                 mapfileat(priv->fd_spe_dir, "signal2",
314                           SIGNAL_SIZE);
315


```

```

316
317             if (priv->mfc_mmap_base == MAP_FAILED ||
318                 priv->cntl_mmap_base == MAP_FAILED ||
319                 priv->signal1_mmap_base == MAP_FAILED ||
320                 priv->signal2_mmap_base == MAP_FAILED) {
321                 DEBUG_PRINTF("ERROR: Could not map SPE "
322                             "PS memory.\n");
323                 free_spe_context(spe);
324                 errno = ENOMEM;
325                 return NULL;
326             }
327         }
328     }
329
330     if (flags & SPE_CFG_SIGNIFY1_OR) {
331         if (setsignotify(priv->fd_spe_dir, "signal1_type")) {
332             DEBUG_PRINTF("ERROR: Could not open SPE "
333                         "signal1_type file.\n");
334             free_spe_context(spe);
335             errno = EFAULT;
336             return NULL;
337         }
338     }
339
340     if (flags & SPE_CFG_SIGNIFY2_OR) {
341         if (setsignotify(priv->fd_spe_dir, "signal2_type")) {
342             DEBUG_PRINTF("ERROR: Could not open SPE "
343                         "signal2_type file.\n");
344             free_spe_context(spe);
345             errno = EFAULT;
346             return NULL;
347         }
348     }
349
350     return spe;
351 }

```

Here is the call graph for this function:



3.23.4.11 int _base_spe_context_destroy (spe_context_ptr_t *spectx*)

_base_spe_context_destroy cleans up what is left when an SPE executable has exited. Closes open file handles and unmaps memory areas.

Parameters:

spectx Specifies the SPE context

Definition at line 406 of file create.c.

References __spe_context_update_event().

```

407 {
408     int ret = free_spe_context(spe);
409
410     __spe_context_update_event();
411
412     return ret;
413 }

```

Here is the call graph for this function:



3.23.4.12 void _base_spe_context_lock (spe_context_ptr_t spe, enum fd_name fd)

_base_spe_context_lock locks members of the SPE context

Parameters:

spectx Specifies the SPE context

fd Specifies the file

Definition at line 91 of file create.c.

References spe_context::base_private, and spe_context_base_priv::fd_lock.

Referenced by _base_spe_close_if_open(), and _base_spe_open_if_closed().

```

92 {
93     pthread_mutex_lock(&spe->base_private->fd_lock[fdesc]);
94 }

```

3.23.4.13 int _base_spe_context_run (spe_context_ptr_t spe, unsigned int * entry, unsigned int runflags, void * argp, void * envp, spe_stop_info_t * stopinfo)

_base_spe_context_run starts execution of an SPE context with a loaded image

Parameters:

spectx Specifies the SPE context

entry entry point for the SPE programm. If set to 0, entry point is determined by the ELF loader.

runflags valid values are:

SPE_RUN_USER_REGS Specifies that the SPE setup registers r3, r4, and r5 are initialized with the 48 bytes pointed to by argp.

SPE_NO_CALLBACKS do not use built in library functions.

argp An (optional) pointer to application specific data, and is passed as the second parameter to the SPE program.

envp An (optional) pointer to environment specific data, and is passed as the third parameter to the SPE program.

Definition at line 98 of file run.c.

References __spe_current_active_context, _base_spe_handle_library_callback(), _base_spe_program_load_complete(), spe_context::base_private, DEBUG_PRINTF, spe_context_base_priv::emulated_entry, spe_context_base_priv::entry, spe_context_base_priv::fd_spe_dir, spe_context_base_priv::flags, LS_SIZE, spe_context_base_priv::mem_mmap_base, spe_context_info::npc, spe_context_info::prev, spe_stop_info::result, spe_stop_info::spe_callback_error, SPE_CALLBACK_ERROR, SPE_DEFAULT_ENTRY, SPE_EVENTS_ENABLE, SPE_EXIT, spe_stop_info::spe_exit_code, spe_context_info::spe_id,

SPE_ISOLATE, SPE_ISOLATE_EMULATE, spe_stop_info::spe_isolation_error, SPE_ISOLATION_ERROR, SPE_NO_CALLBACKS, SPE_PROGRAM_ISO_LOAD_COMPLETE, SPE_PROGRAM_ISOLATED_STOP, SPE_PROGRAM_LIBRARY_CALL, SPE_PROGRAM_NORMAL_END, SPE_RUN_USER_REGS, spe_stop_info::spe_runtime_error, SPE_RUNTIME_ERROR, spe_stop_info::spe_runtime_exception, SPE_RUNTIME_EXCEPTION, spe_stop_info::spe_runtime_fatal, SPE_RUNTIME_FATAL, spe_stop_info::spe_signal_code, SPE_SPU_HALT, SPE_SPU_INVALID_CHANNEL, SPE_SPU_INVALID_INSTR, SPE_SPU_STOPPED_BY_STOP, SPE_SPU_WAITING_ON_CHANNEL, SPE_STOP_AND_SIGNAL, spe_stop_info::spu_status, spe_context_info::status, spe_stop_info::stop_reason, addr64::ui, and addr64::ull.

Referenced by _event_spe_context_run().

```

101 {
102     int retval = 0, run_rc;
103     unsigned int run_status, tmp_entry;
104     spe_stop_info_t stopinfo_buf;
105     struct spe_context_info this_context_info __attribute__((cleanup(cleanupspeinfo)));
106
107     /* If the caller hasn't set a stopinfo buffer, provide a buffer on the
108      * stack instead. */
109     if (!stopinfo)
110         stopinfo = &stopinfo_buf;
111
112
113     /* In emulated isolated mode, the npc will always return as zero.
114      * use our private entry point instead */
115     if (spe->base_private->flags & SPE_ISOLATE_EMULATE)
116         tmp_entry = spe->base_private->emulated_entry;
117
118     else if (*entry == SPE_DEFAULT_ENTRY)
119         tmp_entry = spe->base_private->entry;
120     else
121         tmp_entry = *entry;
122
123     /* If we're starting the SPE binary from its original entry point,
124      * setup the arguments to main() */
125     if (tmp_entry == spe->base_private->entry &&
126         !(spe->base_private->flags &
127           (SPE_ISOLATE | SPE_ISOLATE_EMULATE))) {
128
129         addr64 argp64, envp64, tid64, ls64;
130         unsigned int regs[128][4];
131
132         /* setup parameters */
133         argp64.ull = (uint64_t)(unsigned long)argp;
134         envp64.ull = (uint64_t)(unsigned long)envp;
135         tid64.ull = (uint64_t)(unsigned long)spe;
136
137         /* make sure the register values are 0 */
138         memset(regs, 0, sizeof(regs));
139
140         /* set sensible values for stack_ptr and stack_size */
141         regs[1][0] = (unsigned int) LS_SIZE - 16;           /* stack_ptr */
142         regs[2][0] = 0;                                     /* stack_size */
143
144         if (runflags & SPE_RUN_USER_REGS) {
145             /* When SPE_USER_REGS is set, argp points to an array
146              * of 3x128b registers to be passed directly to the SPE
147              * program.
148              */
149             memcpy(regs[3], argp, sizeof(unsigned int) * 12);
150         } else {
151             regs[3][0] = tid64.ui[0];
152             regs[3][1] = tid64.ui[1];
153

```

```

154             regs[4][0] = argp64.ui[0];
155             regs[4][1] = argp64.ui[1];
156
157             regs[5][0] = envp64.ui[0];
158             regs[5][1] = envp64.ui[1];
159         }
160
161         /* Store the LS base address in R6 */
162         ls64.ul = (uint64_t)(unsigned long)spe->base_private->mem_mmap_base;
163         regs[6][0] = ls64.ui[0];
164         regs[6][1] = ls64.ui[1];
165
166         if (set_regs(spe, regs))
167             return -1;
168     }
169
170     /*Leave a trail of breadcrumbs for the debugger to follow */
171     if (!__spe_current_active_context) {
172         __spe_current_active_context = &this_context_info;
173         if (!__spe_current_active_context)
174             return -1;
175         __spe_current_active_context->prev = NULL;
176     } else {
177         struct spe_context_info *newinfo;
178         newinfo = &this_context_info;
179         if (!newinfo)
180             return -1;
181         newinfo->prev = __spe_current_active_context;
182         __spe_current_active_context = newinfo;
183     }
184     /*remember the ls-addr*/
185     __spe_current_active_context->spe_id = spe->base_private->fd_spe_dir;
186
187 do_run:
188     /*Remember the npc value*/
189     __spe_current_active_context->npc = tmp_entry;
190
191     /* run SPE context */
192     run_rc = spu_run(spe->base_private->fd_spe_dir,
193                      &tmp_entry, &run_status);
194
195     /*Remember the npc value*/
196     __spe_current_active_context->npc = tmp_entry;
197     __spe_current_active_context->status = run_status;
198
199     DEBUG_PRINTF("spu_run returned run_rc=0x%08x, entry=0x%04x, "
200                 "ext_status=0x%04x.\n", run_rc, tmp_entry, run_status);
201
202     /* set up return values and stopinfo according to spu_run exit
203      * conditions. This is overwritten on error.
204      */
205     stopinfo->spu_status = run_rc;
206
207     if (spe->base_private->flags & SPE_ISOLATE_EMULATE) {
208         /* save the entry point, and pretend that the npc is zero */
209         spe->base_private->emulated_entry = tmp_entry;
210         *entry = 0;
211     } else {
212         *entry = tmp_entry;
213     }
214
215     /* Return with stopinfo set on syscall error paths */
216     if (run_rc == -1) {
217         DEBUG_PRINTF("spu_run returned error %d, errno=%d\n",
218                     run_rc, errno);
219         stopinfo->stop_reason = SPE_RUNTIME_FATAL;
220         stopinfo->result.spe_runtime_fatal = errno;

```

```

221         retval = -1;
222
223         /* For isolated contexts, pass EPERM up to the
224          * caller.
225          */
226         if (!(spe->base_private->flags & SPE_ISOLATE
227              && errno == EPERM))
228             errno = EFAULT;
229
230     } else if (run_rc & SPE_SPU_INVALID_INSTR) {
231         DEBUG_PRINTF("SPU has tried to execute an invalid "
232                     "instruction. %d\n", run_rc);
233         stopinfo->stop_reason = SPE_RUNTIME_ERROR;
234         stopinfo->result.spe_runtime_error = SPE_SPU_INVALID_INSTR;
235         errno = EFAULT;
236         retval = -1;
237
238     } else if ((spe->base_private->flags & SPE_EVENTS_ENABLE) && run_status) {
239         /* Report asynchronous error if return val are set and
240          * SPU events are enabled.
241          */
242         stopinfo->stop_reason = SPE_RUNTIME_EXCEPTION;
243         stopinfo->result.spe_runtime_exception = run_status;
244         stopinfo->spu_status = -1;
245         errno = EIO;
246         retval = -1;
247
248     } else if (run_rc & SPE_SPU_STOPPED_BY_STOP) {
249         /* Stop & signals are broken down into three groups
250          * 1. SPE library call
251          * 2. SPE user defined stop & signal
252          * 3. SPE program end.
253          *
254          * These groups are signified by the 14-bit stop code:
255          */
256         int stopcode = (run_rc >> 16) & 0x3fff;
257
258         /* Check if this is a library callback, and callbacks are
259          * allowed (ie, running without SPE_NO_CALLBACKS)
260          */
261         if ((stopcode & 0xff00) == SPE_PROGRAM_LIBRARY_CALL
262             && !(runflags & SPE_NO_CALLBACKS)) {
263
264             int callback_rc, callback_number = stopcode & 0xff;
265
266             /* execute library callback */
267             DEBUG_PRINTF("SPE library call: %d\n", callback_number);
268             callback_rc = _base_spe_handle_library_callback(spe,
269                                         callback_number, *entry);
270
271             if (callback_rc) {
272                 /* library callback failed; set errno and
273                  * return immediately */
274                 DEBUG_PRINTF("SPE library call failed: %d\n",
275                             callback_rc);
276                 stopinfo->stop_reason = SPE_CALLBACK_ERROR;
277                 stopinfo->result.spe_callback_error =
278                     callback_rc;
279                 errno = EFAULT;
280                 retval = -1;
281             } else {
282                 /* successful library callback - restart the SPE
283                  * program at the next instruction */
284                 tmp_entry += 4;
285                 goto do_run;
286             }
287

```

```


288         } else if ((stopcode & 0xff00) == SPE_PROGRAM_NORMAL_END) {
289             /* The SPE program has exited by exit(X) */
290             stopinfo->stop_reason = SPE_EXIT;
291             stopinfo->result.spe_exit_code = stopcode & 0xff;
292
293             if (spe->base_private->flags & SPE_ISOLATE) {
294                 /* Issue an isolated exit, and re-run the SPE.
295                  * We should see a return value without the
296                  * 0x80 bit set. */
297                 if (!issue_isolated_exit(spe))
298                     goto do_run;
299                 retval = -1;
300             }
301
302         } else if ((stopcode & 0xffff0) == SPE_PROGRAM_ISOLATED_STOP) {
303
304             /* 0x2206: isolated app has been loaded by loader;
305              * provide a hook for the debugger to catch this,
306              * and restart
307              */
308             if (stopcode == SPE_PROGRAM_ISO_LOAD_COMPLETE) {
309                 _base_spe_program_load_complete(spe);
310                 goto do_run;
311             } else {
312                 stopinfo->stop_reason = SPE_ISOLATION_ERROR;
313                 stopinfo->result.spe_isolation_error =
314                     stopcode & 0xf;
315             }
316
317         } else if (spe->base_private->flags & SPE_ISOLATE &&
318                    !(run_rc & 0x80)) {
319             /* We've successfully exited isolated mode */
320             retval = 0;
321
322         } else {
323             /* User defined stop & signal, including
324              * callbacks when disabled */
325             stopinfo->stop_reason = SPE_STOP_AND_SIGNAL;
326             stopinfo->result.spe_signal_code = stopcode;
327             retval = stopcode;
328         }
329
330     } else if (run_rc & SPE_SPU_HALT) {
331         DEBUG_PRINTF("SPU was stopped by halt. %d\n", run_rc);
332         stopinfo->stop_reason = SPE_RUNTIME_ERROR;
333         stopinfo->result.spe_runtime_error = SPE_SPU_HALT;
334         errno = EFAULT;
335         retval = -1;
336
337     } else if (run_rc & SPE_SPU_WAITING_ON_CHANNEL) {
338         DEBUG_PRINTF("SPU is waiting on channel. %d\n", run_rc);
339         stopinfo->stop_reason = SPE_RUNTIME_EXCEPTION;
340         stopinfo->result.spe_runtime_exception = run_status;
341         stopinfo->spu_status = -1;
342         errno = EIO;
343         retval = -1;
344
345     } else if (run_rc & SPE_SPU_INVALID_CHANNEL) {
346         DEBUG_PRINTF("SPU has tried to access an invalid "
347                     "channel. %d\n", run_rc);
348         stopinfo->stop_reason = SPE_RUNTIME_ERROR;
349         stopinfo->result.spe_runtime_error = SPE_SPU_INVALID_CHANNEL;
350         errno = EFAULT;
351         retval = -1;
352
353     } else {
354         DEBUG_PRINTF("spu_run returned invalid data: 0x%04x\n", run_rc);

```

```

355         stopinfo->stop_reason = SPE_RUNTIME_FATAL;
356         stopinfo->result.spe_runtime_fatal = -1;
357         stopinfo->spu_status = -1;
358         errno = EFAULT;
359         retval = -1;
360     }
361
362     freespeinfo();
363     return retval;
364 }
365 }
```

Here is the call graph for this function:



3.23.4.14 void _base_spe_context_unlock (spe_context_ptr_t *spe*, enum fd_name *fd*)

`_base_spe_context_unlock` unlocks members of the SPE context

Parameters:

spectx Specifies the SPE context

fd Specifies the file

Definition at line 96 of file create.c.

References `spe_context::base_private`, and `spe_context_base_priv::fd_lock`.

Referenced by `_base_spe_close_if_open()`, and `_base_spe_open_if_closed()`.

```

97 {
98     pthread_mutex_unlock(&spe->base_private->fd_lock[fdesc]);
99 }
```

3.23.4.15 int _base_spe_cpu_info_get (int *info_requested*, int *cpu_node*)

`_base_spe_info_get`

Definition at line 105 of file info.c.

References `_base_spe_count_physical_cpus()`, `_base_spe_count_physical_spes()`, `_base_spe_count_usable_spes()`, `SPE_COUNT_PHYSICAL_CPU_NODES`, `SPE_COUNT_PHYSICAL_SPES`, and `SPE_COUNT_USABLE_SPES`.


```

105
106     int ret = 0;
107     errno = 0;
108
109     switch (info_requested) {
110     case SPE_COUNT_PHYSICAL_CPU_NODES:
111         ret = _base_spe_count_physical_cpus(cpu_node);
112         break;
113     case SPE_COUNT_PHYSICAL_SPES:
```

```

114             ret = _base_spe_count_physical_spes(cpu_node);
115             break;
116         case SPE_COUNT_USABLE_SPES:
117             ret = _base_spe_count_usable_spes(cpu_node);
118             break;
119         default:
120             errno = EINVAL;
121             ret = -1;
122         }
123     return ret;
124 }
```

Here is the call graph for this function:



3.23.4.16 int _base_spe_emulated_loader_present (void)

Check if the emulated loader is present in the filesystem

Returns:

Non-zero if the loader is available, otherwise zero.

Definition at line 145 of file load.c.

References `_base_spe_verify_spe_elf_image()`.

Referenced by `_base_spe_context_create()`.

```

146 {
147     spe_program_handle_t *loader = emulated_loader_program();
148
149     if (!loader)
150         return 0;
151
152     return !_base_spe_verify_spe_elf_image(loader);
153 }
```

Here is the call graph for this function:



3.23.4.17 spe_gang_context_ptr_t _base_spe_gang_context_create (unsigned int flags)

creates the directory in SPUFS that will contain all SPEs that are considered a gang Note: I would like to generalize this to a "group" or "set" Additional attributes maintained at the group level should be used to define scheduling constraints such "temporal" (e.g., scheduled all at the same time, i.e., a gang) "topology" (e.g., "closeness" of SPEs for optimal communication)

Definition at line 364 of file create.c.

References `spe_gang_context::base_private`, `DEBUG_PRINTF`, and `spe_gang_context_base_-priv::gangname`.

```

365 {
366     char pathname[256];
367     struct spe_gang_context_base_priv *pgctx = NULL;
368     struct spe_gang_context *gctx = NULL;
369
370     gctx = malloc(sizeof(*gctx));
371     if (!gctx) {
372         DEBUG_PRINTF("ERROR: Could not allocate spe context.\n");
373         return NULL;
374     }
375     memset(gctx, 0, sizeof(*gctx));
376
377     pgctx = malloc(sizeof(*pgctx));
378     if (!pgctx) {
379         DEBUG_PRINTF("ERROR: Could not allocate spe context.\n");
380         free(gctx);
381         return NULL;
382     }
383     memset(pgctx, 0, sizeof(*pgctx));
384
385     gctx->base_private = pgctx;
386
387     sprintf(gctx->base_private->gangname, "gang-%i-%lu", getpid(),
388             (unsigned long)gctx);
389     sprintf(pathname, "/spu/%s", gctx->base_private->gangname);
390
391     gctx->base_private->fd_gang_dir = spu_create(pathname, SPU_CREATE_GANG,
392                                                 S_IRUSR | S_IWUSR | S_IXUSR);
393
394     if (gctx->base_private->fd_gang_dir < 0) {
395         DEBUG_PRINTF("ERROR: Could not create Gang %s\n", pathname);
396         free_spe_gang_context(gctx);
397         errno = EFAULT;
398         return NULL;
399     }
400
401     gctx->base_private->flags = flags;
402
403     return gctx;
404 }
```

3.23.4.18 int _base_spe_gang_context_destroy (spe_gang_context_ptr_t *gctx*)

`_base_spe_gang_context_destroy` destroys a gang context and frees associated resources

Parameters:

`gctx` Specifies the SPE gang context

Definition at line 415 of file `create.c`.

```

416 {
417     return free_spe_gang_context(gctx);
418 }
```

3.23.4.19 int _base_spe_image_close (spe_program_handle_t * *handle*)

`_base_spe_image_close` unmaps an SPE ELF object that was previously mapped using `spe_open_-image`.

Parameters:

handle handle to open file

Return values:

- 0 On success, spe_close_image returns 0.
- 1 On failure, -1 is returned and errno is set appropriately.

Possible values for errno:

EINVAL From spe_close_image, this indicates that the file, specified by filename, was not previously mapped by a call to spe_open_image.

Definition at line 96 of file image.c.

References spe_program_handle::elf_image, image_handle::map_size, image_handle::speh, and spe_program_handle::toe_shadow.

```

97 {
98     int ret = 0;
99     struct image_handle *ih;
100
101    if (!handle) {
102        errno = EINVAL;
103        return -1;
104    }
105
106    ih = (struct image_handle *)handle;
107
108    if (!ih->speh.elf_image || !ih->map_size) {
109        errno = EINVAL;
110        return -1;
111    }
112
113    if (ih->speh.toe_shadow)
114        free(ih->speh.toe_shadow);
115
116    ret = munmap(ih->speh.elf_image, ih->map_size );
117    free(handle);
118
119    return ret;
120 }
```

3.23.4.20 spe_program_handle_t* _base_spe_image_open (const char *filename)

_base_spe_image_open maps an SPE ELF executable indicated by filename into system memory and returns the mapped address appropriate for use by the spe_create_thread API. It is often more convenient/appropriate to use the loading methodologies where SPE ELF objects are converted to PPE static or shared libraries with symbols which point to the SPE ELF objects after these special libraries are loaded. These libraries are then linked with the associated PPE code to provide a direct symbol reference to the SPE ELF object. The symbols in this scheme are equivalent to the address returned from the spe_open_image function. SPE ELF objects loaded using this function are not shared with other processes, but SPE ELF objects loaded using the other scheme, mentioned above, can be shared if so desired.

Parameters:

filename Specifies the filename of an SPE ELF executable to be loaded and mapped into system memory.

Returns:

On success, spe_open_image returns the address at which the specified SPE ELF object has been mapped. On failure, NULL is returned and errno is set appropriately.

Possible values for errno include:

EACCES The calling process does not have permission to access the specified file.

EFAULT The filename parameter points to an address that was not contained in the calling process's address space.

A number of other errno values could be returned by the open(2), fstat(2), mmap(2), munmap(2), or close(2) system calls which may be utilized by the spe_open_image or spe_close_image functions.

See also:

[spe_create_thread](#)

Definition at line 37 of file image.c.

References `_base_spe_toe_ear()`, `_base_spe_verify_spe_elf_image()`, `spe_program_handle::elf_image`, `spe_program_handle::handle_size`, `image_handle::map_size`, `image_handle::speh`, and `spe_program_handle::toe_shadow`.

```


38 {
39     /* allocate an extra integer in the spe handle to keep the mapped size information */
40     struct image_handle *ret;
41     int binfd = -1, f_stat;
42     struct stat statbuf;
43     size_t ps = getpagesize ();
44
45     ret = malloc(sizeof(struct image_handle));
46     if (!ret)
47         return NULL;
48
49     ret->speh.handle_size = sizeof(spe_program_handle_t);
50     ret->speh.toe_shadow = NULL;
51
52     binfd = open(filename, O_RDONLY);
53     if (binfd < 0)
54         goto ret_err;
55
56     f_stat = fstat(binfd, &statbuf);
57     if (f_stat < 0)
58         goto ret_err;
59
60     /* Sanity: is it executable ?
61      */
62     if(!(statbuf.st_mode & (S_IXUSR | S_IXGRP | S_IXOTH))) {
63         errno=EACCES;
64         goto ret_err;
65     }
66
67     /* now store the size at the extra allocated space */
68     ret->map_size = (statbuf.st_size + ps - 1) & ~(ps - 1);
69
70     ret->speh.elf_image = mmap(NULL, ret->map_size,
71                                 PROT_WRITE | PROT_READ,
72                                 MAP_PRIVATE, binfd, 0);
73     if (ret->speh.elf_image == MAP_FAILED)
74         goto ret_err;
75
76     /*Verify that this is a valid SPE ELF object*/
77     if(!_base_spe_verify_spe_elf_image((spe_program_handle_t *)ret)))
78         goto ret_err;
79
80     if (_base_spe_toe_ear(&ret->speh))
81         goto ret_err;
82
83     /* ok */
84     close(binfd);

```

```

85         return (spe_program_handle_t *)ret;
86
87     /* err & cleanup */
88 ret_err:
89     if (binfofd >= 0)
90         close(binfofd);
91
92     free(ret);
93     return NULL;
94 }
```

Here is the call graph for this function:



3.23.4.21 int _base_spe_in_mbox_status (spe_context_ptr_t spectx)

The `_base_spe_in_mbox_status` function fetches the status of the SPU inbound mailbox for the SPE thread specified by the `speid` parameter. A 0 value is returned if the mailbox is full. A non-zero value specifies the number of available (32-bit) mailbox entries.

Parameters:

`spectx` Specifies the SPE context whose mailbox status is to be read.

Returns:

On success, returns the current status of the mailbox, respectively. On failure, -1 is returned.

See also:

`spe_read_out_mbox`, `spe_write_in_mbox`, `read` (2)


Definition at line 202 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `FD_WBOX_STAT`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, and `spe_spu_control_area::SPU_Mbox_Status`.

```

203 {
204     int rc, ret;
205     volatile struct spe_spu_control_area *cntl_area =
206         spectx->base_private->cntl_mmap_base;
207
208     if (spectx->base_private->flags & SPE_MAP_PS) {
209         ret = (cntl_area->SPU_Mbox_Status >> 8) & 0xFF;
210     } else {
211         rc = read(_base_spe_open_if_closed(spectx, FD_WBOX_STAT, 0), &ret, 4);
212         if (rc != 4)
213             ret = -1;
214     }
215
216     return ret;
217
218 }
```

Here is the call graph for this function:



3.23.4.22 int _base_spe_in_mbox_write (spe_context_ptr_t *spectx*, unsigned int *mbox_data*[], int *count*, int *behavior_flag*)

The `_base_spe_in_mbox_write` function writes `mbox_data` to the SPE inbound mailbox for the SPE thread `speid`.

If the behavior flag indicates `ALL_BLOCKING` the call will try to write exactly `count` mailbox entries and block until the write request is satisfied, i.e., exactly `count` mailbox entries have been written. If the behavior flag indicates `ANY_BLOCKING` the call will try to write up to `count` mailbox entries, and block until the write request is satisfied, i.e., at least 1 mailbox entry has been written. If the behavior flag indicates `ANY_NON_BLOCKING` the call will not block until the write request is satisfied, but instead write whatever is immediately possible and return the number of mailbox entries written. `spe_stat_in_mbox` can be called to ensure that data can be written prior to calling the function.

Parameters:

`spectx` Specifies the SPE thread whose outbound mailbox is to be read.
`mbox_data`
`count`
`behavior_flag` `ALL_BLOCKING`
 `ANY_BLOCKING`
 `ANY_NON_BLOCKING`

Return values:

`>=0` the number of 32-bit mailbox messages written
`-1` error condition and `errno` is set
 Possible values for `errno`:
 `EINVAL` `spectx` is invalid
 `Exxxx` what else do we need here??

3.23.4.23 void* _base_spe_ls_area_get (struct spe_context * *spectx*)

`_base_spe_ls_area_get` returns a pointer to the start of the memory mapped local store area

Parameters:

`spectx` Specifies the SPE context

3.23.4.24 int _base_spe_ls_size_get (spe_context_ptr_t *spe*)

`_base_spe_ls_size_get` returns the size of the local store area

Parameters:

spectx Specifies the SPE context

Definition at line 105 of file accessors.c.

References LS_SIZE.

```
106 {
107     return LS_SIZE;
108 }
```

3.23.4.25 int _base_spe_mfcio_get (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_get function places a get DMA command on the proxy command queue of the SPE thread specified by speid. The get command transfers size bytes of data starting at the effective address specified by ea to the local store address specified by ls. The DMA is identified by the tag id specified by tag and performed according to the transfer class and replacement class specified by tid and rid respectively.

Parameters:

spectx Specifies the SPE context

ls Specifies the starting local store destination address.

ea Specifies the starting effective address source address.

size Specifies the size, in bytes, to be transferred.

tag Specifies the tag id used to identify the DMA command.

tid Specifies the transfer class identifier of the DMA command.

rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 160 of file dma.c.

References MFC_CMD_GET.

```
167 {
168     return spe_do_mfc_get(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_GET);
169 }
```

3.23.4.26 int _base_spe_mfcio_getb (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_getb function is identical to _base_spe_mfcio_get except that it places a getb (get with barrier) DMA command on the proxy command queue. The barrier form ensures that this command and all sequence commands with the same tag identifier as this command are locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context

ls Specifies the starting local store destination address.

ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 171 of file dma.c.

References MFC_CMD_GETB.

```
178 {  
179     return spe_do_mfc_get(spectx, ls, ea, size, tag, rid, rid, MFC_CMD_GETB);  
180 }
```

3.23.4.27 int _base_spe_mfcio_getf (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_getf function is identical to _base_spe_mfcio_get except that it places a getf (get with fence) DMA command on the proxy command queue. The fence form ensure that this command is locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 182 of file dma.c.

References MFC_CMD_GETF.

```
189 {  
190     return spe_do_mfc_get(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_GETF);  
191 }
```

3.23.4.28 int _base_spe_mfcio_put (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_put function places a put DMA command on the proxy command queue of the SPE thread specified by speid. The put command transfers size bytes of data starting at the local store address specified by ls to the effective address specified by ea. The DMA is identified by the tag id specified by tag and performed according transfer class and replacement class specified by tid and rid respectively.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 126 of file dma.c.

References MFC_CMD_PUT.

```
133 {  
134     return spe_do_mfc_put(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_PUT);  
135 }
```

3.23.4.29 int _base_spe_mfcio_putb (spe_context_ptr_t *spectx*, unsigned int *ls*, void * *ea*, unsigned int *size*, unsigned int *tag*, unsigned int *tid*, unsigned int *rid*)

The _base_spe_mfcio_putb function is identical to _base_spe_mfcio_put except that it places a putb (put with barrier) DMA command on the proxy command queue. The barrier form ensures that this command and all sequence commands with the same tag identifier as this command are locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 137 of file dma.c.

References MFC_CMD_PUTB.

```
144 {
145     return spe_do_mfc_put(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_PUTB);
146 }
```

3.23.4.30 int _base_spe_mfcio_putf (spe_context_ptr_t spectx, unsigned int ls, void * ea, unsigned int size, unsigned int tag, unsigned int tid, unsigned int rid)

The _base_spe_mfcio_putf function is identical to _base_spe_mfcio_put except that it places a putf (put with fence) DMA command on the proxy command queue. The fence form ensures that this command is locally ordered with respect to all previously issued commands with the same tag group and command queue.

Parameters:

spectx Specifies the SPE context
ls Specifies the starting local store destination address.
ea Specifies the starting effective address source address.
size Specifies the size, in bytes, to be transferred.
tag Specifies the tag id used to identify the DMA command.
tid Specifies the transfer class identifier of the DMA command.
rid Specifies the replacement class identifier of the DMA command.

Returns:

On success, return 0. On failure, -1 is returned.

Definition at line 148 of file dma.c.

References MFC_CMD_PUTF.

```
155 {
156     return spe_do_mfc_put(spectx, ls, ea, size, tag, tid, rid, MFC_CMD_PUTF);
157 }
```

3.23.4.31 int _base_spe_mfcio_tag_status_read (spe_context_ptr_t spectx, unsigned int mask, unsigned int behavior, unsigned int * tag_status)

_base_spe_mfcio_tag_status_read

No Idea

Definition at line 307 of file dma.c.

References spe_context_base_priv::active_tagmask, spe_context::base_private, spe_context_base_priv::flags, SPE_MAP_PS, SPE_TAG_ALL, SPE_TAG_ANY, and SPE_TAG_IMMEDIATE.

```
308 {
309     if ( mask != 0 ) {
310         if ( !(spectx->base_private->flags & SPE_MAP_PS) )
311             mask = 0;
312     } else {
```

```

313         if ((spectx->base_private->flags & SPE_MAP_PS))
314             mask = spectx->base_private->active_tagmask;
315     }
316
317     if (!tag_status) {
318         errno = EINVAL;
319         return -1;
320     }
321
322     switch (behavior) {
323     case SPE_TAG_ALL:
324         return spe_mfcio_tag_status_read_all(spectx, mask, tag_status);
325     case SPE_TAG_ANY:
326         return spe_mfcio_tag_status_read_any(spectx, mask, tag_status);
327     case SPE_TAG_IMMEDIATE:
328         return spe_mfcio_tag_status_read_immediate(spectx, mask, tag_status);
329     default:
330         errno = EINVAL;
331         return -1;
332     }
333 }
```

3.23.4.32 int _base_spe_mssync_start (spe_context_ptr_t *spectx*)

_base_spe_mssync_start starts Multisource Synchronisation

Parameters:

spectx Specifies the SPE context


Definition at line 335 of file dma.c.

References _base_spe_open_if_closed(), spe_context::base_private, FD_MSS, spe_context_base_priv::flags, spe_mssync_area::MFC_MSSync, spe_context_base_priv::mssync_mmap_base, and SPE_MAP_PS.

```

336 {
337     int ret, fd;
338     unsigned int data = 1; /* Any value can be written here */
339
340     volatile struct spe_mssync_area *mss_area =
341         spectx->base_private->mssync_mmap_base;
342
343     if (spectx->base_private->flags & SPE_MAP_PS) {
344         mss_area->MFC_MSSync = data;
345         return 0;
346     } else {
347         fd = _base_spe_open_if_closed(spectx, FD_MSS, 0);
348         if (fd != -1) {
349             ret = write(fd, &data, sizeof (data));
350             if ((ret < 0) && (errno != EIO)) {
351                 perror("spe_mssync_start: internal error");
352             }
353             return ret < 0 ? -1 : 0;
354         } else
355             return -1;
356     }
357 }
```

Here is the call graph for this function:



3.23.4.33 int _base_spe_mssync_status (spe_context_ptr_t *spectx*)

_base_spe_mssync_status retrieves status of Multisource Synchronisation

Parameters:

spectx Specifies the SPE context

Definition at line 359 of file dma.c.


References *_base_spe_open_if_closed()*, *spe_context::base_private*, *FD_MSS*, *spe_context_base_priv::flags*, *spe_mssync_area::MFC_MSSync*, *spe_context_base_priv::mssync_mmap_base*, and *SPE_MAP_PS*.

```

360 {
361     int ret, fd;
362     unsigned int data;
363
364     volatile struct spe_mssync_area *mss_area =
365         spectx->base_private->mssync_mmap_base;
366
367     if (spectx->base_private->flags & SPE_MAP_PS) {
368         return mss_area->MFC_MSSync;
369     } else {
370         fd = _base_spe_open_if_closed(spectx, FD_MSS, 0);
371         if (fd != -1) {
372             ret = read(fd, &data, sizeof (data));
373             if ((ret < 0) && (errno != EIO)) {
374                 perror("spe_mssync_start: internal error");
375             }
376             return ret < 0 ? -1 : data;
377         } else
378             return -1;
379     }
380 }

```

Here is the call graph for this function:



3.23.4.34 int _base_spe_out_intr_mbox_read (spe_context_ptr_t *spectx*, unsigned int *mbox_data[]*, int *count*, int *behavior_flag*)

The *_base_spe_out_intr_mbox_read* function reads the contents of the SPE outbound interrupting mailbox for the SPE context.


Definition at line 255 of file mbox.c.

References `_base_spe_open_if_closed()`, `FD_IBOX`, `FD_IBOX_NB`, `SPE_MBOX_ALL_BLOCKING`, `SPE_MBOX_ANY_BLOCKING`, and `SPE_MBOX_ANY_NONBLOCKING`.

```

259 {
260     int rc;
261     int total;
262
263     if (mbox_data == NULL || count < 1) {
264         errno = EINVAL;
265         return -1;
266     }
267
268     switch (behavior_flag) {
269     case SPE_MBOX_ALL_BLOCKING: // read all, even if blocking
270         total = rc = 0;
271         while (total < 4*count) {
272             rc = read(_base_spe_open_if_closed(spectx, FD_IBOX, 0),
273                       (char *)mbox_data + total, 4*count - total);
274             if (rc == -1) {
275                 break;
276             }
277             total += rc;
278         }
279         break;
280
281     case SPE_MBOX_ANY_BLOCKING: // read at least one, even if blocking
282         total = rc = read(_base_spe_open_if_closed(spectx, FD_IBOX, 0), mbox_data, 4*count);
283         break;
284
285     case SPE_MBOX_ANY_NONBLOCKING: // only read, if non blocking
286         rc = read(_base_spe_open_if_closed(spectx, FD_IBOX_NB, 0), mbox_data, 4*count);
287         if (rc == -1 && errno == EAGAIN) {
288             rc = 0;
289             errno = 0;
290         }
291         total = rc;
292         break;
293
294     default:
295         errno = EINVAL;
296         return -1;
297     }
298
299     if (rc == -1) {
300         errno = EIO;
301         return -1;
302     }
303
304     return rc / 4;
305 }
```

Here is the call graph for this function:



3.23.4.35 int _base_spe_out_intr_mbox_status (spe_context_ptr_t *spectx*)

The `_base_spe_out_intr_mbox_status` function fetches the status of the SPU outbound interrupt mailbox for the SPE thread specified by the `speid` parameter. A 0 value is returned if the mailbox is empty. A non-zero value specifies the number of 32-bit unread mailbox entries.

Parameters:

`spectx` Specifies the SPE context whose mailbox status is to be read.

Returns:

On success, returns the current status of the mailbox, respectively. On failure, -1 is returned.

See also:

`spe_read_out_mbox`, `spe_write_in_mbox`, `read` (2)


Definition at line 238 of file `mbox.c`.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `FD_IBOX_STAT`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, and `spe_spu_control_area::SPU_Mbox_Stat`.

```

239 {
240     int rc, ret;
241     volatile struct spe_spu_control_area *cntl_area =
242         spectx->base_private->cntl_mmap_base;
243
244     if (spectx->base_private->flags & SPE_MAP_PS) {
245         ret = (cntl_area->SPU_Mbox_Stat >> 16) & 0xFF;
246     } else {
247         rc = read(_base_spe_open_if_closed(spectx, FD_IBOX_STAT, 0), &ret, 4);
248         if (rc != 4)
249             ret = -1;
250     }
251
252     return ret;
253 }
```

Here is the call graph for this function:



3.23.4.36 int _base_spe_out_mbox_read (spe_context_ptr_t *spectx*, unsigned int *mbox_data*[], int *count*)

The `_base_spe_out_mbox_read` function reads the contents of the SPE outbound interrupting mailbox for the SPE thread `speid`.

The call will not block until the read request is satisfied, but instead return up to `count` currently available mailbox entries.

`spe_stat_out_intr_mbox` can be called to ensure that data is available prior to reading the outbound interrupting mailbox.

Parameters:

spectx Specifies the SPE thread whose outbound mailbox is to be read.
mbox_data
count

Return values:

>0 the number of 32-bit mailbox messages read

=0 no data available

-1 error condition and errno is set

Possible values for errno:

EINVAL speid is invalid

Exxxx what else do we need here??


Definition at line 58 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `DEBUG_PRINTF`, `FD_MBOX`, `spe_context_base_priv::flags`, and `SPE_MAP_PS`.

```

61 {
62     int rc;
63
64     if (mbox_data == NULL || count < 1) {
65         errno = EINVAL;
66         return -1;
67     }
68
69     if (spectx->base_private->flags & SPE_MAP_PS) {
70         rc = _base_spe_out_mbox_read_ps(spectx, mbox_data, count);
71     } else {
72         rc = read(_base_spe_open_if_closed(spectx, FD_MBOX, 0), mbox_data, count*4);
73         DEBUG_PRINTF("%s read rc: %d\n", __FUNCTION__, rc);
74         if (rc != -1) {
75             rc /= 4;
76         } else {
77             if (errno == EAGAIN ) { // no data ready to be read
78                 errno = 0;
79                 rc = 0;
80             }
81         }
82     }
83     return rc;
84 }
```

Here is the call graph for this function:



3.23.4.37 int _base_spe_out_mbox_status (spe_context_ptr_t spectx)

The `_base_spe_out_mbox_status` function fetches the status of the SPU outbound mailbox for the SPE thread specified by the `speid` parameter. A 0 value is returned if the mailbox is empty. A non-zero value specifies the number of 32-bit unread mailbox entries.

Parameters:

spectx Specifies the SPE context whose mailbox status is to be read.

Returns:

On success, returns the current status of the mailbox, respectively. On failure, -1 is returned.

See also:

`spe_read_out_mbox`, `spe_write_in_mbox`, `read` (2)


Definition at line 220 of file mbox.c.

References `_base_spe_open_if_closed()`, `spe_context::base_private`, `spe_context_base_priv::cntl_mmap_base`, `FD_MBOX_STAT`, `spe_context_base_priv::flags`, `SPE_MAP_PS`, and `spe_spu_control_area::SPU_Mbox_Stat`.

```

221 {
222     int rc, ret;
223     volatile struct spe_spu_control_area *cntl_area =
224         spectx->base_private->cntl_mmap_base;
225
226     if (spectx->base_private->flags & SPE_MAP_PS) {
227         ret = cntl_area->SPU_Mbox_Stat & 0xFF;
228     } else {
229         rc = read(_base_spe_open_if_closed(spectx, FD_MBOX_STAT, 0), &ret, 4);
230         if (rc != 4)
231             ret = -1;
232     }
233
234     return ret;
235 }
236 }
```

Here is the call graph for this function:



3.23.4.38 int _base_spe_program_load (spe_context_ptr_t *spectx*, spe_program_handle_t * *program*)

`_base_spe_program_load` loads an ELF image into a context

Parameters:

spectx Specifies the SPE context

program handle to the ELF image

Definition at line 189 of file load.c.


References `_base_spe_load_spe_elf()`, `_base_spe_program_load_complete()`, `spe_context::base_private`, `DEBUG_PRINTF`, `spe_context_base_priv::emulated_entry`, `spe_id_info::entry`, `spe_context_base_priv::entry`, `spe_context_base_priv::flags`, `spe_context_base_priv::loaded_program`, `spe_context_base_priv::mem_mmap_base`, `SPE_ISOLATE`, and `SPE_ISOLATE_EMULATE`.

```

190 {
191     int rc = 0;
192     struct spe_ld_info ld_info;
193
194     spe->base_private->loaded_program = program;
195
196     if (spe->base_private->flags & SPE_ISOLATE) {
197         rc = spe_start_isolated_app(spe, program);
198
199     } else if (spe->base_private->flags & SPE_ISOLATE_EMULATE) {
200         rc = spe_start_emulated_isolated_app(spe, program, &ld_info);
201
202     } else {
203         rc = _base_spe_load_spe_elf(program,
204                                     spe->base_private->mem_mmap_base, &ld_info);
205
206         if (!rc)
207             _base_spe_program_load_complete(spe);
208
209     if (rc != 0) {
210         DEBUG_PRINTF ("Load SPE ELF failed..\n");
211         return -1;
212     }
213
214     spe->base_private->entry = ld_info.entry;
215     spe->base_private->emulated_entry = ld_info.entry;
216
217     return 0;
218 }

```

Here is the call graph for this function:



3.23.4.39 void _base_spe_program_load_complete (spe_context_ptr_t *spectx*)

Signal that the program load has completed. For normal apps, this is called directly in the load path. For (emulated) isolated apps, the load is asynchronous, so this needs to be called when we know that the load has completed

Precondition:

spectx spe->base_priv->loaded_program is a valid SPE program

Parameters:

spectx The spe context that has been loaded.

Register the SPE program's start address with the oprofile and gdb, by writing to the object-id file.

Definition at line 37 of file load.c.

References __spe_context_update_event(), spe_context::base_private, DEBUG_PRINTF, spe_program_handle::elf_image, spe_context_base_priv::fd_spe_dir, and spe_context_base_priv::loaded_program.

Referenced by _base_spe_context_run(), and _base_spe_program_load().

```

39         int objfd, len;
40         char buf[20];
41         spe_program_handle_t *program;
42
43         program = spectx->base_private->loaded_program;
44
45         if (!program || !program->elf_image) {
46             DEBUG_PRINTF("%s called, but no program loaded\n", __func__);
47             return;
48         }
49
50         objfd = openat(spectx->base_private->fd_spe_dir, "object-id", O_RDWR);
51         if (objfd < 0)
52             return;
53
54         len = sprintf(buf, "%p", program->elf_image);
55         write(objfd, buf, len + 1);
56         close(objfd);
57
58         __spe_context_update_event();
59     }

```

Here is the call graph for this function:



3.23.4.40 void* _base_spe_ps_area_get (struct spe_context * *spectx*, enum ps_area *area*)

_base_spe_ps_area_get returns a pointer to the start of memory mapped problem state area

Parameters:

spectx Specifies the SPE context

area specifies the area to map

3.23.4.41 int _base_spe_signal_write (spe_context_ptr_t *spectx*, unsigned int *signal_reg*, unsigned int *data*)

The _base_spe_signal_write function writes data to the signal notification register specified by signal_reg for the SPE thread specified by the speid parameter.

Parameters:

spectx Specifies the SPE context whose signal register is to be written to.

signal_reg Specified the signal notification register to be written. Valid signal notification registers are:

SPE_SIG_NOTIFY_REG_1 SPE signal notification register 1

SPE_SIG_NOTIFY_REG_2 SPE signal notification register 2

data The 32-bit data to be written to the specified signal notification register.

Returns:

On success, spe_write_signal returns 0. On failure, -1 is returned.

See also:

`spe_get_ps_area`, `spe_write_in_mbox`


Definition at line 307 of file mbox.c.

References `_base_spe_close_if_open()`, `_base_spe_open_if_closed()`, `spe_context::base_private`, `FD_SIG1`, `FD_SIG2`, `spe_context_base_priv::flags`, `spe_context_base_priv::signal1_mmap_base`, `spe_context_base_priv::signal2_mmap_base`, `SPE_MAP_PS`, `SPE_SIG_NOTIFY_REG_1`, `SPE_SIG_NOTIFY_REG_2`, `spe_sig_notify_1_area::SPU_Sig_Notify_1`, and `spe_sig_notify_2_area::SPU_Sig_Notify_2`.

```

310 {
311     int rc;
312
313     if (spectx->base_private->flags & SPE_MAP_PS) {
314         if (signal_reg == SPE_SIG_NOTIFY_REG_1) {
315             spe_sig_notify_1_area_t *sig = spectx->base_private->signal1_mmap_base;
316
317             sig->SPU_Sig_Notify_1 = data;
318         } else if (signal_reg == SPE_SIG_NOTIFY_REG_2) {
319             spe_sig_notify_2_area_t *sig = spectx->base_private->signal2_mmap_base;
320
321             sig->SPU_Sig_Notify_2 = data;
322         } else {
323             errno = EINVAL;
324             return -1;
325         }
326         rc = 0;
327     } else {
328         if (signal_reg == SPE_SIG_NOTIFY_REG_1)
329             rc = write(_base_spe_open_if_closed(spectx, FD_SIG1, 0), &data, 4);
330         else if (signal_reg == SPE_SIG_NOTIFY_REG_2)
331             rc = write(_base_spe_open_if_closed(spectx, FD_SIG2, 0), &data, 4);
332         else {
333             errno = EINVAL;
334             return -1;
335         }
336
337         if (rc == 4)
338             rc = 0;
339
340         if (signal_reg == SPE_SIG_NOTIFY_REG_1)
341             _base_spe_close_if_open(spectx, FD_SIG1);
342         else if (signal_reg == SPE_SIG_NOTIFY_REG_2)
343             _base_spe_close_if_open(spectx, FD_SIG2);
344     }
345
346     return rc;
347 }
```

Here is the call graph for this function:



3.23.4.42 int _base_spe_stop_reason_get (spe_context_ptr_t spectx)

`_base_spe_stop_reason_get`

Parameters:

specx one thread for which to check why it was stopped

Return values:

- 0* success - eventid and eventdata set appropriately
- 1* spe has not stopped after checking last, so no data was written to event
- 1* an error has happened, event was not touched, errno gets set

Possible values for errno:

EINVAL speid is invalid

Exxxx what else do we need here??

3.23.4.43 int _base_spe_stop_status_get (spe_context_ptr_t *specx*)

_base_spe_stop_status_get


Parameters:

specx Specifies the SPE context


3.24 speevent.h File Reference

```
#include "spebase.h"
```

Include dependency graph for speevent.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [spe_context_event_priv](#)

Typedefs

- typedef struct [spe_context_event_priv](#) [spe_context_event_priv_t](#)
- typedef struct [spe_context_event_priv](#) * [spe_context_event_priv_ptr_t](#)

Enumerations

- enum [__spe_event_types](#) {
 [__SPE_EVENT_OUT_INTR_MBOX](#), [__SPE_EVENT_IN_MBOX](#), [__SPE_EVENT_TAG_GROUP](#), [__SPE_EVENT_SPE_STOPPED](#),
 [__NUM_SPE_EVENT_TYPES](#) }

Functions

- int [_event_spe_stop_info_read](#) ([spe_context_ptr_t](#) spe, [spe_stop_info_t](#) *stopinfo)
- [spe_event_handler_ptr_t](#) [_event_spe_event_handler_create](#) (void)
- int [_event_spe_event_handler_destroy](#) ([spe_event_handler_ptr_t](#) evhandler)

- int `_event_spe_event_handler_register` (`spe_event_handler_ptr_t` evhandler, `spe_event_unit_t` *event)
- int `_event_spe_event_handler_deregister` (`spe_event_handler_ptr_t` evhandler, `spe_event_unit_t` *event)
- int `_event_spe_event_wait` (`spe_event_handler_ptr_t` evhandler, `spe_event_unit_t` *events, int max_events, int timeout)
- int `_event_spe_context_finalize` (`spe_context_ptr_t` spe)
- struct `spe_context_event_priv` * `_event_spe_context_initialize` (`spe_context_ptr_t` spe)
- int `_event_spe_context_run` (`spe_context_ptr_t` spe, unsigned int *entry, unsigned int runflags, void *argp, void *envp, `spe_stop_info_t` *stopinfo)
- void `_event_spe_context_lock` (`spe_context_ptr_t` spe)
- void `_event_spe_context_unlock` (`spe_context_ptr_t` spe)

3.24.1 Typedef Documentation

3.24.1.1 `typedef struct spe_context_event_priv * spe_context_event_priv_ptr_t`

3.24.1.2 `typedef struct spe_context_event_priv spe_context_event_priv_t`

3.24.2 Enumeration Type Documentation

3.24.2.1 `enum __spe_event_types`

Enumerator:

```
__SPE_EVENT_OUT_INTR_MBOX
__SPE_EVENT_IN_MBOX
__SPE_EVENT_TAG_GROUP
__SPE_EVENT_SPE_STOPPED
__NUM_SPE_EVENT_TYPES
```

Definition at line 28 of file speevent.h.

```
28      {
29      __SPE_EVENT_OUT_INTR_MBOX, __SPE_EVENT_IN_MBOX,
30      __SPE_EVENT_TAG_GROUP, __SPE_EVENT_SPE_STOPPED,
31      __NUM_SPE_EVENT_TYPES
32 };
```

3.24.3 Function Documentation

3.24.3.1 `int _event_spe_context_finalize (spe_context_ptr_t spe)`

Definition at line 416 of file spe_event.c.

References `__SPE_EVENT_CONTEXT_PRIV_GET`, `__SPE_EVENT_CONTEXT_PRIV_SET`, `spe_context_event_priv::lock`, `spe_context_event_priv::stop_event_pipe`, and `spe_context_event_priv::stop_event_read_lock`.

```
417 {
418     spe_context_event_priv_ptr_t evctx;
419
420     if (!spe) {
```

```

421     errno = ESRCH;
422     return -1;
423 }
424
425 evctx = __SPE_EVENT_CONTEXT_PRIV_GET(spe);
426 __SPE_EVENT_CONTEXT_PRIV_SET(spe, NULL);
427
428 close(evctx->stop_event_pipe[0]);
429 close(evctx->stop_event_pipe[1]);
430
431 pthread_mutex_destroy(&evctx->lock);
432 pthread_mutex_destroy(&evctx->stop_event_read_lock);
433
434 free(evctx);
435
436 return 0;
437 }
```

3.24.3.2 struct spe_context_event_priv* _event_spe_context_initialize (spe_context_ptr_t spe) [read]

Definition at line 439 of file spe_event.c.

References spe_context_event_priv::events, spe_context_event_priv::lock, spe_event_unit::spe, spe_context_event_priv::stop_event_pipe, and spe_context_event_priv::stop_event_read_lock.

```

440 {
441     spe_context_event_priv_ptr_t evctx;
442     int rc;
443     int i;
444
445     evctx = calloc(1, sizeof(*evctx));
446     if (!evctx) {
447         return NULL;
448     }
449
450     rc = pipe(evctx->stop_event_pipe);
451     if (rc == -1) {
452         free(evctx);
453         return NULL;
454     }
455     rc = fcntl(evctx->stop_event_pipe[0], F_GETFL);
456     if (rc != -1) {
457         rc = fcntl(evctx->stop_event_pipe[0], F_SETFL, rc | O_NONBLOCK);
458     }
459     if (rc == -1) {
460         close(evctx->stop_event_pipe[0]);
461         close(evctx->stop_event_pipe[1]);
462         free(evctx);
463         errno = EIO;
464         return NULL;
465     }
466
467     for (i = 0; i < sizeof(evctx->events) / sizeof(evctx->events[0]); i++) {
468         evctx->events[i].spe = spe;
469     }
470
471     pthread_mutex_init(&evctx->lock, NULL);
472     pthread_mutex_init(&evctx->stop_event_read_lock, NULL);
473
474     return evctx;
475 }
```

3.24.3.3 void _event_spe_context_lock (spe_context_ptr_t spe)

Definition at line 49 of file spe_event.c.

References __SPE_EVENT_CONTEXT_PRIV_GET.

Referenced by _event_spe_event_handler_deregister(), _event_spe_event_handler_register(), and _event_spe_event_wait().

```
50 {
51     pthread_mutex_lock (&__SPE_EVENT_CONTEXT_PRIV_GET (spe) ->lock);
52 }
```


3.24.3.4 int _event_spe_context_run (spe_context_ptr_t spe, unsigned int *entry, unsigned int runflags, void *argp, void *envp, spe_stop_info_t *stopinfo)

Definition at line 477 of file spe_event.c.

References __SPE_EVENT_CONTEXT_PRIV_GET, _base_spe_context_run(), and spe_context_event_priv::stop_event_pipe.

```
478 {
479     spe_context_event_priv_ptr_t evctx;
480     spe_stop_info_t stopinfo_buf;
481     int rc;
482
483     if (!stopinfo) {
484         stopinfo = &stopinfo_buf;
485     }
486     rc = _base_spe_context_run(spe, entry, runflags, argp, envp, stopinfo);
487
488     evctx = __SPE_EVENT_CONTEXT_PRIV_GET (spe);
489     if (write(evctx->stop_event_pipe[1], stopinfo, sizeof(*stopinfo)) != sizeof(*stopinfo)) {
490         /* error check. */
491     }
492
493     return rc;
494 }
```

Here is the call graph for this function:



3.24.3.5 void _event_spe_context_unlock (spe_context_ptr_t spe)

Definition at line 54 of file spe_event.c.

References __SPE_EVENT_CONTEXT_PRIV_GET.

Referenced by _event_spe_event_handler_deregister(), _event_spe_event_handler_register(), and _event_spe_event_wait().

```
55 {
56     pthread_mutex_unlock (&__SPE_EVENT_CONTEXT_PRIV_GET (spe) ->lock);
57 }
```

3.24.3.6 `spe_event_handler_ptr_t _event_spe_event_handler_create (void)`

Definition at line 110 of file spe_event.c.

References `__SPE_EPOLL_FD_SET`, and `__SPE_EPOLL_SIZE`.

```

111 {
112     int epfd;
113     spe_event_handler_t *evhandler;
114
115     evhandler = calloc(1, sizeof(*evhandler));
116     if (!evhandler) {
117         return NULL;
118     }
119
120     epfd = epoll_create(__SPE_EPOLL_SIZE);
121     if (epfd == -1) {
122         free(evhandler);
123         return NULL;
124     }
125
126     __SPE_EPOLL_FD_SET(evhandler, epfd);
127
128     return evhandler;
129 }
```

3.24.3.7 `int _event_spe_event_handler_deregister (spe_event_handler_ptr_t evhandler, spe_event_unit_t * event)`

Definition at line 273 of file spe_event.c.


References `_base_spe_event_source_acquire()`, `__SPE_EPOLL_FD_GET`, `__SPE_EVENT_ALL`, `__SPE_EVENT_CONTEXT_PRIV_GET`, `__SPE_EVENT_IN_MBOX`, `__SPE_EVENT_OUT_INTR_MBOX`, `__SPE_EVENT_SPE_STOPPED`, `__SPE_EVENT_TAG_GROUP`, `__SPE_EVENTS_ENABLED`, `_event_spe_context_lock()`, `_event_spe_context_unlock()`, `spe_context_event_priv::events`, `spe_event_unit::events`, `FD_IBOX`, `FD_MFC`, `FD_WBOX`, `spe_event_unit::spe`, `SPE_EVENT_IN_MBOX`, `SPE_EVENT_OUT_INTR_MBOX`, `SPE_EVENT_SPE_STOPPED`, `SPE_EVENT_TAG_GROUP`, and `spe_context_event_priv::stop_event_pipe`.

```

274 {
275     int epfd;
276     const int ep_op = EPOLL_CTL_DEL;
277     spe_context_event_priv_ptr_t evctx;
278     int fd;
279
280     if (!evhandler) {
281         errno = ESRCH;
282         return -1;
283     }
284     if (!event || !event->spe) {
285         errno = EINVAL;
286         return -1;
287     }
288     if (!__SPE_EVENTS_ENABLED(event->spe)) {
289         errno = ENOTSUP;
290         return -1;
291     }
292
293     epfd = __SPE_EPOLL_FD_GET(evhandler);
294     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(event->spe);
295
296     if (event->events & ~__SPE_EVENT_ALL) {
```

```
297     errno = ENOTSUP;
298     return -1;
299 }
300
301 _event_spe_context_lock(event->spe); /* for spe->event_private->events */
302
303 if (event->events & SPE_EVENT_OUT_INTR_MBOX) {
304     fd = __base_spe_event_source_acquire(event->spe, FD_IBOX);
305     if (fd == -1) {
306         _event_spe_context_unlock(event->spe);
307         return -1;
308     }
309     if (epoll_ctl(epfd, ep_op, fd, NULL) == -1) {
310         _event_spe_context_unlock(event->spe);
311         return -1;
312     }
313     evctx->events[__SPE_EVENT_OUT_INTR_MBOX].events = 0;
314 }
315
316 if (event->events & SPE_EVENT_IN_MBOX) {
317     fd = __base_spe_event_source_acquire(event->spe, FD_WBOX);
318     if (fd == -1) {
319         _event_spe_context_unlock(event->spe);
320         return -1;
321     }
322     if (epoll_ctl(epfd, ep_op, fd, NULL) == -1) {
323         _event_spe_context_unlock(event->spe);
324         return -1;
325     }
326     evctx->events[__SPE_EVENT_IN_MBOX].events = 0;
327 }
328
329 if (event->events & SPE_EVENT_TAG_GROUP) {
330     fd = __base_spe_event_source_acquire(event->spe, FD_MFC);
331     if (fd == -1) {
332         _event_spe_context_unlock(event->spe);
333         return -1;
334     }
335     if (epoll_ctl(epfd, ep_op, fd, NULL) == -1) {
336         _event_spe_context_unlock(event->spe);
337         return -1;
338     }
339     evctx->events[__SPE_EVENT_TAG_GROUP].events = 0;
340 }
341
342 if (event->events & SPE_EVENT_SPE_STOPPED) {
343     fd = evctx->stop_event_pipe[0];
344     if (epoll_ctl(epfd, ep_op, fd, NULL) == -1) {
345         _event_spe_context_unlock(event->spe);
346         return -1;
347     }
348     evctx->events[__SPE_EVENT_SPE_STOPPED].events = 0;
349 }
350
351 _event_spe_context_unlock(event->spe);
352
353 return 0;
354 }
```

Here is the call graph for this function:



3.24.3.8 int _event_spe_event_handler_destroy (spe_event_handler_ptr_t evhandler)

Definition at line 135 of file spe_event.c.

References `__SPE_EPOLL_FD_GET`.

```

136 {
137     int epfd;
138
139     if (!evhandler) {
140         errno = ESRCH;
141         return -1;
142     }
143
144     epfd = __SPE_EPOLL_FD_GET(evhandler);
145     close(epfd);
146
147     free(evhandler);
148     return 0;
149 }
```

3.24.3.9 int _event_spe_event_handler_register (spe_event_handler_ptr_t evhandler, spe_event_unit_t * event)

Definition at line 155 of file spe_event.c.

References `__base_spe_event_source_acquire()`, `__SPE_EPOLL_FD_GET`, `__SPE_EVENT_ALL`, `__SPE_EVENT_CONTEXT_PRIV_GET`, `__SPE_EVENT_IN_MBOX`, `__SPE_EVENT_OUT_INTR_MBOX`, `__SPE_EVENT_SPE_STOPPED`, `__SPE_EVENT_TAG_GROUP`, `__SPE_EVENTS_ENABLED`, `_event_spe_context_lock()`, `_event_spe_context_unlock()`, `spe_context::base_private`, `spe_event_unit::data`, `spe_context_event_priv::events`, `spe_event_unit::events`, `FD_IBOX`, `FD_MFC`, `FD_WBOX`, `spe_context_base_priv::flags`, `spe_event_data::ptr`, `spe_event_unit::spe`, `SPE_EVENT_IN_MBOX`, `SPE_EVENT_OUT_INTR_MBOX`, `SPE_EVENT_SPE_STOPPED`, `SPE_EVENT_TAG_GROUP`, `SPE_MAP_PS`, and `spe_context_event_priv::stop_event_pipe`.

```

156 {
157     int epfd;
158     const int ep_op = EPOLL_CTL_ADD;
159     spe_context_event_priv_ptr_t evctx;
160     spe_event_unit_t *ev_buf;
161     struct epoll_event ep_event;
162     int fd;
163
164     if (!evhandler) {
165         errno = ESRCH;
166         return -1;
167     }
```


```

168     if (!event || !event->spe) {
169         errno = EINVAL;
170         return -1;
171     }
172     if (!__SPE_EVENTS_ENABLED(event->spe)) {
173         errno = ENOTSUP;
174         return -1;
175     }
176     epfd = __SPE_EPOLL_FD_GET(evhandler);
177     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(event->spe);
178     if (event->events & ~__SPE_EVENT_ALL) {
179         errno = ENOTSUP;
180         return -1;
181     }
182     _event_spe_context_lock(event->spe); /* for spe->event_private->events */
183     if (event->events & SPE_EVENT_OUT_INTR_MBOX) {
184         fd = __base_spe_event_source_acquire(event->spe, FD_IBOX);
185         if (fd == -1) {
186             _event_spe_context_unlock(event->spe);
187             return -1;
188         }
189         ev_buf = &evctx->events[__SPE_EVENT_OUT_INTR_MBOX];
190         ev_buf->events = SPE_EVENT_OUT_INTR_MBOX;
191         ev_buf->data = event->data;
192         ep_event.events = EPOLLIN;
193         ep_event.data.ptr = ev_buf;
194         if (epoll_ctl(epfd, EPOLLIN, fd, &ep_event) == -1) {
195             _event_spe_context_unlock(event->spe);
196             return -1;
197         }
198     }
199     if (event->events & SPE_EVENT_IN_MBOX) {
200         fd = __base_spe_event_source_acquire(event->spe, FD_WBOX);
201         if (fd == -1) {
202             _event_spe_context_unlock(event->spe);
203             return -1;
204         }
205         ev_buf = &evctx->events[__SPE_EVENT_IN_MBOX];
206         ev_buf->events = SPE_EVENT_IN_MBOX;
207         ev_buf->data = event->data;
208         ep_event.events = EPOLLOUT;
209         ep_event.data.ptr = ev_buf;
210         if (epoll_ctl(epfd, EPOLLOUT, fd, &ep_event) == -1) {
211             _event_spe_context_unlock(event->spe);
212             return -1;
213         }
214     }
215     if (event->events & SPE_EVENT_TAG_GROUP) {
216         fd = __base_spe_event_source_acquire(event->spe, FD_MFC);
217         if (fd == -1) {
218             _event_spe_context_unlock(event->spe);
219             return -1;
220         }
221         if (event->spe->base_private->flags & SPE_MAP_PS) {
222             _event_spe_context_unlock(event->spe);
223             errno = ENOTSUP;
224         }
225     }
226 }
```

```

235         return -1;
236     }
237
238     ev_buf = &evctx->events[___SPE_EVENT_TAG_GROUP];
239     ev_buf->events = SPE_EVENT_TAG_GROUP;
240     ev_buf->data = event->data;
241
242     ep_event.events = EPOLLIN;
243     ep_event.data.ptr = ev_buf;
244     if (epoll_ctl(epfd, EPOLLIN, fd, &ep_event) == -1) {
245         _event_spe_context_unlock(event->spe);
246         return -1;
247     }
248 }
249
250 if (event->events & SPE_EVENT_SPE_STOPPED) {
251     fd = evctx->stop_event_pipe[0];
252
253     ev_buf = &evctx->events[___SPE_EVENT_SPE_STOPPED];
254     ev_buf->events = SPE_EVENT_SPE_STOPPED;
255     ev_buf->data = event->data;
256
257     ep_event.events = EPOLLIN;
258     ep_event.data.ptr = ev_buf;
259     if (epoll_ctl(epfd, EPOLLIN, fd, &ep_event) == -1) {
260         _event_spe_context_unlock(event->spe);
261         return -1;
262     }
263 }
264
265 _event_spe_context_unlock(event->spe);
266
267 return 0;
268 }
```

Here is the call graph for this function:



3.24.3.10 int _event_spe_event_wait (spe_event_handler_ptr_t evhandler, spe_event_unit_t *events, int max_events, int timeout)

Definition at line 360 of file spe_event.c.

References `_SPE_EPOLL_FD_GET`, `_event_spe_context_lock()`, `_event_spe_context_unlock()`, and `spe_event_unit::spe`.

```


361 {
362     int epfd;
363     struct epoll_event *ep_events;
364     int rc;
365
366     if (!evhandler) {
367         errno = ESRCH;
368         return -1;
```

```

369 }
370 if (!events || max_events <= 0) {
371     errno = EINVAL;
372     return -1;
373 }
374
375 epfd = __SPE_EPOLL_FD_GET(evhandler);
376
377 ep_events = malloc(sizeof(*ep_events) * max_events);
378 if (!ep_events) {
379     return -1;
380 }
381
382 for ( ; ; ) {
383     rc = epoll_wait(epfd, ep_events, max_events, timeout);
384     if (rc == -1) { /* error */
385         if (errno == EINTR) {
386             if (timeout >= 0) { /* behave as timeout */
387                 rc = 0;
388                 break;
389             }
390             /* else retry */
391         }
392         else {
393             break;
394         }
395     }
396     else if (rc > 0) {
397         int i;
398         for (i = 0; i < rc; i++) {
399             spe_event_unit_t *ev = (spe_event_unit_t *) (ep_events[i].data.ptr);
400             _event_spe_context_lock(ev->spe); /* lock ev itself */
401             events[i] = *ev;
402             _event_spe_context_unlock(ev->spe);
403         }
404         break;
405     }
406     else { /* timeout */
407         break;
408     }
409 }
410
411 free(ep_events);
412
413 return rc;
414 }

```

Here is the call graph for this function:



3.24.3.11 int _event_spe_stop_info_read (spe_context_ptr_t spe, spe_stop_info_t *stopinfo)

Definition at line 59 of file spe_event.c.

References `__SPE_EVENT_CONTEXT_PRIV_GET`, `spe_context_event_priv::stop_event_pipe`, and `spe_context_event_priv::stop_event_read_lock`.

60 {

```
61     spe_context_event_priv_ptr_t evctx;
62     int rc;
63     int fd;
64     size_t total;
65
66     evctx = __SPE_EVENT_CONTEXT_PRIV_GET(spe);
67     fd = evctx->stop_event_pipe[0];
68
69     pthread_mutex_lock(&evctx->stop_event_read_lock); /* for atomic read */
70
71     rc = read(fd, stopinfo, sizeof(*stopinfo));
72     if (rc == -1) {
73         pthread_mutex_unlock(&evctx->stop_event_read_lock);
74         return -1;
75     }
76
77     total = rc;
78     while (total < sizeof(*stopinfo)) { /* this loop will be executed in few cases */
79         struct pollfd fds;
80         fds.fd = fd;
81         fds.events = POLLIN;
82         rc = poll(&fds, 1, -1);
83         if (rc == -1) {
84             if (errno != EINTR) {
85                 break;
86             }
87         }
88         else if (rc == 1) {
89             rc = read(fd, (char *)stopinfo + total, sizeof(*stopinfo) - total);
90             if (rc == -1) {
91                 if (errno != EAGAIN) {
92                     break;
93                 }
94             }
95             else {
96                 total += rc;
97             }
98         }
99     }
100    pthread_mutex_unlock(&evctx->stop_event_read_lock);
101
102    return rc == -1 ? -1 : 0;
103 }
```

Index

__NUM_SPE_EVENT_TYPES
speevent.h, 179

__SPE_EVENT_IN_MBOX
speevent.h, 179

__SPE_EVENT_OUT_INTR_MBOX
speevent.h, 179

__SPE_EVENT_SPE_STOPPED
speevent.h, 179

__SPE_EVENT_TAG_GROUP
speevent.h, 179

__PRINTF
elf_loader.c, 65
handler_utils.h, 76
spebase.h, 142

__SPE_EPOLL_FD_GET
spe_event.c, 129

__SPE_EPOLL_FD_SET
spe_event.c, 129

__SPE_EPOLL_SIZE
spe_event.c, 129

__SPE_EVENTS_ENABLED
spe_event.c, 130

__SPE_EVENT_ALL
spe_event.c, 129

__SPE_EVENT_CONTEXT_PRIV_GET
spe_event.c, 129

__SPE_EVENT_CONTEXT_PRIV_SET
spe_event.c, 129

__attribute__
accessors.c, 40

__base_spe_event_source_acquire
accessors.c, 40
spebase.h, 145

__base_spe_event_source_release
accessors.c, 40
spebase.h, 145

__base_spe_spe_dir_get
accessors.c, 40
spebase.h, 145

__base_spe_stop_event_source_get
accessors.c, 41
spebase.h, 146

__base_spe_stop_event_target_get
accessors.c, 41
spebase.h, 146

__reserved_ptr
spe_stop_info, 37

__reserved_u64
spe_stop_info, 37

__spe_context_update_event
spebase.h, 146

__spe_current_active_context
run.c, 127

__spe_event_types
speevent.h, 179

_base_spe_callback_handler_deregister
lib_builtin.c, 90
spebase.h, 146

_base_spe_callback_handler_query
lib_builtin.c, 90
spebase.h, 147

_base_spe_callback_handler_register
lib_builtin.c, 90
spebase.h, 147

_base_spe_close_if_open
create.c, 45
create.h, 52

_base_spe_context_create
create.c, 45
spebase.h, 148

_base_spe_context_destroy
create.c, 48
spebase.h, 151

_base_spe_context_lock
create.c, 49
spebase.h, 152

_base_spe_context_run
run.c, 122
spebase.h, 152

_base_spe_context_unlock
create.c, 49
spebase.h, 157

_base_spe_count_physical_cpus
info.c, 83
info.h, 86

_base_spe_count_physical_spes
info.c, 84
info.h, 87

_base_spe_count_usable_spes
info.c, 84

info.h, 88
`_base_spe_cpu_info_get`
 info.c, 85
 spebase.h, 157
`_base_spe_emulated_loader_present`
 load.c, 108
 spebase.h, 158
`_base_spe_gang_context_create`
 create.c, 49
 spebase.h, 158
`_base_spe_gang_context_destroy`
 create.c, 50
 spebase.h, 159
`_base_spe_handle_library_callback`
 lib_builtin.c, 91
 lib_builtin.h, 94
`_base_spe_image_close`
 image.c, 79
 spebase.h, 159
`_base_spe_image_open`
 image.c, 80
 spebase.h, 160
`_base_spe_in_mbox_status`
 mbox.c, 111
 spebase.h, 162
`_base_spe_in_mbox_write`
 mbox.c, 112
 spebase.h, 163
`_base_spe_load_spe_elf`
 elf_loader.c, 65
 elf_loader.h, 71
`_base_spe_ls_area_get`
 accessors.c, 41
 spebase.h, 163
`_base_spe_ls_size_get`
 accessors.c, 41
 spebase.h, 163
`_base_spe_mfcio_get`
 dma.c, 56
 spebase.h, 164
`_base_spe_mfcio_getb`
 dma.c, 56
 spebase.h, 164
`_base_spe_mfcio_getf`
 dma.c, 57
 spebase.h, 165
`_base_spe_mfcio_put`
 dma.c, 57
 spebase.h, 165
`_base_spe_mfcio_putb`
 dma.c, 58
 spebase.h, 166
`_base_spe_mfcio_putf`
 dma.c, 58

spebase.h, 167
`_base_spe_mfcio_tag_status_read`
 dma.c, 59
 spebase.h, 167
`_base_spe_mssync_start`
 dma.c, 59
 spebase.h, 168
`_base_spe_mssync_status`
 dma.c, 60
 spebase.h, 169
`_base_spe_open_if_closed`
 create.c, 50
 create.h, 53
`_base_spe_out_intr_mbox_read`
 mbox.c, 114
 spebase.h, 169
`_base_spe_out_intr_mbox_status`
 mbox.c, 115
 spebase.h, 170
`_base_spe_out_mbox_read`
 mbox.c, 116
 spebase.h, 171
`_base_spe_out_mbox_status`
 mbox.c, 117
 spebase.h, 172
`_base_spe_parse_isolated_elf`
 elf_loader.c, 66
 elf_loader.h, 72
`_base_spe_program_load`
 load.c, 109
 spebase.h, 173
`_base_spe_program_load_complete`
 load.c, 110
 spebase.h, 174
`_base_spe_ps_area_get`
 accessors.c, 42
 spebase.h, 175
`_base_spe_signal_write`
 mbox.c, 117
 spebase.h, 175
`_base_spe_stop_reason_get`
 spebase.h, 176
`_base_spe_stop_status_get`
 spebase.h, 177
`_base_spe_toe_ear`
 elf_loader.c, 67
 elf_loader.h, 73
`_base_spe_verify_spe_elf_image`
 elf_loader.c, 68
 elf_loader.h, 74
`_event_spe_context_finalize`
 spe_event.c, 130
 speevent.h, 179
`_event_spe_context_initialize`

spe_event.c, 130
speevent.h, 180
`_event_spe_context_lock`
 spe_event.c, 131
 speevent.h, 180
`_event_spe_context_run`
 spe_event.c, 131
 speevent.h, 181
`_event_spe_context_unlock`
 spe_event.c, 132
 speevent.h, 181
`_event_spe_event_handler_create`
 spe_event.c, 132
 speevent.h, 181
`_event_spe_event_handler_deregister`
 spe_event.c, 132
 speevent.h, 182
`_event_spe_event_handler_destroy`
 spe_event.c, 134
 speevent.h, 184
`_event_spe_event_handler_register`
 spe_event.c, 134
 speevent.h, 184
`_event_spe_event_wait`
 spe_event.c, 137
 speevent.h, 186
`_event_spe_stop_info_read`
 spe_event.c, 138
 speevent.h, 187

accessors.c, 39
 `__attribute__, 40`
 `_base_spe_event_source_acquire, 40`
 `_base_spe_event_source_release, 40`
 `_base_spe_spe_dir_get, 40`
 `_base_spe_stop_event_source_get, 41`
 `_base_spe_stop_event_target_get, 41`
 `_base_spe_ls_area_get, 41`
 `_base_spe_ls_size_get, 41`
 `_base_spe_ps_area_get, 42`

active_tagmask
 spe_context_base_priv, 15

addr64, 5
 ui, 5
 ull, 5

base_private
 spe_context, 11
 spe_gang_context, 23

cbea_map.h, 43
 spe_mfc_command_area_t, 43
 spe_mssync_area_t, 43
 spe_sig_notify_1_area_t, 43

spe_sig_notify_2_area_t, 43
spe_spu_control_area_t, 43

class
 mfc_command_parameter_area, 8

cmd
 mfc_command_parameter_area, 8

ctl mmap_base
 spe_context_base_priv, 14

CNTL_OFFSET
 spebase.h, 142

CNTL_SIZE
 spebase.h, 142

create.c, 44
 `_base_spe_close_if_open, 45`
 `_base_spe_context_create, 45`
 `_base_spe_context_destroy, 48`
 `_base_spe_context_lock, 49`
 `_base_spe_context_unlock, 49`
 `_base_spe_gang_context_create, 49`
 `_base_spe_gang_context_destroy, 50`
 `_base_spe_open_if_closed, 50`

create.h, 52
 `_base_spe_close_if_open, 52`
 `_base_spe_open_if_closed, 53`

data
 spe_event_unit, 22

DEBUG_PRINTF
 elf_loader.c, 65
 handler_utils.h, 76
 spebase.h, 142

DECL_0_ARGS
 handler_utils.h, 76

DECL_1_ARGS
 handler_utils.h, 76

DECL_2_ARGS
 handler_utils.h, 76

DECL_3_ARGS
 handler_utils.h, 77

DECL_4_ARGS
 handler_utils.h, 77

DECL_5_ARGS
 handler_utils.h, 77

DECL_6_ARGS
 handler_utils.h, 77

DECL_RET
 handler_utils.h, 77

design.txt, 54

dma.c, 55
 `_base_spe_mfcio_get, 56`
 `_base_spe_mfcio_getb, 56`
 `_base_spe_mfcio_getf, 57`
 `_base_spe_mfcio_put, 57`
 `_base_spe_mfcio_putb, 58`

_base_spe_mfcio_putf, 58
 _base_spe_mfcio_tag_status_read, 59
 _base_spe_mssync_start, 59
 _base_spe_mssync_status, 60
 dma.h, 62
 MFC_CMD_GET, 62
 MFC_CMD_GETB, 62
 MFC_CMD_GETF, 63
 MFC_CMD_PUT, 62
 MFC_CMD_PUTB, 62
 MFC_CMD_PUTF, 62
 mfc_cmd, 62

 ea
 mfc_command_parameter_area, 8
 elf_image
 spe_program_handle, 30
 elf_loader.c, 64
 __PRINTF, 65
 _base_spe_load_spe_elf, 65
 _base_spe_parse_isolated_elf, 66
 _base_spe_toe_ear, 67
 _base_spe_verify_spe_elf_image, 68
 DEBUG_PRINTF, 65
 TAG, 65
 elf_loader.h, 70
 _base_spe_load_spe_elf, 71
 _base_spe_parse_isolated_elf, 72
 _base_spe_toe_ear, 73
 _base_spe_verify_spe_elf_image, 74
 LS_SIZE, 71
 SPE_LDR_PARAMS_start, 71
 SPE_LDR_PROG_start, 71
 emulated_entry
 spe_context_base_priv, 15
 entry
 spe_context_base_priv, 15
 spe_ld_info, 25
 ev_pipe
 spe_context_base_priv, 14
 event_private
 spe_context, 11
 spe_gang_context, 23
 events
 spe_context_event_priv, 17
 spe_event_unit, 22

 FD_IBOX
 spebase.h, 144
 FD_IBOX_NB
 spebase.h, 144
 FD_IBOX_STAT
 spebase.h, 144
 FD_MBOX

 spebase.h, 144
 FD_MBOX_STAT
 spebase.h, 144
 FD_MFC
 spebase.h, 144
 FD_MSS
 spebase.h, 144
 FD_SIG1
 spebase.h, 144
 FD_SIG2
 spebase.h, 144
 FD_WBOX
 spebase.h, 144
 FD_WBOX_NB
 spebase.h, 144
 FD_WBOX_STAT
 spebase.h, 144
 fd_attr, 6
 mode, 6
 name, 6
 fd_gang_dir
 spe_gang_context_base_priv, 24
 fd_grp_dir
 spe_context_base_priv, 13
 fd_lock
 spe_context_base_priv, 13
 fd_name
 spebase.h, 144
 fd_spe_dir
 spe_context_base_priv, 13
 flags
 spe_context_base_priv, 13
 spe_gang_context_base_priv, 24

 gangname
 spe_gang_context_base_priv, 24
 GET_LS_PTR
 handler_utils.h, 77
 GET_LS_PTR_NULL
 handler_utils.h, 78
 GNU_SOURCE
 run.c, 122

 handle
 spe_context, 11
 handle_size
 spe_program_handle, 30
 HANDLER_IDX
 lib_builtin.c, 89
 handler_utils.h, 76
 __PRINTF, 76
 DEBUG_PRINTF, 76
 DECL_0_ARGS, 76
 DECL_1_ARGS, 76

DECL_2_ARGS, 76
DECL_3_ARGS, 77
DECL_4_ARGS, 77
DECL_5_ARGS, 77
DECL_6_ARGS, 77
DECL_RET, 77
GET_LS_PTR, 77
GET_LS_PTR_NULL, 78
LS_ADDR_MASK, 78
LS_ARG_ADDR, 78
LS_SIZE, 78
PUT_LS_RC, 78

image.c, 79
 _base_spe_image_close, 79
 _base_spe_image_open, 80

image_handle, 7
 map_size, 7
 speh, 7

info.c, 83
 _base_spe_count_physical_cpus, 83
 _base_spe_count_physical_spes, 84
 _base_spe_count_usable_spes, 84
 _base_spe_cpu_info_get, 85

info.h, 86
 _base_spe_count_physical_cpus, 86
 _base_spe_count_physical_spes, 87
 _base_spe_count_usable_spes, 88
 THREADS_PER_BE, 86

lib_builtin.c, 89
 _base_spe_callback_handler_deregister, 90
 _base_spe_callback_handler_query, 90
 _base_spe_callback_handler_register, 90
 _base_spe_handle_library_callback, 91
 HANDLER_IDX, 89

lib_builtin.h, 93
 _base_spe_handle_library_callback, 94
 MAX_CALLNUM, 93
 RESERVED, 93

libspe2-types.h, 95
 ps_area, 103
 SIGSPE, 97
 SPE_CONTROL_AREA, 103
 SPE_MFC_COMMAND_AREA, 103
 SPE_MSSYNC_AREA, 103
 SPE_SIG_NOTIFY_1_AREA, 103
 SPE_SIG_NOTIFY_2_AREA, 103
 SPE_AFFINITY_MEMORY, 97
 SPE_CALLBACK_ERROR, 97
 SPE_CALLBACK_NEW, 97
 SPE_CALLBACK_UPDATE, 97
 SPE_CFG_SIGNIFY1_OR, 97
 SPE_CFG_SIGNIFY2_OR, 97

spe_context_ptr_t, 102
SPE_COUNT_PHYSICAL_CPU_NODES, 97
SPE_COUNT_PHYSICAL_SPES, 97
SPE_COUNT_USABLE_SPES, 98
SPE_DEFAULT_ENTRY, 98
SPE_DMA_ALIGNMENT, 98
SPE_DMA_SEGMENTATION, 98
SPE_DMA_STORAGE, 98
SPE_EVENT_ALL_EVENTS, 98
spe_event_data_t, 102
spe_event_handler_ptr_t, 102
spe_event_handler_t, 102
SPE_EVENT_IN_MBOX, 98
SPE_EVENT_OUT_INTR_MBOX, 98
SPE_EVENT_SPE_STOPPED, 99
SPE_EVENT_TAG_GROUP, 99
spe_event_unit_t, 102
SPE_EVENTS_ENABLE, 99
SPE_EXIT, 99
spe_gang_context_ptr_t, 103
SPE_ISOLATE, 99
SPE_ISOLATE_EMULATE, 99
SPE_ISOLATION_ERROR, 99
SPE_MAP_PS, 99
SPE_MBOX_ALL_BLOCKING, 100
SPE_MBOX_ANY_BLOCKING, 100
SPE_MBOX_ANY_NONBLOCKING, 100
SPE_NO_CALLBACKS, 100
spe_program_handle_t, 103
SPE_RUN_USER_REGS, 100
SPE_RUNTIME_ERROR, 100
SPE_RUNTIME_EXCEPTION, 100
SPE_RUNTIME_FATAL, 100
SPE_SIG_NOTIFY_REG_1, 101
SPE_SIG_NOTIFY_REG_2, 101
SPE_SPU_HALT, 101
SPE_SPU_INVALID_CHANNEL, 101
SPE_SPU_INVALID_INSTR, 101
SPE_SPU_SINGLE_STEP, 101
SPE_SPU_STOPPED_BY_STOP, 101
SPE_SPU_WAITING_ON_CHANNEL, 101
SPE_STOP_AND_SIGNAL, 102
spe_stop_info_t, 103
SPE_TAG_ALL, 102
SPE_TAG_ANY, 102
SPE_TAG_IMMEDIATE, 102

libspe2.h, 104
 spe_callback_handler_deregister, 107
 spe_callback_handler_query, 107
 spe_callback_handler_register, 107
 spe_context_create, 107
 spe_context_create_affinity, 107
 spe_context_destroy, 107

spe_context_run, 107
 spe_cpu_info_get, 107
 spe_event_handler_create, 107
 spe_event_handler_deregister, 107
 spe_event_handler_destroy, 107
 spe_event_handler_register, 107
 spe_event_wait, 107
 spe_gang_context_create, 107
 spe_gang_context_destroy, 107
 spe_image_close, 107
 spe_image_open, 107
 spe_in_mbox_status, 107
 spe_in_mbox_write, 107
 spe_ls_area_get, 107
 spe_ls_size_get, 107
 spe_mfcio_get, 107
 spe_mfcio_getb, 107
 spe_mfcio_getf, 107
 spe_mfcio_put, 107
 spe_mfcio_putb, 107
 spe_mfcio_putf, 107
 spe_mfcio_tag_status_read, 107
 spe_mssync_start, 107
 spe_mssync_status, 107
 spe_out_intr_mbox_read, 107
 spe_out_intr_mbox_status, 107
 spe_out_mbox_read, 107
 spe_out_mbox_status, 107
 spe_program_load, 107
 spe_ps_area_get, 107
 spe_signal_write, 107
 spe_stop_info_read, 107
 load.c, 108
 _base_spe_emulated_loader_present, 108
 _base_spe_program_load, 109
 _base_spe_program_load_complete, 110
 SPE_EMULATED_LOADER_FILE, 108
 loaded_program
 spe_context_base_priv, 15
 lock
 spe_context_event_priv, 17
 LS_ADDR_MASK
 handler_utils.h, 78
 LS_ARG_ADDR
 handler_utils.h, 78
 LS_SIZE
 elf_loader.h, 71
 handler_utils.h, 78
 spebase.h, 142
 lsa
 mfc_command_parameter_area, 8
 map_size
 image_handle, 7
 MAX_CALLNUM
 lib_builtin.h, 93
 mbox.c, 111
 _base_spe_in_mbox_status, 111
 _base_spe_in_mbox_write, 112
 _base_spe_out_intr_mbox_read, 114
 _base_spe_out_intr_mbox_status, 115
 _base_spe_out_mbox_read, 116
 _base_spe_out_mbox_status, 117
 _base_spe_signal_write, 117
 mbox.h, 120
 mem_mmap_base
 spe_context_base_priv, 14
 MFC_CMD_GET
 dma.h, 62
 MFC_CMD_GETB
 dma.h, 62
 MFC_CMD_GETF
 dma.h, 63
 MFC_CMD_PUT
 dma.h, 62
 MFC_CMD_PUTB
 dma.h, 62
 MFC_CMD_PUTF
 dma.h, 62
 MFC_ClassID_CMD
 spe_mfc_command_area, 27
 mfc_cmd
 dma.h, 62
 MFC_CMDStatus
 spe_mfc_command_area, 27
 mfc_command_parameter_area, 8
 class, 8
 cmd, 8
 ea, 8
 lsa, 8
 pad, 8
 size, 8
 tag, 8
 MFC_EAH
 spe_mfc_command_area, 26
 MFC_EAL
 spe_mfc_command_area, 26
 MFC_LSA
 spe_mfc_command_area, 26
 mfc_mmap_base
 spe_context_base_priv, 14
 MFC_MSSync
 spe_mssync_area, 29
 MFC_OFFSET
 spebase.h, 142
 MFC_QStatus
 spe_mfc_command_area, 27
 MFC_SIZE

spebase.h, 143
MFC_Size_Tag
 spe_mfc_command_area, 26
mode
 fd_attr, 6
MSS_SIZE
 spebase.h, 143
mssync_mmap_base
 spe_context_base_priv, 14
MSSYNC_OFFSET
 spebase.h, 143

name
 fd_attr, 6
npc
 spe_context_info, 18
NUM_MBOX_FDS
 spebase.h, 144

pad
 mfc_command_parameter_area, 8
prev
 spe_context_info, 18
Prxy_QueryMask
 spe_mfc_command_area, 27
Prxy_QueryType
 spe_mfc_command_area, 27
Prxy_TagStatus
 spe_mfc_command_area, 27
ps_area
 libspe2-types.h, 103
psmap_mmap_base
 spe_context_base_priv, 14
PSMAP_SIZE
 spebase.h, 143
ptr
 spe_event_data, 19
PUT_LS_RC
 handler_utils.h, 78

RESERVED
 lib_builtin.h, 93
reserved_0_3
 spe_mfc_command_area, 26
 spe_spu_control_area, 34
reserved_0_B
 spe_sig_notify_1_area, 32
 spe_sig_notify_2_area, 33
reserved_108_203
 spe_mfc_command_area, 27
reserved_10_13
 spe_spu_control_area, 34
reserved_18_103
 spe_mfc_command_area, 27

reserved_18_1B
 spe_spu_control_area, 35
reserved_208_21B
 spe_mfc_command_area, 27
reserved_20_23
 spe_spu_control_area, 35
reserved_220_22B
 spe_mfc_command_area, 27
reserved_28_33
 spe_spu_control_area, 35
reserved_8_B
 spe_spu_control_area, 34
result
 spe_stop_info, 37
run.c, 121
 _spe_current_active_context, 127
 _base_spe_context_run, 122
 GNU_SOURCE, 122

signal1_mmap_base
 spe_context_base_priv, 14
SIGNAL1_OFFSET
 spebase.h, 143
signal2_mmap_base
 spe_context_base_priv, 14
SIGNAL2_OFFSET
 spebase.h, 143
SIGNAL_SIZE
 spebase.h, 143
SIGSPE
 libspe2-types.h, 97
size
 mfc_command_parameter_area, 8
slot
 spe_reg128, 31
spe
 spe_event_unit, 22
SPE_CONTROL_AREA
 libspe2-types.h, 103
SPE_MFC_COMMAND_AREA
 libspe2-types.h, 103
SPE_MSSYNC_AREA
 libspe2-types.h, 103
SPE_SIG_NOTIFY_1_AREA
 libspe2-types.h, 103
SPE_SIG_NOTIFY_2_AREA
 libspe2-types.h, 103
SPE_AFFINITY_MEMORY
 libspe2-types.h, 97
SPE_CALLBACK_ERROR
 libspe2-types.h, 97
spe_callback_error
 spe_stop_info, 37
spe_callback_handler_deregister

libspe2.h, 107
 spe_callback_handler_query
 libspe2.h, 107
 spe_callback_handler_register
 libspe2.h, 107
 SPE_CALLBACK_NEW
 libspe2-types.h, 97
 SPE_CALLBACK_UPDATE
 libspe2-types.h, 97
 SPE_CFG_SIGNNOTIFY1_OR
 libspe2-types.h, 97
 SPE_CFG_SIGNNOTIFY2_OR
 libspe2-types.h, 97
 spe_context, 10
 base_private, 11
 event_private, 11
 handle, 11
 spe_context_base_priv, 12
 active_tagmask, 15
 cntl_mmap_base, 14
 emulated_entry, 15
 entry, 15
 ev_pipe, 14
 fd_grp_dir, 13
 fd_lock, 13
 fd_spe_dir, 13
 flags, 13
 loaded_program, 15
 mem_mmap_base, 14
 mfc_mmap_base, 14
 mssync_mmap_base, 14
 psmap_mmap_base, 14
 signal1_mmap_base, 14
 signal2_mmap_base, 14
 spe_fds_array, 13
 spe_fds_refcount, 13
 spe_context_create
 libspe2.h, 107
 spe_context_create_affinity
 libspe2.h, 107
 spe_context_destroy
 libspe2.h, 107
 spe_context_event_priv, 16
 events, 17
 lock, 17
 stop_event_pipe, 17
 stop_event_read_lock, 17
 spe_context_event_priv_ptr_t
 speevent.h, 179
 spe_context_event_priv_t
 speevent.h, 179
 spe_context_info, 18
 npc, 18
 prev, 18
 spe_id, 18
 status, 18
 spe_context_ptr_t
 libspe2-types.h, 102
 spe_context_run
 libspe2.h, 107
 SPE_COUNT_PHYSICAL_CPU_NODES
 libspe2-types.h, 97
 SPE_COUNT_PHYSICAL_SPES
 libspe2-types.h, 97
 SPE_COUNT_USABLE_SPES
 libspe2-types.h, 98
 spe_cpu_info_get
 libspe2.h, 107
 SPE_DEFAULT_ENTRY
 libspe2-types.h, 98
 SPE_DMA_ALIGNMENT
 libspe2-types.h, 98
 SPE_DMA_SEGMENTATION
 libspe2-types.h, 98
 SPE_DMA_STORAGE
 libspe2-types.h, 98
 SPE_EMULATE_PARAM_BUFFER
 spebase.h, 143
 SPE_EMULATED_LOADER_FILE
 load.c, 108
 spe_event.c, 128
 __SPE_EPOLL_FD_GET, 129
 __SPE_EPOLL_FD_SET, 129
 __SPE_EPOLL_SIZE, 129
 __SPE_EVENTS_ENABLED, 130
 __SPE_EVENT_ALL, 129
 __SPE_EVENT_CONTEXT_PRIV_GET, 129
 __SPE_EVENT_CONTEXT_PRIV_SET, 129
 event_spe_context_finalize, 130
 event_spe_context_initialize, 130
 event_spe_context_lock, 131
 event_spe_context_run, 131
 event_spe_context_unlock, 132
 event_spe_event_handler_create, 132
 event_spe_event_handler_deregister, 132
 event_spe_event_handler_destroy, 134
 event_spe_event_handler_register, 134
 event_spe_event_wait, 137
 event_spe_stop_info_read, 138
 SPE_EVENT_ALL_EVENTS
 libspe2-types.h, 98
 spe_event_data, 19
 ptr, 19
 u32, 19
 u64, 19
 spe_event_data_t
 libspe2-types.h, 102

spe_event_handler_create
 libspe2.h, 107
spe_event_handler_deregister
 libspe2.h, 107
spe_event_handler_destroy
 libspe2.h, 107
spe_event_handler_ptr_t
 libspe2-types.h, 102
spe_event_handler_register
 libspe2.h, 107
spe_event_handler_t
 libspe2-types.h, 102
SPE_EVENT_IN_MBOX
 libspe2-types.h, 98
SPE_EVENT_OUT_INTR_MBOX
 libspe2-types.h, 98
SPE_EVENT_SPE_STOPPED
 libspe2-types.h, 99
SPE_EVENT_TAG_GROUP
 libspe2-types.h, 99
spe_event_unit, 20
 data, 22
 events, 22
 spe, 22
spe_event_unit_t
 libspe2-types.h, 102
spe_event_wait
 libspe2.h, 107
SPE_EVENTS_ENABLE
 libspe2-types.h, 99
SPE_EXIT
 libspe2-types.h, 99
spe_exit_code
 spe_stop_info, 36
spe_fds_array
 spe_context_base_priv, 13
spe_fds_refcount
 spe_context_base_priv, 13
spe_gang_context, 23
 base_private, 23
 event_private, 23
spe_gang_context_base_priv, 24
 fd_gang_dir, 24
 flags, 24
 gangname, 24
spe_gang_context_create
 libspe2.h, 107
spe_gang_context_destroy
 libspe2.h, 107
spe_gang_context_ptr_t
 libspe2-types.h, 103
spe_id
 spe_context_info, 18
spe_image_close
 libspe2.h, 107
spe_image_open
 libspe2.h, 107
spe_in_mbox_status
 libspe2.h, 107
spe_in_mbox_write
 libspe2.h, 107
SPE_ISOLATE
 libspe2-types.h, 99
SPE_ISOLATE_EMULATE
 libspe2-types.h, 99
SPE_ISOLATION_ERROR
 libspe2-types.h, 99
spe_isolation_error
 spe_stop_info, 37
spe_ld_info, 25
 entry, 25
SPE_LDR_PARAMS_start
 elf_loader.h, 71
SPE_LDR_PROG_start
 elf_loader.h, 71
spe_ls_area_get
 libspe2.h, 107
spe_ls_size_get
 libspe2.h, 107
SPE_MAP_PS
 libspe2-types.h, 99
SPE_MBOX_ALL_BLOCKING
 libspe2-types.h, 100
SPE_MBOX_ANY_BLOCKING
 libspe2-types.h, 100
SPE_MBOX_ANY_NONBLOCKING
 libspe2-types.h, 100
spe_mfc_command_area, 26
 MFC_ClassID_CMD, 27
 MFC_CMDStatus, 27
 MFC_EAH, 26
 MFC_EAL, 26
 MFC_LSA, 26
 MFC_QStatus, 27
 MFC_Size_Tag, 26
 Prxy_QueryMask, 27
 Prxy_QueryType, 27
 Prxy_TagStatus, 27
 reserved_0_3, 26
 reserved_108_203, 27
 reserved_18_103, 27
 reserved_208_21B, 27
 reserved_220_22B, 27
spe_mfc_command_area_t
 cbea_map.h, 43
spe_mfcio_get
 libspe2.h, 107
spe_mfcio_getb

libspe2.h, 107
 spe_mfcio_getf
 libspe2.h, 107
 spe_mfcio_put
 libspe2.h, 107
 spe_mfcio_putb
 libspe2.h, 107
 spe_mfcio_putf
 libspe2.h, 107
 spe_mfcio_tag_status_read
 libspe2.h, 107
 spe_mssync_area, 29
 MFC_MSSync, 29
 spe_mssync_area_t
 cbea_map.h, 43
 spe_mssync_start
 libspe2.h, 107
 spe_mssync_status
 libspe2.h, 107
SPE_NO_CALLBACKS
 libspe2-types.h, 100
 spe_out_intr_mbox_read
 libspe2.h, 107
 spe_out_intr_mbox_status
 libspe2.h, 107
 spe_out_mbox_read
 libspe2.h, 107
 spe_out_mbox_status
 libspe2.h, 107
 spe_program_handle, 30
 elf_image, 30
 handle_size, 30
 toe_shadow, 30
 spe_program_handle_t
 libspe2-types.h, 103
SPE_PROGRAM_ISO_LOAD_COMPLETE
 spebase.h, 144
SPE_PROGRAM_ISOLATED_STOP
 spebase.h, 144
SPE_PROGRAM_LIBRARY_CALL
 spebase.h, 144
 spe_program_load
 libspe2.h, 107
SPE_PROGRAM_NORMAL_END
 spebase.h, 144
 spe_ps_area_get
 libspe2.h, 107
 spe_reg128, 31
 slot, 31
SPE_RUN_USER_REGS
 libspe2-types.h, 100
SPE_RUNTIME_ERROR
 libspe2-types.h, 100
 spe_runtime_error

spe_stop_info, 36
SPE_RUNTIME_EXCEPTION
 libspe2-types.h, 100
 spe_runtime_exception
 spe_stop_info, 36
SPE_RUNTIME_FATAL
 libspe2-types.h, 100
 spe_runtime_fatal
 spe_stop_info, 37
 spe_sig_notify_1_area, 32
 reserved_0_B, 32
 SPU_Sig_Notify_1, 32
 spe_sig_notify_1_area_t
 cbea_map.h, 43
 spe_sig_notify_2_area, 33
 reserved_0_B, 33
 SPU_Sig_Notify_2, 33
 spe_sig_notify_2_area_t
 cbea_map.h, 43
SPE_SIG_NOTIFY_REG_1
 libspe2-types.h, 101
SPE_SIG_NOTIFY_REG_2
 libspe2-types.h, 101
 spe_signal_code
 spe_stop_info, 36
 spe_signal_write
 libspe2.h, 107
 spe_spu_control_area, 34
 reserved_0_3, 34
 reserved_10_13, 34
 reserved_18_1B, 35
 reserved_20_23, 35
 reserved_28_33, 35
 reserved_8_B, 34
 SPU_In_Mbox, 34
 SPU_Mbox_Stat, 34
 SPU_NPC, 35
 SPU_Out_Mbox, 34
 SPU_RunCntl, 35
 SPU_Status, 35
 spe_spu_control_area_t
 cbea_map.h, 43
SPE_SPU_HALT
 libspe2-types.h, 101
SPE_SPU_INVALID_CHANNEL
 libspe2-types.h, 101
SPE_SPU_INVALID_INSTR
 libspe2-types.h, 101
SPE_SPU_SINGLE_STEP
 libspe2-types.h, 101
SPE_SPU_STOPPED_BY_STOP
 libspe2-types.h, 101
SPE_SPU_WAITING_ON_CHANNEL
 libspe2-types.h, 101

SPE_STOP_AND_SIGNAL
 libspe2-types.h, 102

spe_stop_info, 36
 __reserved_ptr, 37
 __reserved_u64, 37
 result, 37
 spe_callback_error, 37
 spe_exit_code, 36
 spe_isolation_error, 37
 spe_runtime_error, 36
 spe_runtime_exception, 36
 spe_runtime_fatal, 37
 spe_signal_code, 36
 spu_status, 37
 stop_reason, 36

spe_stop_info_read
 libspe2.h, 107

spe_stop_info_t
 libspe2-types.h, 103

SPE_TAG_ALL
 libspe2-types.h, 102

SPE_TAG_ANY
 libspe2-types.h, 102

SPE_TAG_IMMEDIATE
 libspe2-types.h, 102

spebase.h, 140
 __PRINTF, 142
 __base_spe_event_source_acquire, 145
 __base_spe_event_source_release, 145
 __base_spe_spe_dir_get, 145
 __base_spe_stop_event_source_get, 146
 __base_spe_stop_event_target_get, 146
 __spe_context_update_event, 146
 __base_spe_callback_handler_deregister, 146
 __base_spe_callback_handler_query, 147
 __base_spe_callback_handler_register, 147
 __base_spe_context_create, 148
 __base_spe_context_destroy, 151
 __base_spe_context_lock, 152
 __base_spe_context_run, 152
 __base_spe_context_unlock, 157
 __base_spe_cpu_info_get, 157
 __base_spe_emulated_loader_present, 158
 __base_spe_gang_context_create, 158
 __base_spe_gang_context_destroy, 159
 __base_spe_image_close, 159
 __base_spe_image_open, 160
 __base_spe_in_mbox_status, 162
 __base_spe_in_mbox_write, 163
 __base_spe_ls_area_get, 163
 __base_spe_ls_size_get, 163
 __base_spe_mfcio_get, 164
 __base_spe_mfcio_getb, 164
 __base_spe_mfcio_getf, 165
 __base_spe_mfcio_put, 165
 __base_spe_mfcio_putb, 166
 __base_spe_mfcio_putf, 167
 __base_spe_mfcio_tag_status_read, 167
 __base_spe_msSync_start, 168
 __base_spe_msSync_status, 169
 __base_spe_out_intr_mbox_read, 169
 __base_spe_out_intr_mbox_status, 170
 __base_spe_out_mbox_read, 171
 __base_spe_out_mbox_status, 172
 __base_spe_program_load, 173
 __base_spe_program_load_complete, 174
 __base_spe_ps_area_get, 175
 __base_spe_signal_write, 175
 __base_spe_stop_reason_get, 176
 __base_spe_stop_status_get, 177
 CNTL_OFFSET, 142
 CNTL_SIZE, 142
 DEBUG_PRINTF, 142
 FD_IBOX, 144
 FD_IBOX_NB, 144
 FD_IBOX_STAT, 144
 FD_MBOX, 144
 FD_MBOX_STAT, 144
 FD_MFC, 144
 FD_MSS, 144
 FD_SIG1, 144
 FD_SIG2, 144
 FD_WBOX, 144
 FD_WBOX_NB, 144
 FD_WBOX_STAT, 144
 fd_name, 144
 LS_SIZE, 142
 MFC_OFFSET, 142
 MFC_SIZE, 143
 MSS_SIZE, 143
 MSYNC_OFFSET, 143
 NUM_MBOX_FDS, 144
 PSMAP_SIZE, 143
 SIGNAL1_OFFSET, 143
 SIGNAL2_OFFSET, 143
 SIGNAL_SIZE, 143
 SPE_EMULATE_PARAM_BUFFER, 143
 SPE_PROGRAM_ISO_LOAD_COMPLETE, 144
 SPE_PROGRAM_ISOLATED_STOP, 144
 SPE_PROGRAM_LIBRARY_CALL, 144
 SPE_PROGRAM_NORMAL_END, 144

speevent.h, 178
 __NUM_SPE_EVENT_TYPES, 179
 __SPE_EVENT_IN_MBOX, 179
 __SPE_EVENT_OUT_INTR_MBOX, 179
 __SPE_EVENT_SPE_STOPPED, 179
 __SPE_EVENT_TAG_GROUP, 179

<code>__spe_event_types</code> , 179 <code>_event_spe_context_finalize</code> , 179 <code>_event_spe_context_initialize</code> , 180 <code>_event_spe_context_lock</code> , 180 <code>_event_spe_context_run</code> , 181 <code>_event_spe_context_unlock</code> , 181 <code>_event_spe_event_handler_create</code> , 181 <code>_event_spe_event_handler_deregister</code> , 182 <code>_event_spe_event_handler_destroy</code> , 184 <code>_event_spe_event_handler_register</code> , 184 <code>_event_spe_event_wait</code> , 186 <code>_event_spe_stop_info_read</code> , 187 <code>spe_context_event_priv_ptr_t</code> , 179 <code>spe_context_event_priv_t</code> , 179	<code>u64</code> <code>spe_event_data</code> , 19 <code>ui</code> <code>addr64</code> , 5 <code>ull</code> <code>addr64</code> , 5
speh <code>image_handle</code> , 7	
SPU_In_Mbox <code>spe_spu_control_area</code> , 34	
SPU_Mbox_Stat <code>spe_spu_control_area</code> , 34	
SPU_NPC <code>spe_spu_control_area</code> , 35	
SPU_Out_Mbox <code>spe_spu_control_area</code> , 34	
SPU_RunCtl <code>spe_spu_control_area</code> , 35	
SPU_Sig_Notify_1 <code>spe_sig_notify_1_area</code> , 32	
SPU_Sig_Notify_2 <code>spe_sig_notify_2_area</code> , 33	
SPU_Status <code>spe_spu_control_area</code> , 35	
spu_status <code>spe_stop_info</code> , 37	
status <code>spe_context_info</code> , 18	
stop_event_pipe <code>spe_context_event_priv</code> , 17	
stop_event_read_lock <code>spe_context_event_priv</code> , 17	
stop_reason <code>spe_stop_info</code> , 36	
TAG <code>elf_loader.c</code> , 65	
tag <code>mfc_command_parameter_area</code> , 8	
THREADS_PER_BE <code>info.h</code> , 86	
toe_shadow <code>spe_program_handle</code> , 30	
u32 <code>spe_event_data</code> , 19	